User Manual



x-mini
CLICK 2

Bottom view



1 Power button

Power/pair | Volume up | Camera shutter

Pairing devices:
Press and hold power button until power on prompt is heard. Search for new Bluetooth device and select X-mini™ CLICK 2. The connected prompt is heard once the speaker is paired successfully.

*If pairing is unsuccessful, switch off and on X-mini™ CLICK 2 to reattempt.

Disconnecting devices:
Press and hold power button until power off prompt is heard.

*Speaker will turn off automatically when disconnected and idle for 5 min.

Camera shutter function:
Press power button twice to take a picture when in a camera application.

2 Microphone

Answering call: Press power button once
End call: Press power button once

*Functions and indication tones may vary between devices.

3 LED light

- Power on
- Charging
- Low battery
- Connected/ Incoming call
- Pairing mode
- Fully charged

*Audio output gets softer and a warning tone is heard when the battery level of the speaker is low. Recharge before use.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.