Kodak

Video Monitor CFH-V10





This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

Warning

To prevent Fire or Shock Hazards, Do Not Expose This PRODUCT to Rain or Moisture.

Apparatus shall not be exposed to dripping or splashing and no object filled with liquids, such as vases, shall be placed on the apparatus.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following
measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
RF Exposure Statement
To maintain compliance with FCC’s RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

Camera Mounting

To mount the KODAK Video Monitor CFH-V10 to a wall, unscrew the base of the camera and remove the metal plate.



With the included screws and anchors, fasten the mounting bracket on to the wall. Then, reattached the base cover and screw the stand back on to the mounting bracket.

1. iSecurity+ App

To get started, download the iSecurity+ app from Apple's App store or the Google Play Store.

2. Connect to Power

Connect the KODAK Video Monitor CFH-V10to the AC power adapter, then plug your power cord into the electrical outlet.

3a. Wi-Fi Setup Mode

Please make sure the “Wi-Fi Setup” switch on the back of the camera is set to ON.

The “Wi-Fi Setup” indicator will glow green when the KODAK Video Monitor CFH-V10 is ready for setup. (This may take up to 2 minutes when the camera is first powered on.)

3b. Connect to KODAK Video Monitor CFH-V10

iPhone



Android

Go to Settings -> (Wireless & Networks for Android) Wi-Fi on your device and connect to the KODAK Video Monitor CFH-V10 network (denoted by "+CAM-Pro" plus the last 4 digits of its CAM ID, which can be found on the back of the camera).

4a. Launch iSecurity+ App

Once your device establishes its connection to the KODAK Video Monitor CFH-V10, (usually takes around 30 seconds) launch the iSecurity+ App.

The iSecurity+ app will automatically detect your camera. When prompted, click 'Yes' to setup your camera.

4b. Setup Wizard

Follow the instructions in the Camera SetupWizard to complete installation.



5. Using iSecurity+

Please enter your user name and password, created during the setup process, in the login window to access your KODAK Video Monitor CFH-V10.



6a. iSecurity+ Features – Main Window



6b. iSecurity+ Features – Camera Viewer



Take a Snapshot

Audio Muting Off/On

Audio-only Mode

Record a video clip

Safety Information

Do not point the camera directly at the sun, or else it will damage the image sensor.

Keep the camera away from heat to avoid electric shock.

Keep the camera away from rain and moisture.

Do not attempt to open, dismantle, repair, or service the camera. Doing so may cause electric shock and other hazards.

Any evidence of misuse, abuse, or tampering will void the Limited Warranty.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated withminimum distance of 20 cm between the radiator and your body. Use only the supplied antenna.

Troubleshooting

LED Status Indicators

Wi-Fi Setup

Green:	Setup mode on
Orange:	Setup mode initializing
Light Off:	Setup mode off

Network

Green:	Connected to iSecurity+
Flashing Green:	Connected to the Internet
Orange:	Connected to local network
Flashing Orange:	Not connected to any network

Power

Green:	Power On

For More Information

To get the latest camera driver updates or to learn more about Imogen Studio products, please visit: **www.imogenstudio.com**

To get the latest software updates or to learn more about Seedonk, please visit: **www.seedonk.com**

Kodak

Revised July 30, 2014