INSTRUCTION MANUAL

A preliminary draft copy of the Users Manual follows:

Introduction

Welcome

Thank you for choosing your Motorola phone from a global leader in communications technology. All Motorola digital cellular phones are designed and manufactured to meet Motorola's rigorous specifications and world-class quality standards. During development, our laboratory testing team took your cellular phone through rigorous durability tests including temperature, humidity, shock, dust, vibration, and drop tests—and the phone still worked!

We are confident that the phone you purchased will meet your own exacting standards. Enjoy your Motorola phone.

PHONE GRAPHIC TO BE SUPPLIED
OR ON INSIDE OF FRONT COVER

Understanding this Manual

Many of your phone options are accessed by a simple menu system. A full description of the menus and how to move around them is covered in the next section ***Menu Navigation***. When the manual describes the use of each menu item, it will be assumed that you are familiar with the menu system.

Key Presses

Key presses are represented in this manual using symbols so that you may locate and use the required sequence quickly. A sequence of key presses may be shown as follows:

FCN 0 7 CLR

This means you should press FCN followed by 0, 7, and then CLR, in sequence, not simultaneously.

Prompts and Messages

Your phone responds to key presses by displaying either easy to understand prompts that guide you to the next action, or simple messages confirming that your action is complete. Prompts and messages are represented in this manual in LCD style, for example:

`Enter 1st Letter` or `Location ——`

Other Symbols

You will find the following symbols used throughout this manual:

A Note contains additional information which is relevant to the feature/item.

A Caution contains important additional information which is relevant to the efficient and/or safe usage of your phone.

This symbol indicates a short key sequence for the feature.

Menu Navigation

A large number of your phone's options are accessed by using menus which use a common approach for selection, change and cancellation.

Please read this section carefully before attempting to access a menu option. When you understand the common approach to menu navigation and how the menus are shown on the page, you will be able to access and change options with ease.

Menus and Sub-menus

A menu is a simple list of options. Some of these options provide access to a further list of options called a sub-menu. When navigating through the menus you may find it is helpful to think in terms of menu levels - the 'parent' menu being on one level and its sub-menus being on a lower level.

Navigating the Menus

You can navigate through the menu system using the three keys located on the left side of the phone. Use the upper and lower volume keys to scroll to sub-menus and to control volume. Use the middle Smart Button to choose menus and functions.

Follow these symbols as a guide for using the keys on the side of your phone:

Press ⊕ to scroll up.

Press ⊕ to select.

Press ⊕ to scroll down.

You can also use your phone's ◄✱ and #► keys to scroll through the menu system.

Leaving the Menus

Press END to exit the menu.

Menu Options with Security Codes

Some options are protected from misuse by requiring you to entry one of the security codes. To use these options, you must enter the requested code before proceeding.

Total Customer Satisfaction

At Motorola, Total Customer Satisfaction is a top priority. If you have a question, a suggestion or a concern about your Motorola Cellular Phone, Motorola wants to hear from you.

Please contact the Motorola Cellular Response Center by fax on: +44 (0) 131 458 6732, or use one of the local phone numbers in the following countries:

Austria	0660 7246
Belgium	0800 72 370
Czech Republic	00420 2 21 85 21 01
Denmark	4348 8005
Egypt	02 3411800
Eire	01 402 6887
Finland	0800 117 036
France	0 803 303 302
Germany	0180 35050
Greece	00800 441 28150
Italy	02 696 333 16
Jordan	06 863750
Kuwait	484 2000 Ext 1177
Lebanon	01 744156
Luxembourg	0800 21 99
Netherlands	0800 022 27 43
Norway	22 55 10 04
Oman	790925
Portugal	01 318 0051
Qatar	418999
Saudi Arabia	01 2303294
South Africa	0800 11 48 49
Spain	902 100 077
Sweden	08 445 1210
Switzerland	0800 553 109
Turkey	0212 425 9090
UK	0500 55 55 55
United Arab Emirates	04 32 11 66
Hong Kong	852 25063888
People's Republic of China	86 10 68466060
Singapore	65 4855 333
Taiwan	886 2 87731746
United States of America	1 800 331 6456
Canada	1 800 461 4575

For e-mail questions contact:mcrc@ei.css.mot.com

For Internet questions contact:http://www.mot.com

Contents

Safety
Important information for the efficient and safe operation of your phone 7

About Your Phone and Battery
Introduces your phone, explains how to charge and maintain batteries 13

Using Your Phone
Explains how to place calls, how to redial, how to end a call, and how to use the phone memory 19

Using the Menu Features
Provides an explanation of the Menu Features and how to use them 29

Using the Messaging Menu
Provides an explanation of the Message Center and how to use it 53

Using the MiniBrowser
Provides an explanation of the MiniBrowser and how to use it 59

Accessories
Details the accessories available for use with your phone 65

What To Do If...
Helps you to solve any problems that may occur 67

Index
A comprehensive Index 77



The Manufacturer reserves the right to make changes in technical and product specifications without prior notice.

Safety

Wireless Phone Safety Tips

"Safety is your most important call!"

Your Motorola wireless telephone gives you the powerful ability to communicate by voice - almost anywhere, anytime, wherever wireless phone service is available and safe conditions allow. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. If you find it necessary to use your wireless phone while behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your Motorola wireless phone and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
2. When available, use a hands-free device. If possible, add an additional layer of convenience to your wireless phone with one of the many Motorola Original hands-free accessories available today.
3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
5. If you receive an incoming call at an inconvenient time do not take notes or look up phone numbers while driving. Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility—driving safely.
6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be station-ary. If you need to make a call while moving, dial only a few numbers, check the road and your mir-rors, then continue.
7. Do not engage in stressful or emotional conversa-tions that may be distracting. Make people you are talking with aware you are driving and suspend con-versations which have the potential to divert your attention away from the road.
8. Use your wireless phone to call for help. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.[1]
9. Use your wireless phone to help others in emergen-cies. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.[1]
10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.[1]

---

1. Wherever wireless phone service is available.

Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

For more information, please call 1-888-901-SAFE or visit the CTIA website at www.wow-com.com ™ .

Hand-Held Portable PCS Telephone

IMPORTANT

Read this information before using your PCS Telephone

Exposure To Radio Frequency Signals

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standard bodies:

- ANSI C95.1 (1992)[1]
- NCRP Report 86 (1986)[1]
- ICNIRP (1996)[1]

These standards are based on comprehensive and periodic evaluations of relevant scientific literature. For example, over 120 scientists, engineers and physicians from universities, government health agencies and industry reviewed the available body of research to develop the updated ANSI Standard (C95.1).

The design of your phone complies with the FCC guidelines (and these standards).

Antenna Care

Use only the supplied or approved replacement antenna. Unauthorised antennas, modifications or attachments could damage the phone and may violate FCC regulations.

Phone Operation

Normal Position: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation: For your phone to operate most efficiently:

- Extend your antenna fully (if applicable).
- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

1. *American National Standard Institute: National Council on radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection*

Batteries

All batteries can cause property damage, injury or burns if a conductive material such as jewelry, keys or beaded chains touches exposed terminals. The material may complete an electrical circuit and become quite hot. To protect against such unwanted current drain, exercise care in handling any charged battery, particularly when placing it inside your pocket, purse or other container with metal objects. When the battery is detached from the phone, your batteries are packed with a protective battery cover; please use this cover for storing your batteries when not in use.

Driving

Check the laws and regulations on the use of wireless telephones in the areas where you drive. Always obey them. Also, if using your phone while driving, please:

- give full attention to driving - driving safely is your first responsibility
- use hands-free operation, if available
- pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six (6”) inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- Should **ALWAYS** keep the phone more than six inches from their pacemaker when the phone is turned on.
- Should not carry the phone in a breast pocket.
- Should use the ear opposite the pacemaker to minimise the potential for interference.

If you have any reason to suspect that interference is taking place, turn your phone **OFF** immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone **OFF** in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone **OFF** in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Switch **OFF** your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone **OFF** when in a "blasting area" or in areas posted: "turn off two-way radio". Obey all signs and instructions.

Potentially Explosive Atmospheres

Turn your phone **OFF** and do not remove the battery when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks, from your battery, in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always clearly marked. They include fueling areas such as gasoline stations; below deck on boats; fuel or chemical transfer or storage facilities; areas where fuel odors are present, i.e. if a gas/propane leak occurs in a car or home; areas where the air contains chemicals or particles, such as grain, dust, or metal powders; and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. **DO NOT** place objects, including both installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

About Your Phone and Battery

Phone Overview

See the inside front cover of this manual for a diagram of the components described below.

Retractable Antenna—Provides superior connectability. Extend for best performance.

Earpiece—Ultra-compact phone speaker.

Accessory Connector Port—Provides the connections for an external power supply and vehicular and optional accessories.

Headset Jack—Provides the connection for an optional headset.

Microphone—Positioned for convenient conversation.

Alphanumeric Display—Displays your input from the keypad, information recalled from memory, and other messages.

Function Keys

(Power)—Turns the phone On and Off.

(FCN)—Acts as a "shift" key to access the secondary functions of other keys.

(RCL)—Recalls phone numbers from memory and acts as the left soft key for MiniBrowser navigation.

(STO)—Stores phone numbers into memory and acts as the right soft key for MiniBrowser navigation.

(CLR)—Clears characters from the screen.

(END)—Ends phone calls.

(SEND)—Places or answers calls.

(◄ ✱) and (# ►)—Can be used to scroll through memory entries and menu features.

(✉) **Messaging Menu button**—Opens messaging menus.

⊕ **Smart Button**—Use the Smart Button to place and end calls, enter menus, toggle features on and off, and select items in the display. See

⊕⊖ **Volume Keys**—The upper and lower volume keys can adjust keypad, earpiece, and ringer volume. After pressing the Smart Button, the volume keys also scroll through memory entries and menu features.

Using the Smart Button

Use the Smart Button to place and end calls, enter menus, toggle features on and off, and select items in the display. The Smart Button is the middle key on the left side—easy to feel, easy to find, and easy to use.

The symbol ⌖ in your display represents the Smart Button.

Selecting Items in the Display

The primary use of the Smart Button is to make selections. Whenever the phone offers you a choice, such as setting a ringer style, press ⊕ to select it. You will see: `Press ⌖ to Select`.

Toggling Features On and Off

Some of your phone's features toggle on and off. Use the upper or lower volume key to scroll to the desired feature, then press the Smart Button to select it. You will see: `Press ⌖ to Toggle`.

Entering the Menu System

Press (FCN), then press ⊕ to enter the phone's menu system.

⊕ *You can also enter the menu system by pressing* (FCN) (1).

Placing and Ending a Call

To place a call when the number you want to call is on the display, press and hold ⊙. Press and hold ⊙ again to end a call. See "Using Your Phone" on page 19.

Opening the Quick Menu

When your phone is idle, press ⊙ to display a menu containing shortcuts to your phone's most popular features. See page 22.

Opening Your Phone Book

To open the Phone Book with all your names and numbers, press ⊙ twice. See page 23.

Controlling Volume

Use the upper and lower volume keys to adjust earpiece, keypad, and ringer volume. When you press these keys, the phone's speaker demonstrates the current volume level.

Adjusting Earpiece and Keypad Volume

The audio feedback your phone gives you when you press a key is called keypad tones. To adjust the volume of the keypad tones, use the volume keys when your phone is idle.

⊙ *To silence the keypad tones, see page 39*

To adjust the volume of your conversation (the earpiece volume) use the volume keys during a call.

Press ⊙ to raise the volume or press ⊙ to lower the volume.

Adjusting Ringer Volume

To adjust ringer volume:

Press FCN ⊙ to raise the volume or press FCN ⊙ to lower the volume.

The Display

The display on your phone can show alphanumeric characters as well as useful information symbols.The various elements of the display are as follows



1.		**Signal Strength**. The more segments displayed in the bar graph, the better the signal strength.
2.	**D**	**Digital Indicator.** If you are in a digital coverage area, the digital indicator appears. Your phone operates more efficiently in Digital mode.
3.	**IU**	**In Use Indicator.** Displayed when a call is in progress.
4.	**Rm**	**Roam.** Lights up when your phone accesses a wireless service outside of your home system. When you leave your wireless Service Area, your phone roams (seeks another wireless system).

5.	**NS**	**No Service Indicator**. If you travel beyond the range of a cellular system, the No Service Indicator appears to let you know that calls cannot be placed or received from your location.
6.	✉	**Short Message Service***. Displayed when the phone has received a message. The symbol will flash when your message storage area is full.
7.	✉ ·))	**Voicemail Waiting Indicator***. Displayed when you have a voice message waiting.
8.	⊕	**Battery Charge Indicator**. The more segments displayed, the greater the battery charge.
9.	12:00	**Clock.** When your phone is using a CDMA digital network, the display shows the current local time and date. You can set your clock for 12- or 24-hour format. See page 99 for more information.

*The availability of this feature depends on your service provider.

Your Battery

Installing the Batteries

New batteries are supplied uncharged and fitted within a protective battery carrier. To remove the batteries, press the release catch on the battery carrier and open the cover.

To install the batteries in your phone:

1. Press the release catch of the phone battery cover and slide the battery cover towards the bottom of the phone.
2. Align the positive and negative (+ and -) connections on the battery with the positive and negative (+ and -) connections within the phone.
3. Press the battery towards the connections and push it downwards until it clicks into place.
4. Replace the phone battery cover.



To Be Completed

Important Battery Information

Always treat your batteries with care. See 'Batteries', at the beginning of this manual.

Never leave your battery in extremely high temperatures (over 60°C), for example behind glass in very hot, direct sunlight.

Only Motorola Original Accessory batteries can be charged in the phone. This is to protect you and your phone from the risks of incorrect charging.

Charging a New Battery

New batteries are supplied in a totally uncharged state.

To ensure maximum battery performance, a new battery (or battery that has not been used for several months) should be charged for at least 14 hours before use.

A new battery will require several full charge/discharge cycles in order to achieve its optimum performance.

A new battery, or a battery that has not been used for several months, may cause a premature fully charged indication. Ignore this indication and let the battery charge for several more hours, remove and re-insert the battery into the charger, and charge for an additional 14 hours.

Your batteries will not charge if they are not matched properly to the phone connection markings (+ and -). Please ensure that you have installed the batteries properly before initiating a charge.

To ensure that you enjoy maximum battery life and use your battery to its fullest capacity:

- The battery should be at or near room temperature when charging.

Battery Performance and Maintenance

- Best battery performance will be achieved when you regularly charge and discharge batteries as instructed in this manual.
- Battery performance is greatly affected by network coverage.
- Set `Battery Saving Mode` to On (see 'Phone Setup Menu') and/or `Frequency of Search` to Slow or Medium (see 'Network Selection Menu').
- If left unused, a fully charged battery will discharge itself in approximately one month.
- When not in use, store your battery uncharged in a cool, dark and dry place.

Removing Your Batteries

! *Switch off your phone before removing batteries. Failure to do so may damage your phone memory.*

1 Press the release catch of the phone battery cover and slide the battery cover towards the bottom of the phone.

2 Remove the batteries.



To Be Completed

Charging Your Battery Using the Travel Charger

The travel charger can power the phone and charge a fitted battery.

! *Ensure that the local mains voltage at your location matches that of your travel charger.*

Install the batteries into your phone (see 'Installing the Batteries').

To charge your battery:

1 Attach the correct adapter plug to the travel charger.

2 Connect the travel charger to the phone.

The connector is keyed and can only be inserted one way.



To Be Supplied

3 Insert the travel charger plug into a suitable mains power socket.

A beep-tone is heard and the battery icon flashes when charging begins.

The beep-tone on the phone will not occur if the batteries are installed improperly. The beep-tone may take two minutes to occur with new or fully drained batteries.

The state of charging is monitored and displayed by your phone. See 'Battery Meter Indicators' later in this section for details.

Low Battery Warning

When the battery level is low and only a few minutes of talk time remain, a warning signal (two double beeps) will sound, and `Low Battery` will be displayed.

For a detailed battery level reading: Press FCN 4.

The more segments filled on the battery gauge (**B**▁▂▃▄▅), the greater the charge.

When the battery is completely discharged, your phone will turn off.

Battery Indicators

Your phone monitors and displays information about your battery. The following message will appear on the display, as the condition occurs:

`Low Battery`	The battery charge is low. The battery should be recharged.

Battery Meter Indicators

The battery meter displays different messages depending on the batteries attached, and whether or not there is an external power source. The battery meter is found in the Call Related Features part of the Options Menu.

`Charging Battery`	The battery is being charged.
`Charging Complete`	Charging is complete.

When the battery is completely discharged, you must charge the battery for one minute before you can make or accept a phone call.

Placing and Receiving Calls

This section explains how to:

- turn your phone ON and OFF
- place calls, end calls, and receive calls.
- redial phone numbers
- mute your phone

Turning Your Phone On and Off

To turn the phone on:

1	**Extend Antenna**	Extend the antenna completely for best performance.
2	**Open Phone**	Open the phone to expose the keypad.
3	**Turn ON Phone**	Press and hold (Power) until the display appears and you hear an audible alert.

To turn the phone off, press and hold (Power) again. Powering off will be displayed, and you will hear an audible alert.

What You Will See

When you turn on your phone, it performs a self-test to let you know it is operational and then it scans for a service. While the phone scans, the display reads: Searching.

When your phone finds a CDMA digital system, you will see the time and date and the icon.

Power Save Mode

If you travel outside the range of available networks, your phone continues to search for a signal. To save power, it stops searching every couple of minutes.

Your phone will automatically begin searching again in a minute or two – if you would like it to start searching immediately, just press any key.

Standby Mode

To conserve energy, your phone enters standby mode and turns off the backlight when you have not touched a key for a few seconds. The backlight will come back on as soon you press a key or open the phone.

Placing a Call

To place a call:

1	**Extend Antenna**	Extend the antenna completely for best performance.
2	**Open Phone**	Open the phone to expose the keypad. If necessary, press (Power) to turn the phone ON.
3	**Enter Number**	Enter the number you want to call, for example: 555-1212.
	Correct Errors	Press (CLR) to erase one digit at a time if you make a mistake. Press and hold (CLR) to erase the entire entry and start again.

4	**Place Call**	Press (SEND) to place the call. **or** Press and hold until you hear a high tone. You will see: Calling 555-1212.

You can also recall a previously dialed or stored number. (See "Using Phone Memory" on page 23 for details on storing or recalling.)

You can dial phone numbers with up to 32 digits, but only the last 20 digits appear in the display.

Press (RCL) to see the entire phone number.

Your phone will display the first 24 digits, then a second screen will show the digits remaining in the phone number.

Ending a Call

There are three ways to end a call:

	Close	Close the phone to end a call.
or	**Press Key**	Press (END).
or	**Hold Smart Button**	Press and hold until you hear a high tone. You will see: Press * to End Call. Press again to end the call.

Receiving a Call

Your phone must be powered on to receive calls.

To answer a call:

1	**Extend Antenna**	Extend the antenna completely for best performance.
2	**Open Phone**	Open the phone to expose the keypad. **or** Press (SEND) if the phone is already open.

Caller ID

If Caller ID* is active on your phone, you will be able to see who is calling before you answer. The display will show either your caller's name (if in your Phone Book) or your caller's number. If you prefer to always see your caller's number, see page 32 to turn Number Preference ON.



The Caller IDs for your last 16 callers will be saved. See page 54 to learn how to view your stored Caller IDs.

Unanswered Call Indicator

Even with the latest wireless technology, sometimes you are unavailable to answer calls. If your phone is ON, it keeps a count of unanswered calls. For example, if you miss two calls, your display will show: 2 Calls Unanswered.

Clear Display	Press (CLR) or press (END) to clear the display, and you can begin placing calls again.

If you subscribe to Caller ID service, you can easily return the calls that you missed. See page 50 to learn how to return the calls you missed.

* *Contact your Service Provider for availability.*

Call Waiting

If you subscribe to Call Waiting through your Service Provider, you may hear a tone while on a call, indicating that you are receiving a second call.

	Answer Call	Press SEND to answer the call and automatically place the current call on hold.
or	**End Current Call**	Press END to end the current call. Your phone will then ring as usual. Press SEND to answer the call.

Redialing a Number

Automatic Redial

The wireless system may at times be too busy to handle your call. If this is the case, you may hear a fast busy signal and see Call Failed and Press SND to Redial. With Automatic Redial, your phone will repeat the call attempt over the next four minutes. When the call succeeds, your phone will ring until the person you are calling answers.

To use Automatic Redial:

Press SEND or press and hold until you hear a high tone. You will see: Redialing.

To make this feature even easier, turn Instant Redial ON. Your phone will instantly redial after a fast busy signal, and you will not have to push a button. To find out more, see page 95.

Redial

If you hear an ordinary busy signal:

1	**Hang Up**	Press END to hang up.
2	**Redial**	Press SEND to redial. **or** Press and hold you will see: Calling.

Display Last Ten Numbers Dialed

Your phone keeps track of the last ten numbers you have dialed.

1	**Enter List**	Press RCL then press 0, 0. The display will show the last number you dialed.
2	**Review List**	Press ▲ or ▼ to scroll through the last calls made, including the time, date, and number.
3	**Call Number**	Press SEND or press and hold to call the number in your display. You will see: Calling.

Muting the Microphone

For privacy during a call, mute the microphone. You can hear the person on the other end, but he or she cannot hear you.

Mute Phone	Press FCN then press 6 during a call to mute the microphone. You will see: Muted.
Unmute Phone	Press FCN then press 6 again to resume your conversation.

Using the Quick Menu

Throughout this guide you will see shortcuts that point out simple ways to reach some of your phone's features. If you have owned a Motorola phone before, some of these shortcuts will already be familiar to you.

The Quick Menu

Press the Smart Button and the Quick Menu opens on the display.

The Quick Menu contains shortcuts to your phone's most popular features. Press the volume keys to scroll through the options shown below and press the Smart Button to choose one.

Phone Book	The Phone Book is the place to find all your personal names and numbers. See page 32.
Messaging	If you subscribe to messaging, you can use this shortcut or the one on page 53.
Last 10 Dialed	Your phone remembers the last ten numbers you dialed. Turn to page 21 to learn more.
Main Menu	Select this option to access your phone's menu system. See page 29 to find out more.
Exit	Select this option or press (END) to exit the Quick Menu at any time.

The Usual Shortcuts

The words "menu," "batt," "lock," and "mute" appear on the (1), (4), (5), and (6) buttons. Press the (FCN) key first, then any one of these buttons, and your phone will perform that function.

Enter Menu	Press (FCN) then press (1) to enter the menu system.
Display Meter	Press (FCN) then press (4) to display the battery meter.
Lock Phone	Press (FCN) then press (5). You will see: Lock? Press (STO) to lock.
Mute Phone	Press (FCN) then press (6) to toggle mute ON and OFF during a conversation.

Using Phone Memory

Use your phone's internal Phone Book to store up to 99 names and numbers for easy access.

In this section you will learn how to:

- store names and numbers into the Phone Book
- recall phone numbers from memory
- clear names and numbers
- dial a number with Speed Dial and Turbo Dial™
- make notes on the scratchpad
- store numbers with pause dialing
- store calling card sequences for easy access

Using Your Phone's Built-in Phone Book

Each phone number in your phone book is stored in a *memory location* numbered 01-99.

Arrange numbers for easy recall by storing related numbers in groups. If you store the numbers you call most in locations 01-09, then you can use Turbo Dial™ to call those numbers with a single key. (See "Using the Turbo Dial™ Function" on page 25 for details.) You could store business contacts in locations 10-19, family in 20-29, friends in 30-39, and so on.

You can also store names to identify phone numbers. Later, you can recall a number by the name that corresponds to it.

Storing Names and Numbers

Each memory location can store up to four numbers. For a single contact, you can store every number you need, like home, mobile, fax, and more.

Keep in mind: Your Phone Book sorts alphabetically by the first letter in the entry. If you store an entry without a name it will be placed at the back of the Phone Book

How to Store Phone Numbers

1	**Enter Number**	Enter the phone number you want to store. You can store up to 32 digits per phone number entry.
2	**Begin Storing**	Press STO to begin storing. You will see: Location xx?. 'XX' is the number of the lowest available location.
3	**Accept Location**	Press STO or ◄✱ to store the sequence in the displayed location.
or	**Enter New**	Press CLR to erase the location number and enter a new two-digit location number.
or	**Select Range of Ten**	Enter the first digit of the memory location, then press ◄✱ to store the sequence in the first available location beginning with that digit. For example, if you store personal numbers in the twenties, press 2 ◄✱.
4	**Enter Name**	Enter a name to identify the phone number. (See the following section for details on entering names.) Press ⊕ or STO when finished. Your phone will confirm the entry by displaying the information stored.

How to Enter Names

When the display shows Alpha Or *, you can press the numeric keys one or more times to produce any letter or number in the alphabet. Use the letters printed on each key as a guide. For example, press 2 to enter "A," "B," "C," or "2" as shown:



1	**Enter Letter**	Press a key as many times as necessary to enter a letter. The next letter on the key will appear with each press.
	Toggle Case	Press ⊕ or ⊖ to switch between upper and lowercase.
2	**Advance Cursor**	After each character, press #▸ to advance the cursor to the next space.
	Clear Letter	Press CLR to erase a letter if you make a mistake.
	Back Space	Press ◂✱ to move the cursor backward if you would like to insert a letter earlier in the sequence.
3	**Choose Label**	Press 0 to scroll through the available labels. After 0, you will see Home, Mobile, Pager, or Work.
4	**Enter Marks**	Press 1 to scroll through the available punctuation marks: <space> 1 ! " $ % & ' @ ( ) + , - . / \ : ; < = > ? [ ] _ * #.
5	**Finish Storing**	Enter up to 20 letters. Press ⊕ when you are finished. Your phone will confirm the entry by displaying the information stored.

Recalling an Entry by Name

After storing names and numbers, you can recall them alphabetically and immediately place calls.

1	**Enter**	Press ⊕ twice to enter your name directory.
2	**Scroll to Name**	Press ⊕ or ⊖ to scroll to the name you are looking for.
or	**Search for Name**	Enter the first letter of the name. The display will show the name and memory location of the first entry beginning with that letter, and an icon for each number stored in the entry (up to four).
3	**Place Call**	Press and hold ⊕ or press SEND to call the number. You will see: Calling.
4	**End Call**	Press END or close the phone. **or** Press and hold ⊕ until you hear a high tone. You will see: Press * to End Call. **then** Press ⊕ again.

Recalling an Entry by Memory Location

Each name and number you store is placed in a memory location numbered 01-99. Once you have stored names and numbers, you can recall them by memory location:

1	**Begin**	Press RCL to begin recalling.
2	**Enter Location**	Enter the two-digit memory location of the phone number you are looking for.
3	**Place Call**	Press and hold ⊕ or press SEND to call the number. You will see: Calling.
4	**End Call**	Press END or close the phone. **or** Press and hold ⊕ until you hear a high tone. You will see: Press * to End Call. **then** Press ⊕ again.

Clearing a Phone Memory Entry

To erase a memory entry:

1	**Recall Entry**	Press ⊕ twice and then press ⊕ or ⊕ to scroll to the name you are looking for. or Press RCL and the two digit location number of the entry.
2	**Clear Entry**	Press CLR to clear the entry. You will see: To Delete Press STO.
3	**Confirm Erase**	Press STO to confirm that you want to erase the entry.

Shortcuts for Recalling Phone Book Entries

Using Speed Dial

If you know the memory location of the number you want to call, try the Speed Dial function:

1	**Enter Location**	Enter the two-digit memory location of the phone number you are looking for.
2	**Place Call**	Press and hold ⊕ or press SEND to call the number. You will see: Calling.

Using the Turbo Dial™ Function

The Turbo Dial™ function enables you to dial numbers stored in locations 01-09 with the push of a single button:

Turbo Dial	Press and hold the memory location number of the entry you want to call, 1 through 9, and your call is placed. You will see: Calling.

Your phone's Priority Call feature gives you fast access to any number stored in location 01. To learn more about this feature, see "Priority Call" on page 42.

Making Notes on the Scratchpad

In addition to your internal phone book, you also have a built-in scratchpad for making quick notes. The scratchpad remembers the last phone number shown on your display.

Entering a Number in the Scratchpad

If you are on the phone and your party gives you another number to call, enter the number on the scratchpad so you can place the call later.

1	**Enter Number**	Enter the number with the keypad. (The person on the line will hear tones as you dial.)
2	**Store Number**	Press STO, enter a two-digit location, enter a name with the keypad, and press STO to finish. See page 23 for more details.
or	**End Call**	Press END to end your current call if necessary.
and	**Place Call**	Press SEND to call the number in the Scratchpad.

Pause Dialing

When you call automated systems like Voice Mail or bank by phone, a recorded message prompts you for PIN numbers, account numbers, etc. Pause Dialing can make using automated systems easy by allowing you to store these numbers in the same memory location as the automated system's access number. Separate each set of numbers with a "pause"– a special character that tells your phone to wait before sending additional numbers.

Storing a Number with Pause Dialing

The pause occupies a one-digit space in your phone's memory. Once you have entered a string of numbers and pauses, store the string in the same way you store other entries.

You can store up to 32 digits, including pauses.

1	**Enter Number**	Enter the phone number you use to access the automated system.
2	**Insert Pause**	Press FCN and press SEND. You will see: Insert Pause o. Press ⊕. You will see a pause circle o inserted into the number entry.
3	**Enter PIN**	Enter the next group of numbers, for example, your PIN number. If the automated system requires a * or #, enter those symbols, too.
4	**Insert More Pauses**	Repeat steps 2 and 3 as many times as necessary.
5	**Store Sequence**	Press STO. Enter a two-digit location, select a label, enter a name if you like, and press STO or ⊕ when finished. Your phone will confirm the entry by displaying the information you stored.

Using Pause Dialing

Once stored, you may recall the entry and place the call. All of the digits you have stored will be recalled, but your phone will only send the tones for the set of numbers before the first pause.

1	**Place Call**	Enter the two-digit memory location of the Pause Dialing number and press and hold ⊕ or press SEND . Your phone will dial the access number and wait for your input when it reaches the first pause.
2	**Send More Numbers**	When the automated system prompts you for information, press ⊕ or SEND to send the next group of numbers. Repeat this step to send each group of numbers that you have stored.
3	**End Call**	Press END, close the phone, or press and hold ⊕ until you hear a high tone and press ⊕ again.

Using Memory Linking

Each memory location holds up to 32 digits, including pauses. Some automated systems, however, may require you to enter more than 32 digits. If this is required, split the numbers into two memory locations and recall the second set of digits as you need them.

1	**Recall 2nd Location**	Once you have sent the tones from the 1st location, press RCL and the two-digit memory location where you stored the second set of digits.
2	**Send Tones**	Press RCL and SEND to send the tones in the 2nd location. If you have stored a pause in the 2nd location, your phone will pause as usual when it reaches the pause character.

Using Calling Cards

Storing Calling Card Numbers

Number Characters are another way your phone can save you time in dialing. The Number Character saves a place in the memory sequence for whatever number you are calling when you use your calling card. For best results, you may use the Number Character along with Pause Dialing.

1	**Enter Access Number**	Enter the phone number you use to access the calling card system, usually a 1-800 phone number. Skip this step if you only dial 0.
2	**Insert Pause**	Press FCN then press SEND . You will see: Insert Pause o. Press ⊕.
3	**Insert Number Character**	Press FCN then press SEND. Press ⊕ or ⊖ to scroll to Insert Number ´N. Press ⊕. You will see the number character ´N inserted into the sequence. This special character saves a place for the number you will be calling when you use your calling card.
4	**Insert Pause**	Press FCN then press SEND then ⊕ as in step 2.
5	**Enter Code**	When you use your calling card, the system prompts you for an access code, usually a PIN code. Enter this number. Repeat steps 4 & 5 if your card requires more access codes.
6	**Store Sequence**	Press STO. Enter a two-digit location, select a label, enter a name if you like, and press STO or ⊕ when finished. Your phone will confirm the entry by displaying the information you stored.

☞ *You can protect your calling card information with your phone's call restriction features. See page 86 for details.*

Placing a Calling Card Call

Once you have stored your calling card information, recall the information and place the call whenever you want to use your calling card. Before your phone begins dialing, it will prompt you for the number you want to call. Once you have entered the number, your phone will automatically insert the number in place of the Number Character you stored.

1	Recall Entry	Press RCL then enter the location number where your calling card sequence is stored.
2	Enter Number	Press SEND. You will see: Enter Number. Enter the phone number you are calling. You may enter the number manually or recall it by location.
3	Place Call	Press and hold to place the call. Your phone will dial the number to access your long distance provider, then wait for your input when it reaches the first pause.
4	Send More Numbers	Press or press SEND to send the next group of numbers when the recording prompts you. The phone will automatically insert the number to call at the appropriate spot in the sequence. Press to send each set of numbers until finished.
5	End Call	Press END, close the phone, or press and hold until you hear a high tone, and press again to end the call.

Using the Menu Features

Using the Menu System

Your cellular phone includes many features that can help make life easier and more productive. The phone's user-friendly menu system helps you find what you need quickly and easily.

In this section you will learn:

- what are the main menu features
- how to navigate through the menus
- how to read a menu road map

Introducing the Menu Features

As you scroll through the menu system, you will see the following icons, each representing a high-level menu.



Navigating the Menu

You can navigate through the menu system using the three keys located on the left side of the phone. Use the upper and lower volume keys to scroll to sub-menus and to control volume. Use the middle Smart Button to choose menus and functions.

Follow these symbols as a guide for using the keys on the side of your phone:

Press ⊕ to scroll up.

Press ⊕ to select.

Press ⊖ to scroll down.

You can also use your phone's ◄✱ and #► keys to scroll through the menu system.

Road Maps

To help you navigate through the phone's menu system, each section begins with an easy-to-follow visual "road map." To enter the menu features:

1	**Enter Menu**	Press FCN, then press ⊕. or Press FCN 1. "menu" is printed on the 1 key as a reminder.
2	**Scroll through Menu**	Press ⊕⊖ to scroll through the menu's top level.
3	**Exit Menu**	Press END to exit the menu.

Detailed instructions within each section describe how each feature works.

MENU

Managing the Phone Book

In "Using Phone Memory" you learned how to store and recall phone numbers with the internal Phone Book. You can access the same features, along with several advanced features, using your phone's convenient menu system.

In this section you will learn how to:

- recall and store phone numbers using the menu system
- edit your memory information
- add numbers to existing entries.
- view your own phone number.

You can also recall phone numbers without using the Phone Book. See "Recalling an Entry by Name" on page 24 or "Recalling an Entry by Memory Location" on page 25.

Start:



Recalling an Entry by Name

Once you have stored entries, you can recall them alphabetically with the Phone Book menu. Find the name, choose the number, and instantly place a call.

1	**Begin Recalling**	Press ⊕ to select Recall By Name. You will see: Enter 1st Letter.
2	**Enter First Letter**	Press the appropriate digit key as many times as necessary to enter the first letter of the name. (See page 24 for help entering letters.) You will see the first entry with that letter.
3	**Find Name**	If necessary, press ⊖ or ⊖ to scroll to the name you are looking for.
4	**Place Call**	Press and hold ⊕ or press SEND to call the displayed number. You will see: Calling.
5	**End Call**	Press END or close the phone. **or** Press and hold ⊕ until you hear a high tone. You will see: Press * to End Call. **then** Press ⊕ again.

Recalling an Entry by Location

Each name and number you store is placed in a memory location numbered 01-99. After storing names and numbers, you can recall them by memory location with the Phone Book menu.

1	**Begin Recalling**	Press ⊖ or ⊖ to scroll to Recall By Location and press ⊕ to select.
2	**Enter Location**	Enter the two-digit memory location of the number you are looking for. You will see the name, location number, and an icon for each number stored in the entry.
3	**Place Call**	Press and hold ⊕ or press SEND to call the displayed number. You will see: Calling.
4	**End Call**	Press END or close the phone. **or** Press and hold ⊕ until you hear a high tone. You will see: Press * to End Call. **then** Press ⊕ again.

⊕ *To place a quick call just enter the two-digit location and press SEND.*

Phone Book Status

You can use this feature to see how many of your Phone Book's 99 locations have been used.

1	**Select Feature**	Press ⊖ or ⊖ to scroll to Phone Book Status and press ⊕ to select. You will see: XX Full XX Empty.
2	**Exit Menu**	Press END to exit menu, or you may scroll to other features.

MENU

MENU

Storing a New Number

This feature allows you to create a new entry in the internal Phone Book. To add a number to an existing entry, turn to Editing a Memory Location on page 33.

Always store your Voice Mail number in location 98.

1	**Begin Storing**	Press ▲ or ▼ to scroll to Store New Number and press ◆ to select. You will see: Enter Number.
2	**Enter Number**	Enter the number you want to store and press ◆. You will see: Location XX?. 'XX' is the number of the lowest available location.
3	**Enter Location**	Press STO or ◄✱ to store the number in the displayed location or enter a new two-digit location and press STO.
or	**Select Range of Ten**	Enter the first digit of the memory location and press ◄✱ to store it in the first available location beginning with that digit.
4	**Enter Name**	Enter a name to identify the phone number(s) or continue with step 5. See page 24 for details on entering names.
5	**Store Number**	Press STO or ◆. Your phone will confirm the entry by displaying: Stored At XX. If the name or number is already in your Phone Book, you will see: Duplicate Name or Number.
6	**Exit Menu**	Press END to exit menu, or you may scroll to other features.

Viewing Your Number

Press RCL #►.

Use this feature to view your phone's currently active number.

1	**View Number**	Press ▲ or ▼ to scroll to View My Number and press ◆ to select. The display will show the currently active number.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Number Preference

When Placing Calls:

If you prefer to see the number (Calling 555-1212) instead of the name (Calling Jane Smith) when you place a call from the internal Phone Book, turn Number Preference ON.

When Receiving Calls:

If you subscribe to Caller ID, your phone automatically looks up callers in your Phone Book and displays the name stored in the entry. If you prefer to see the caller's number (555-1212), then turn Number Preference ON.

1	**Find Feature**	Press ▲ or ▼ to scroll to Number Prefer.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Editing a Memory Location

You can use this feature to add a number to an entry, change an old number, or duplicate an entry to make a similar one.

1 Begin Editing — Press ▲ or ▼ to scroll to Edit Memory and press ◆ to select.

2 Find by Location — Press ▲ or ▼ to scroll to Edit By Location and press ◆ to select. You will see: Location_____. Enter the two-digit memory location of the phone number you want to edit. Press ◆ or STO and continue with Step 3.

or Find by Name — Press ▲ or ▼ to scroll to Edit By Name and press ◆ to select. You will see: Enter 1st Letter. Enter the first letter of the name you want to edit. (See page 24 for information on entering letters. You will see the first entry beginning with that letter. Press ▲ or ▼ to scroll to the name you are looking for. Press ◆ or STO and continue with Step 3.

3 Edit /Add Phone Number — Enter digits. Press CLR to erase a digit at a time, or press and hold CLR to erase the entire number. Press ◄✱ to move the cursor backward.

4 Finish Number — Press ◆ or STO when you finish the phone number.

5 Change Original — If you would like to save your changes in the same location, then press ◆ or STO. You will see the name associated with the entry.

or Copy Entry — If you would like to move the entry to a new location and keep the original entry, then press and hold to erase the location and enter a new two-digit location. You will see the name associated with the entry.

6 Edit Name — Press CLR to erase one letter at a time, or press and hold CLR to erase the entire name. Press ◄✱ to move the cursor backward. (See page 24 for details on entering names.) Skip this step to leave the name unchanged.

7 Confirm Changes — Press ◆ or STO when you finish editing the name. You will see: Location XX is Full. The display wil then show the new information and you will see: Change? Press ◆ or STO again to save your changes. You will see: Stored At XX.

8 Exit Menu — Press END to exit the menu, or you may scroll to other features.

Timing Your Calls

Your phone is equipped with three visual and three audible call timers. You can monitor or record the length of individual calls, set a timer to track monthly usage, or have the phone alert you at intervals that you specify.

In this section you will learn how to:

- monitor the length of your calls
- set and view the resettable timer for long-term monitoring
- program audible timers for your individual needs

MENU

Start:



Viewing the Individual Timer

1) Press RCL then #▸ two times.
or 2) Press FCN, ⊕ then 4, 5.

The individual timer records the air-time of your most recent call in hours, minutes, and seconds. It resets before you place the next call. You can have the timer display automatically while calls are in progress. See "Auto Display Individual Timer" on page 36.

1	**View Timer**	When you enter the Call Timers menu, you will see: Individual XX:XX:XX.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Viewing the Resettable Timer

1) Press RCL then #▸ three times.
or 2) Press FCN, ⊕ then 4, 5.

You can track how much air-time you have accumulated during any time period you choose. For example, reset this timer at the beginning of each billing period to know where you stand at any given moment. Use this feature to view the time elapsed, and follow the instructions on page 35 to reset the timer.

1	**View Timer**	Press ⊕ or ⊖ to scroll to Resettable Time. You will see the air-time in minutes since you last reset the timer.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Viewing the Cumulative Timer

1) Press RCL then #▸ four times.
or 2) Press FCN, ⊕ then 4, 7.

This is a non-resettable timer that keeps track of your phone's total air-time (in minutes) since your phone was activated.

1	**View Timer**	Press ⊕ or ⊖ to scroll to Cumulative Time. You will see the total air-time in minutes.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Resetting the Timer

Press FCN, ⊕ then 4, 3 and continue with step 2.

Press FCN then 0, 7, CLR to reset the timer.

This feature allows you to monitor elapsed air-time over a period of time that you choose. After you reset the timer, it will continue to keep track of your air-time (in minutes) until you reset it again.

1	**Find Feature**	Press ⊕ or ⊖ to scroll to Reset Timer.
2	**Reset Timer**	Press ⊕ to reset. You will see: Resettable Time 00000.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Auto Display Individual Timer

Press FCN, then 4, 8 and continue with step 2.

When you turn this feature ON, your phone will automatically display your air-time in minutes and seconds during and after each call.

Activating the Auto Display Timer may reduce standby-time and talk-time.

MENU

1	**Find Feature**	Press ▲ or ▼ to scroll to Individual Timer.
2	**Toggle Display**	Press ◆ to toggle On or Off the automatic display of the individual timer.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

One Minute Audible Timer

Press FCN, then 4, 4 and continue with step 2.

Turn this feature ON to hear an audible beep 10 seconds before the end of every minute during a call. The party on the other end will not hear the beeps.

1	**Find Feature**	Press ▲ or ▼ to scroll to One Minute Timer.
2	**Toggle Timer**	Press ◆ to toggle the timer On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Repeating Audible Timer

Press FCN, then 4, 1 and continue with step 2.

You can set this timer to beep during your calls at an interval that you select—from 11-999 seconds. Like the One Minute Timer, you will hear the beep 10 seconds before the end of each interval, and the party on the other end will not hear the beeps.

1	**Find Feature**	Press ▲ or ▼ to scroll to Repeating Timer.
2	**Toggle Timer**	Press ◆ to toggle the timer On or Off.
3	**Enter Seconds**	If you toggle the timer ON, you will see: Enter Seconds. Enter the number of seconds you would like between beeps and press ◆ to set the timer. You will see: Set At XXX Secs.
4	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Single Audible Timer

Press FCN, then 4, 2 and continue with step 2.

You can set the Single Timer to beep during your calls at a time that you select–from 11-999 seconds. It will beep once during each call, 10 seconds before the end of the preset time. The party on the other end will not hear the beeps.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Single Timer`.
2	**Toggle Timer**	Press ◆ to toggle the timer On or Off.
3	**Enter Seconds**	If you toggle the timer ON, you will see: `Enter Seconds`. Enter the number of seconds you would like before the beep and press ◆ to set the timer. You will see: `Set At XXX Secs`.
4	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Adjusting Tone Controls

MENU

Use these features to personalize your phone's ringer styles, or set the phone to remind you of new messages.

In this section you will learn how to:

- choose from nine different ringer styles
- silence the keypad
- silence all your phone's tones with one convenient feature.
- set the Message Reminder.

Start:



Selecting a Ringer Style

Your new phone offers nine different ringer styles. After you choose a style, the phone will give you a brief sample of your new alert sound.

1	**Enter Feature**	Press ⊖ or ⊕ to scroll to Ringer Style and press ⊕ to select.
2	**Select Ringer**	Press ⊖ or ⊕ to scroll through the ringer styles. As you scroll, your phone will give an audible sample of the currently displayed style. Press ⊕ to select the displayed option.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Setup Message Tones

When you receive a new Voice Mail or alphanumeric message, your phone beeps three times. To change the number of beeps or to turn them OFF, use this feature.

1	**Enter Feature**	Press ⊖ or ⊕ to scroll to Setup Msg Tones and press ⊕ to select.
2	**Select Msg Type**	Press ⊖ or ⊕ to scroll to Text Msg Tone or Voicemail Tone and press ⊕ to select.
3	**Toggle Tone**	Press ⊕ to toggle between 3Beep, 1Beep, or Off. To make new messages easy to recognize, try making the number of beeps unique to each message type.
4	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Reminder Tones Setup

If you subscribe to messaging services, this feature can help you remember to check your messages. Turn Message Reminder Tones ON and your phone will remind you of unread messages by beeping every two minutes. This feature is especially helpful if you are busy or away from your phone.

1	**Find Feature**	Press ⊖ or ⊕ to scroll to Reminder TonesSetup and press ⊕ to select. You will see: CallRemind Tone.
2	**Toggle Feature**	Press ⊕ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Keypad Tones

Press FCN, ⊕ then 3, 2 and continue with step 2.

Keypad Tones are the sounds you hear when you press any key on the phone. If you want to be discreet, use this feature to silence the audio feedback from the keypad.

⊕ *Turning Keypad Tones OFF does not silence the tones your phone sends across the line. See "Transmit Tones" on page 40 for more information.*

MENU

1	**Find Feature**	Press ▲ or ▼ to scroll to Keypad Tones.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Transmit Tones

MENU

Press FCN, ◆ then 3, 3 and continue with step 2.

Your phone transmits tones to communicate with automated calling systems like Voice Mail or bank by phone. These tones are called DTMF tones (Dual Tone Multi-Frequency tones), and this feature allows you to control the length of the tone your phone sends. For most systems, you should use the default setting of short tones, which sends the tones for a preset length of time. If you choose long tones, your phone will transmit the tones for as long as you press and hold the key. To silence the tones during conversations, turn the tones OFF.

1	**Enter Feature**	Press ▲ or ▼ to scroll to DTMF Select and press ◆ to select.
2	**Select Setting**	Press ▲ or ▼ to scroll to Transmit DTMF Long, Transmit DTMF Short, or Transmit DTMF Off and press ◆ to select.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *If you turned the DTMF tones OFF, but you want to access a tone-activated system like Voice Mail, place your call, enter the numbers you need to transmit and:*

Send Tones Press RCL then press SEND to send the tones if DTMF tones are OFF.

Service Tones

When Service Tones are ON, you will be instantly alerted to any change in your wireless service. You will hear two short beeps when your phone (1) starts to roam, (2) returns to a home system after roaming, (3) loses service, or (4) finds service.

1	**Find Feature**	Press ▲ or ▼ to scroll to Service Tones.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *Your phone will always beep if a call is dropped.*

Using Lock/Security Features

While you probably would not want to leave your phone unattended, your phone has a number of built-in security features to prevent unauthorized use.

In this section you will learn how to:

- lock and unlock your phone
- place priority calls
- view and change your lock code
- restrict call placement and memory access
- reset or clear your phone's settings

Start:



Auto Lock

Turn this feature ON and your phone will automatically lock itself each time the phone is turned OFF.

1	**Find Feature**	Press ▲ or ▼ to scroll to Auto Lock.
2	**Toggle Lock**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

MENU

Locking the Phone

You can lock your phone manually at any time to help prevent unwanted use. Once locked, you can leave the phone ON or turn it OFF and the phone will remain locked.

1	**Lock Phone**	Press FCN then press 5. You will see: Lock?
2	**Confirm**	Press ◆ or STO. You will see: Locked.

Unlocking the Phone

Unlocking your phone is quick and easy. Once your phone is ON, just enter your three-digit code. Your factory programmed lock code is 123. If you have changed this code and cannot remember what it is, see Viewing the Lock Code on page 43.

◆ *You can still receive calls when the phone is locked. Follow these steps to answer an incoming call:*

Unlock and Answer	Enter your three-digit code and press ◆ or SEND to answer.

Priority Call

Press FCN, ◆ then 2, 9 and continue with step 2.

Your phone's priority call feature allows you to instantly place a call from location 01 – even when your phone is locked.

1	**Find Feature**	Press ▲ or ▼ to scroll to Priority Call.
2	**Toggle**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *Some wireless systems only allow access to their own emergency numbers. Check with your Service Provider for more information.*

Storing a Priority Call Number

You should reserve memory location 01 for an emergency number or the number of a family member or close friend. To store your priority number, follow these steps:

1	**Enter Number**	Enter your priority number.
2	**Save Number**	Press STO and 0, 1 to choose location 01.
3	**Enter Name**	Select a label, enter a name if you like, and press ◆ when finished. Your phone will confirm the entry by displaying the stored information.

Placing a Priority Call

Place Call	When Priority Call is ON, press and hold 1 at any time.

If call restriction Service Level 1 is enabled, the Turbo Dial® Keys will not be active. To override the restriction and place a priority call, press RCL, 1, SEND. See page 44 for information on your phone's service levels.

Secure Options Submenu

For your protection, you must enter a six-digit secure code in order to access the features in the Secure Options submenu. The factory programmed secure code is 000000.

Viewing the Lock Code

Press FCN, 0, enter six-digit secure code, then RCL.

To view the three-digit lock code:

1	**View Code**	Press to select View Lock Code. You will see: Lock Code XXX.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Changing the Lock Code

Press FCN, 0, enter six-digit secure code, enter a new lock code, then STO.

To change the three-digit lock code:

1	**Begin Change**	Press or to scroll to Change Lock Code and press to select. You will see: Enter New Code__.
2	**Enter New Code**	Enter a new three-digit lock code. You will see: New Lock Code XXX.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Changing the Secure Code

The Secure Code is a six-digit number factory set to 000000. You will probably want to change it to something unique and easy to remember.

1	**Select Feature**	Press or to scroll to Change Secure Code and press to select. You will see: New Code _.
2	**Enter New Code**	Enter a new six-digit Secure Code. Your phone will briefly display the new code.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

MENU

Service Level

When loaning your phone to others, you may want to restrict call placement or protect memory information. Your phone has two service levels that allow you to control the types of outgoing calls that can be made from your phone.

1	**Select Feature**	Press ⊕ or ⊖ to scroll to `Service Level` and press ⊕ to select.
2	**Choose Level**	Press ⊕ or ⊖ to scroll through service level settings and press ⊕ to select the setting. (See the chart below for descriptions.)
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Your phone has two service levels:

Level 1: Calls can be placed from memory locations 1-10 only. • No dialing from keypad. • No memory edit or storage. • No access to name directory.	`1 Memory 1-10 Only`
Level 4: This is the **default setting.** • No restrictions.	`4 Standard Setting`

Master Reset

Use this feature to reset all user-selectable options back to their original factory settings.

⊕ *Once you select this feature, the process cannot be canceled or reversed.*

1	**Reset Features**	Press ⊕ or ⊖ to scroll to `Master Reset` and press ⊕ to select. You will see: `Reset?`
2	**Confirm Reset**	Press ⊕ to confirm. You will see: `Standard Setting`.
or	**Exit**	Press END to exit without resetting.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Master Clear

Use Master Clear to clear all user-selectable options, the resettable timer, the Phone Book, and the Messaging memory.

⊕ *Once you select this feature, the process cannot be canceled or reversed.*

1	**Clear Settings**	Press ⊕ or ⊖ to scroll to `Master Clear` and press ⊕ to select. You will see: `Clear?`
2	**Confirm Clear**	Press ⊕ to confirm. You will see: `Busy`. It will take a few seconds to reset all of your phone's options back to their factory settings.
or	**Exit**	Press END to exit without resetting.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Customizing Phone Options

The Phone Options menu lets you customize the way your phone sends and receives calls.

You can tune your phone for optimal performance, view information about the phone, and choose from a number of convenient features.

In this section you will learn how to:

- switch phone numbers.
- review your phone's settings.
- select a variety of system specific settings.

Start:



MENU

Displaying Phone Information

This feature allows you to view information about your phone. If you require technical assistance, you may be asked to check here.

1	**Find Feature**	Press ▲ or ▼ to scroll to Phone Info then press ◆ to select.
2	**Scroll**	Press ▲ or ▼ to scroll through the the information.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Feature Review

Press FCN, then 0, 9, RCL.

After you have spent some time adjusting your phone's settings, use this feature to review the changes you have made. When you enter Feature Review, your phone will display any features that you have changed from their default factory settings.

◆ *Feature Review is simply an opportunity to review – but not change – your current settings.*

1	**Begin Review**	Press ▲ or ▼ to scroll to Feature Review and press ◆ to enter.
2	**Browse Features**	Press ▲ or ▼ to scroll through any features you have changed from their default settings. If all features are set to their default factory settings, the display will show: Standard Setting.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Call Options Submenu

This submenu gives you control over the way your phone places and receives calls.

Multiple Key Answer

With Multiple Key Answer ON, you can answer calls by pressing ◆ or any key in the center of the keypad, 1 through #▸.

1	**Find Feature**	Press ▲ or ▼ to scroll to Multi Key Answer.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *If there are any digits in your Scratchpad or if your phone is locked, this feature will not work.*

Open to Answer

This feature allows you to set whether or not your phone automatically answers when opened. If you subscribe to Caller ID, you will probably want to set this feature OFF so you can open the phone and check who is calling before you answer.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Open to Answer`.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *To answer calls with Open to Answer OFF, press SEND.*

Automatic Answer

Press FCN, ◆ then 2, 6 and continue with step 2.

Turn Auto Answer ON to have your phone automatically answer incoming calls after two ring cycles.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Auto Answer`.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *We recommend you use this feature only with vehicle accessories and with your phone's ringer active. See page 75. Otherwise, your phone may answer a call in your absence.*

Instant Redial

When placing calls, you may hear a fast busy signal and see `Press SND to Redial`. This probably means the network is temporarily busy. If you turn Instant Redial ON, your phone will redial for the next four minutes or until the call goes through.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Instant Redial`.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

◆ *This feature redials only when the network is busy. If you hear a normal busy signal, this feature will not work. See page 21 for more redialing options.*

Display Options Submenu

This submenu allows you to customize your phone's display.

Activating the Quick Menu

Press the Smart Button once and the Quick Menu appears on the display, offering shortcuts to the most popular features. This feature turns the Quick Menu OFF if you would rather use the Smart Button to go straight into the Phone Book. See page 22 for more information.

MENU

1	**Toggle Feature**	When you enter Display Options, you will see: Quick Menu. Press to toggle the feature On or Off.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Changing the Language

This feature allows you to select the language in the display.

1	**Begin Selection**	Press or to scroll to Change Language and press to select.
2	**Choose Option**	Press or to scroll through the available languages and press to select.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Changing the Banner

You may create your own message banner for the phone to display when it is idle. Your banner can be up to 12 characters long.

1	**Enter Feature**	Press or to scroll to Change Banner and press to select. You will see the current banner or Alpha or Press *.
2	**Enter Message**	Enter your message using the alphanumeric keypad. Press when your message is complete.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Customizing the Backlight

Your phone's backlight illuminates when you open the phone, press a key, or your phone receives an incoming call signal. This feature allows you to choose how long it remains ON.

1	**Find Feature**	Press or to scroll to Backlight Select and press to select.
2	**Toggle Feature**	Press or to scroll to Backlight 15 Seconds, Backlight 30 Seconds, or Backlight Always On and press to select the displayed option.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

The backlight will always be illuminated when your phone is connected to an external power supply, like a charger or vehicle accessory.

Auto Hyphen

Just turn Auto Hyphen ON to have all phone numbers automatically hyphenated on the display. This allows you to easily distinguish between area codes, call prefixes, and other numbers.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Auto Hyphen`.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Displaying the 24-Hour Clock

Your phone can display the current time in 12-hour or 24-hour format. Use this feature to turn the 24-hour clock On or Off.

1	**Find Feature**	Press ▲ or ▼ to scroll to `24 Hour Clock`.
2	**Toggle Feature**	Press ◆ to toggle the feature On or Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

*MiniBrowser Options**

This submenu offers several options for customizing the way your phone accesses information with the MiniBrowser.

Launching the MiniBrowser

Select this feature to launch the MiniBrowser and access sports scores, stock reports, weather reports, and more.

◆ *You can also launch the MiniBrowser with the Quick Menu. See page 22.*

1	**Find Feature**	Press ▲ or ▼ to scroll to `Launch MiniBrowser`.
2	**Select**	Press and hold ◆ to select.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Power Up Mode

When you turn ON your phone, you can begin with the MiniBrowser or the regular phone features.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Power Up Mode`. and press ◆ to select.
2	**Select Option**	Press ▲ or ▼ to scroll to `Power Up Phone` or `Power Up MiniBrowse` and press ◆ to select.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

MENU

* *Contact your Service Provider for availability.*

Confirm at Start-up

Your phone can display reminders when you launch the MiniBrowser to indicate that your time browsing may be charged. This feature toggles the reminder ON or OFF.

1	**Find Feature**	Press ▲ or ▼ to scroll to `Confirm at Start`.
2	**Toggle**	Press ◆ to toggle between On and Off.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

MENU

System Options Submenu

The System Options submenu offers a couple features that will help you use your phone and wireless network.

Displaying the System ID

Use this feature to determine the unique System ID for your wireless phone.

1	**View SID**	Press ◆ to select `Display System ID`. You will see the System ID for your phone.
2	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Selecting a System Mode

Press RCL then ◄✱ and continue with step 2.

Your Service Provider configures Select System Mode when you receive your phone. This feature allows you to select the type of system your phone will attempt to access. See below for a chart of available settings.

1	**Begin Selection**	Press ▲ or ▼ to scroll to Select `SystemMode` and press ◆ to enter. The display will show your phone's current System Mode setting.
2	**Choose Mode**	Press ▲ or ▼ to scroll through the System Mode settings (see chart on next page). Press ◆ to select the displayed setting.
3	**Exit Menu**	Press END to exit the menu, or you may scroll to other features.

Standard Mode: Your phone first seeks a home type system, then a non-home type system.	Standard Scan
Home Only Mode: Phone will not operate outside its home system.	Home Only

Displaying the Roam List Version

This feature displays the Roam List Version used by your phone. If you require technical assistance, you may be asked to check this feature.

1. **View Roam List** — Press ▲ or ▼ to scroll to Roam List Version then press ◆ to select. You will see: Version XXXX.
2. **Exit Menu** — Press END to exit the menu, or you may scroll to other features.

MENU

Using the Messaging Menu*

The dedicated Message Key provides access to your phone's new and easy Messaging Menu. Through this menu, you can check your Voice Mail, read your pager-like alphanumeric Messages, access MiniBrowser alerts, and view the Caller IDs of your most recent callers.

In this section you will learn how to:

- view your Caller IDs.
- check your Voice Mail.
- read your Messages.
- explore your options with the Function Menus.

Receiving Messages

If your phone is ON and you receive a Voice Mail, MiniBrowser alert, or alphanumeric message: an indicator appears on the display:

- ✉ Appears on the lower line of the display when you receive an alphanumeric message. It will stay on the display until you have read the message.
- Urgent ✉ Appears in the main display when you receive an urgent message and your phone is in idle mode. After a few seconds, the screen will change to Press ✉ and begin flashing.
- Msg Mem Low Appears when your phone's message memory is almost full (at approximately 85% capacity). Your Service Provider holds your messages and will forward them after you have made room. See page 60 to learn how to delete messages.
- Msg Mem Full Appears in the main display when the message memory is completely full and your phone is in idle mode.

☞ *Your Service Provider holds your messages and will forward them after you have made room. See page 57 to learn how to delete messages.*

- ✉ Appears on the lowe line of the display when you receive a Voice Mail message. It will stay on the display until you have listened to the message. Your Service Provider will then signal your phone to turn the indicator OFF.

☞ *For information on MiniBrowser alerts, see page106.*

Press ✉ to open the Messaging Menu:

When you open the Messaging Menu, the icon of the message type you received will be flashing.



* *Contact your Service Provider for availability.*

Viewing Your Caller IDs

Contact your Service Provider for availability.

Your phone supports Caller ID service, which lets you see who is calling before you answer. The Caller IDs for the last 16 different callers are stored so they can be viewed at any time.

1 **Enter Messaging** Press (✉) to open the Messaging Menu.

2 **Select Caller ID** Press ⊕ or ⊖ to scroll to Caller ID and press a to select.

You will see a Caller ID icon for each stored Caller ID. Flashing icons represent Caller IDs that have not been viewed. Below the icons you will see information for the latest Caller ID:



3 **Select Caller** Press ⊕ or ⊖ to highlight a Caller ID to view and press ⊕ to view complete information for that call:



Keep in mind: You will see the caller's name only if it is stored in your Phone Book.

✓ A check mark will appear in the corner if you have answered or returned the call. Press (SEND) to return the call of the displayed caller. Press (STO) to store the information.

Caller ID Options

When viewing Caller IDs, press the Message Key to see the options available for the highlighted Caller ID.

1 **Enter Messaging** Press (✉) to open the Messaging Menu.



2 **Choose Function** Press ⊕ or ⊖ to scroll to one of the following:

	Go To Msg Menu	Press ⊕ to return your phone to the Messaging Menu.
	Exit	Press ⊕ to exit Messaging to idle mode.
	Delete Message	Press ⊕ to delete the currently selected Caller ID. Press ⊕ again to confirm.
	Delete AllMsgs	Press ⊕ to delete all your Caller IDs. Press ⊕ again to confirm.
	CallBack	Press ⊕ to return the call.
	Store To Mem	Press ⊕ to begin storing the number. Enter a two-digit location, select a label, enter a name, and press (STO) again.

Checking Your Voice Mail

Contact your Service Provider for availability.

When you receive Voice Mail, your Service Provider sends a notification to your phone and your phone displays an indicator. That way, you will be able to check for new Voice Mail simply by glancing at your phone's display.

1	**Enter Messaging**	Press (✉) to open the Messaging Menu.
2	**Select Voice Mail**	Press ⊕ or ⊕ to scroll to Voice Mail and press ⊕ to select.

If you have one or more Voice Mail messages, you will see:



To listen to your messages, dial your access number. Your phone will do this automatically with one key press.

Dial Number	When viewing notifications, press (SEND) or press and hold ⊕ to call your Voice Mail box.

See the following page for more options.

Some Service Providers send the Voice Mailbox number to your phone automatically. If the number has not been sent, then store it in location 98 of your Phone Book. To learn how, see Pause Dialing on page 26.

Press and hold (✉) to call your Voice Mail number.

If you have no new messages, you will see:



Voice Mail Options

When checking Voice Mail, press the Message Key to see options for the highlighted Voice Mail notification.

3 **Access Options** Press to open the Voice Mail Function Menu.



4 **Choose Function** Press or to scroll to one of the following:

- **Go To Msg Menu** Press to return your phone to the Messaging Menu.
- **Exit** Press to exit Messaging to idle mode.
- **Delete Message** Press to delete the currently selected Voice Mail notification. Press to confirm.
- **CallBack** Press to dial your Voice Mail box number.

Reading Your Messages

Contact your Service Provider for availability.

Your phone can receive alphanumeric messages like a pager. The message memory stores up to 60 messages, depending on the size of each.

1 **Enter Messaging** Press to open the Messaging Menu.

2 **Select Messages** Press or to scroll to Messages and press a to select.



Flashing icons represent messages that have not been viewed.

Select a Message Press or to highlight a message to read and press to select the message.

Once a message is selected, the following keys will help you read through your messages:

Scroll Press or to scroll through the selected message.

Previous Message Press ⓐ or ⓔ to go to the previous message.

Next Message Press #▶ to go to the next message.

If the message includes a number in parentheses (a Call Back number) you can use the following shortcuts:

Call Back Press SEND to dial the Call Back number (in parentheses if included).

If the Call Back number matches one in your Phone book, you will see the name of the caller when you view the message.

Store Press STO to store the Call Back number (in parentheses if included) in your Phone Book.

Message Options

When reading your messages, press the Message Key to see the options available for the highlighted message.

3 **Access Options** Press ✉ to open the Message Function Menu.

4 **Choose Function** Press ⓐ or ⓥ to scroll to one of the following:

Go To Msg Menu Press ⊙ to return your phone to the Messaging Menu.

Exit Press ⊙ to exit Messaging to idle mode.

Delete Message Press ⊙ to delete the currently selected message. Press ⊙ again to confirm.

Delete AllMsgs Press ⊙ to delete all messages. Press ⊙ again to confirm.

Lock Message Press ⊙ to lock or unlock the message. Lock important messages to protect them from accidental deletion.

Unlock Message Messages must be unlocked before they can be deleted.

If the message contains a Call Back number (in parentheses), you will also see these options:

CallBack Press ⊙ to dial the sender's number.

Store To Mem Press ⊙ to begin storing the number. Enter a two-digit location, select a label, enter a name, and press STO again.

Using the MiniBrowser*

Your phone can give you instant access to valuable resources. With a subscription and wireless service, you can retrieve sports scores, weather and traffic reports, stock prices, and more.

In this section you will learn how to:

- launch the MiniBrowser.
- navigate using your phone.
- bookmark your favorite sites

Follow these symbols as a guide for using the MiniBrowser.

Press ⊕ to scroll up.

Press ⊖ to scroll down.

Press RCL for Soft Key

Press STO for Soft Key

Press CLR to go back or stop, hold to return to home page

Press END to exit

Getting Started Browsing

To get started with you MiniBrowser, you will need an IP address for your phone. The IP address is the location of a server provided by your Service Provider, and it will be loaded into your phone by your Service Provider when you subscribe to this service. Contact your Service Provider for more information.

Launching the MiniBrowser

If your IP address is already set, then you are ready to go. Just follow these simple steps:

1. **Open Quick Menu** — Press ⊕ to open the Quick Menu.



2. **Select Browser** — Press ⊕ or ⊖ to scroll to Launch Browser and press ⊕ to select.

   When you launch the MiniBrowser, you will see the last page you accessed with the MiniBrowser. If this is your first time, you will see your home page.

For more setup options and another way to launch the browser, turn to page 49.

* *Contact your Service Provider for availability.*

MiniBrowser Navigation

If you know the keys to navigate your phone's other features, then you already have a head start at navigating with the MiniBrowser.

Scrolling and Selecting

When browsing, you will see a list of options on the phone's display. Each of the items on the list is assigned a number. Just press the matching numeric key to select that item. Or you can scroll to the item with the volume keys and use the Smart Button to select.



Select Item Press the key matching the number of the list item. In the above example, press 7 for Email.

Scroll Press ⊕ or ⊖ to scroll up and down the page. You can also use ◄✱ or #►. Above, press ⊖ once to scroll to Email, twice to scroll to To-Do List.

Select Press ⊕ or the left soft key (see the next page) to select the highlighted item. Above, press ⊕ to select Web Sites.

Go Back One Page While navigating, press CLR to return to the previous page.

Stop When sending and receiving data, press CLR to interrupt transmission.

Return to Home Press and hold CLR to return to your home page.

MiniBrowser Navigation

Soft Keys

In addition to the familiar keys for scrolling and selecting, the MiniBrowser makes uses of "soft keys." Soft keys are keys that change their function according to the screen. Read the lower line of the display (above the indicators) to find out what the soft keys can do on that screen.

You will see two functions, one on the left and one on the right, each with an icon:



Left Soft Key Press RCL to choose the option on the left. In the above example, press RCL to select OK and accept the highlighted option: Web Sites

You can also press ⊕ to select the left option.

Right Soft Key Press STO to choose the option on the right. In the above example, press STO to select Inbox.

Display Messages

While you navigate, the lower line of the display will show you messages to let you know what your phone is doing. You will see: Sending))))), Receiving(((((, or Waiting.....

Bookmarks

Bookmarks make it easy to quickly jump to the sites you use most often. You can assign up to nine bookmarks, one for each of the numeric keys on the keypad. See page 62 to learn how to make a bookmark. Once you bookmark the site, press and hold the key and you will automatically jump to the page.

Bookmarks are only available while browsing.

MiniBrowser Alerts

To stay current with changing information, like stock prices or sports scores, you can subscribe to MiniBrowser alerts through your Service Provider.

If your phone is ON and you receive a MiniBrowser alert:

- **An alert sounds**: Your phone will beep three times.

  See Setup Message Tones on page 39 to set your phone's alert. See page 39 to learn about Reminder Tones.
- **An indicator appears:** ✉ Appears on the lower line of the display. It will stay on the display until you have checked the alert.

1	**Check Message**	Press ✉ to open the messaging menu. The icon of the message type received will be flashing.
2	**Select Alert**	Press ▲ or ▼ to scroll to MiniBrowse Alrt and press ◆ to select.

Receiving Calls

Most of the time, while browsing you will not be able to receive calls (depending on your service, callers will probably get your Voice Mail).

Look for the IU indicator on the lower line of the display. If you see it, your phone is online and you will not be able to receive calls.

Occasionally, when you access a page that you have recently visited and the information on the page has not changed, your phone may use a version of the page stored in its memory. When this is the case and you receive a call, your phone's alerts will sound and the display will show the Caller ID (if available).

Answer Call	Press SEND to answer the call. Your browsing session will be put on hold while the call lasts. Once the call is complete, your phone will return to the same site.

Entering Words

At times you may need to enter information while browsing, like a keyword for searching or a message. If you see a flashing cursor, you can use the keypad to enter letters and punctuation in the same way you do for the internal Phone Book. See page 24 for more information.

Security

To find out if the information you are sending is secure, just look at the lower line of the display. A key icon denotes a secure transmission. If the key has a slash through it, then the transmission is not secure.

Secure

Non-Secure

The MiniBrowser Menu

Through this menu, you can set Bookmarks, read MiniBrowser alerts, refresh the display, and other advanced features.

This menu is only available while browsing.

Help

If you need assistance while browsing, select this option.

Select	Press ⊕ to select Help. You will see a help screen specific to the site.

Some sites do not have help available.

Home

Select this option to return to the home page set up by your Service Provider.

Select	Press ⊕ to select Home. You will see the home screen of your Service Provider.

Mark Site

To add a page to your bookmark list, choose this feature. Once bookmarked, press and hold the corresponding key to jump to the bookmarked page. There are nine bookmarks available so your favorites are never more than a keypress away.

1	**Select**	Press ⊕ to select Mark Site. You will see: Select Number.
2	**Select Number**	Press a key, (1) through (9), to choose the bookmark number.

Show URL

To see the address of the current page, choose this feature.

Select	Press ⊕ to select Show URL. You will see the address of the current page.

Reset UP

This features relaunches the MiniBrowser.

Refresh Display	Press ⊕ to select Reset UP. You will see the start-up screen and then the first menu.

About UP

This feature offers information on the company that helps to provide the web browsing service.

View Page	Press ⊕ to select About UP. You will see a page with information.

Advanced Settings

This submenu contains a couple features for advanced users, like security and technical settings.

1	**Select**	Press ⊕ to select Advanced.
2	**Scroll**	Press ⊖ or ⊖ to scroll to `Set.UP Link` or `Security` and press ⊕ to select.

Accessories

The following accessories have been designed to work with your phone. Additional accessories may be available and are packaged separately. Please refer to your local service provider or retail outlet for more information.

Vehicular Power Adapter

The Vehicular Power Adapter connects to your phone and allows you to charge your phone's battery while driving. When the phone is in use, the adapter overrides the battery therefore preserving battery life. The adapter also provides dead battery operation.

In some cars, the engine must be running in order for the Vehicular Power Adapter to operate.

Personal Handsfree System

The convenient headset provides both an earphone and microphone for simple handsfree and private telephone conversations. The headset plugs directly into the jack on the top of your phone, so that you can wear your phone and move freely. Place the foam cover on the earpiece for a more comfortable fit..

Zero Install Car Kit

For the quickest and easiest mobile solution, use the Zero Install Car Kit. Just plug it in, attach the microphone, and you are ready to go.

Accessory Limited Warranty Information

We recommend that you use Motorola original batteries and accessories. Under its limited cellular telephone warranty, Motorola specifically disclaims any responsibility for damage caused by the use of portable cellular telephone accessories not manufactured by Motorola.

For details on the complete line of Motorola cellular accessories, see your dealer or visit our Web site at

`http://www.mot.com/`

What to do if...

I pressed the power button, but nothing happened. What's wrong with my phone?	Make sure that you press and hold the power button until the display appears and you hear an audible alert. If nothing still happens, then check that you have installed a battery and that the battery is charged. For more information about batteries and charging see "Your Battery" on page 15.
My battery didn't last as long as I expected. What can I do to extend battery life?	Your battery's "talk-time" and "standby-time" are relative measurements of the battery's capacity. The more you talk on the phone, the less standby-time you have, and vice versa. You can also turn on the Power Save Mode feature to extend battery life. However, the LED Power/Status Indicator does not light when this feature is activated. Certain features demand power from your battery and reduce battery life. If you have selected the Automatic Display of Individual Call Timer feature, the display uses battery power to remain active during each call. Turn this feature off to conserve battery energy. (See "Auto Display Individual Timer" on page 36 for more information on this feature.) Make sure that you are using batteries that are compatible with your phone. Exposing your battery to extreme temperatures—below -10°C (14°F) or above 45°C (113°F)—can shorten battery life. Batteries are especially sensitive to high temperature extremes. As a good rule, always take your phone with you when you leave your car.
The display says, "Locked." How do I unlock my phone?	Enter the last three digits of your cellular number. If that doesn't work, use the factory preset lock code: 123. If all else fails, call your service provider (the company that sends you your monthly cellular bill) for assistance. (See "Using Lock/Security Features" on page 41 for more information on Security Features.)
I tried to place a call and received a fast busy signal.	This sound means that the cellular system did not process your call. For example, the cellular system may be overloaded with call attempts. To redial the number, press SEND before ending your call attempt, or press END and try the call again later. (See "Redialing a Number" on page 21 for more information on redialing.)
I tried to place a call and received an alternating high/ low tone.	This sound means your call did not reach the cellular system. You may have dialed the number too soon after turning the phone on. Wait until the "NS" light stops blinking before placing a call. An alternating tone may also indicate that your phone's signal is blocked. Make sure the antenna is fully extended and you're clear of any obstructions such as bridges, parking garages, or tall buildings.
My phone was stolen. What should I report and to whom?	Report a stolen phone to the police and to your service provider (the company that sends you your monthly cellular service bills).

I tried to listen to my Voice Mail (or use a paging service, a calling card, etc.) but nothing happened.	You have probably turned off the transmit tones. Place your call, enter the access numbers when prompted by the recording, then press RCL SEND. To avoid this problem in the future, follow the directions in "Transmit Tones" on page 40 to turn the transmit tones on.
I tried to place a calling card call using the internal Phone Book, but it didn't work.	You may have turned off your transmit tones. Follow the directions in "Transmit Tones" on page 40 to turn the transmit tones on. Check that you stored your calling card information in the correct order, and make sure the groups of numbers are separated by pauses. The easiest way to correct the sequence may be to start from scratch. Follow the instructions on "Storing Calling Card Numbers" on page 27, enter your calling card information again, and store it in the same memory location as your previous attempt. Also keep in mind that when using your calling card, you must enter the number you are calling with the area code, but without the initial "1." Check with your long distance carrier for details on using your calling card.
My phone started beeping, and the display says: 1 Call Unanswered. What happened?	Someone tried to call you while you were in an area where the signal was weak. Press CLR to clear your display, extend your phone's antenna, and avoid obstructions like tunnels, parking garages and tall buildings whenever possible.
I launched the MiniBrowser but the display says: Service Not Available. What is wrong?	You are in an area without service. If you have wireless service, look in the display for the Digital indicator. If you don't see it you may have only Analog service or no service at all. If you do see the Digital indicator, you may be connected to digital network that does not support Internet access.
I launched the MiniBrowser but the display says: Data Server Unavailable. What is wrong?	Try again in a few minutes. The servers may be temporarily busy.

Patent Information

Manufactured under one or more of the following patents:

4121218	4127824	4128740	4138681	4193036	4254382
4302845	4312074	4327319	4329666	4369516	4369522
4378603	4390963	4398265	4400584	Re.31470	4431977
4434461	4455534	4462098	4484153	4485486	4486624
4491972	4504834	D278708	4523155	4546329	4549311
4550426	4551696	4564821	D282169	4571595	4573017
4574243	4585957	4602218	D284759	4616314	4617520
4626309	4628529	4629829	4630304	4630305	4633141
4636593	4636741	4644351	D288432	4648125	4649543
D288683	4654655	4654867	4662691	4667333	4668917
4670747	4672502	4692726	4704588	D292578	4706036
D292920	4710724	4711361	4715063	4716319	4716391
4723305	D294257	4727306	4727583	4730195	4734635
4737976	4740794	4741018	4741034	4742562	D295627
D295975	4751737	4761621	4764737	D297734	D297735
D297736	4777564	Re.32768	4783697	D299232	4797929
4798975	4800348	4802236	4803726	4809356	4811377
4811404	4816774	4817157	4823098	D300742	D300827
4827226	4827507	4829274	4829543	4837534	4843621
4845772	4851966	4868576	4872196	4873683	4876552
4876740	D304189	4879533	4885553	4887050	4890199
D305427	4896124	4896361	4897873	D305717	4903327
D306163	4904549	4905288	4905301	D306299	4910470
4912602	4916262	4918403	4918732	4922209	4924194
4930126	D309301	D309451	4945570	4954796	4956854
4963812	4963843	4965537	4970475	4972355	4972432
4972455	4975808	4982108	4984219	4989230	D314173
4992753	4998289	D315330	D315543	5004992	5008925
5010309	5010570	5014294	5014346	D316859	5017856
5018188	5020076	5020091	5020092	5020093	5023580
5023866	5023911	5025387	5028859	5029233	5036532
5040127	5042071	5045824	5053924	5055800	5055802
5055803	5057762	5058136	5059885	5060264	5060294
5063340	5065408	5067139	5068625	5070310	5077757
5081674	5083304	5093632	D325028	5107487	5109536
5111162	5113400	5113436	5117441	5117449	5121047
5121288	5121412	5122722	D327062	5124889	5127040
5127042	5128834	5130682	5130683	5133010	5136135
5140286	5142551	5142696	5148471	5150075	5150359
5150384	5152006	5152007	5153590	5157693	5159283
5160898	5163159	5164652	5166596	5166642	5170173
5170492	5173672	5175759	5175874	5177458	5182749
5185566	5187640	5187809	5192924	5193223	5195106
5195108	5198887	5200655	5201069	5202654	5203009
D334746	5204977	5205751	5208566	5210793	5211581
5212815	5212826	5214675	5214774	5220290	5222078
5222104	5222251	5224122	5230007	5230093	5233506
5233633	5235492	5237257	5237570	5239127	5239294
5241545	5241548	5241592	5241650	5241688	5241693
D338887	5242767	D339127	D339335	D339336	D339337
5247544	D339578	5249302	5250916	5251331	5253292

5255292	5257414	5259005	5260170	5260988	5261119
5262710	5263052	5263055	5265219	D341589	5271042
D342248	5276685	5276707	5276913	5278527	5278832
5278994	5280637	5280644	D343615	D343616	D343834
D343835	5287553	5287555	5287556	5289505	D344512
5297142	5299232	5301364	5301365	5308716	5312705
5321847	5323421	5325429	D348250	D348427	5327642
D348665	D348666	D348668	5331123	D349273	5336984
5338909	D350113	D350348	D350349	D350350	5349588
5351245	D351375	5359696	5361400	5363071	5365549
D352503	5366826	5367538	5367558	5371791	D353131
5373101	D353361	5375143	5375258	D353587	D353588
5379324	5384825	5392000	5392023	5396654	D356309
5402447	5404120	5404582	5406146	5406562	D357224
D357457	5410275	5414711	D358148	5420759	5424689
5428820	5428836	5430416	5432017	5434947	5436589
5436802	5438684	D361070	5444764	5446763	5448763
5448770	5448771	5453997	D362840	D362852	5461643
5463628	5465412	5469177	5475752	D365094	5477192
D365817	5486843	5487184	5488335	5490177	5493198
5493700	5493714	5495206	5497126	5497383	D367640
5499273	5504812	5506490	D368696	5508709	5510693
5511235	5513078	5513382	D369359	5513996	D369598
D369797	5519303	5519346	5519506	5519777	D370016
D370463	5526398	D370672	5530922	5539360	5542103
5542106	5544250	D372481	5546380	D372896	5551078
5555550	5559471	D374013	5561436	D374227	D374424

5565881 5570453 5572223 5572224 5577267 5577268
D375932 D375952
Other patents pending

Motorola Limited Warranty

I. What This Warranty Covers And For How Long:

Motorola Inc. (Motorola) warrants the Motorola PCS Subscriber Radiotelephone products and accessories against defects in material and workmanship under normal use and service for a period of time specified by the product's serial number from the date of installation.

A Installation, in the case of radiotelephones, accessories or batteries that are not installed in a vehicle, means the date that the product is placed into subscriber service. Installation will be deemed to be no later than thirty (30) days from date of delivery of the Product to you the owner.

The warranty time period is specified by the last digit of the mechanical serial number found on each PCS product. Products sold under this warranty may have either a "P", "Y", "A", "B", "C", or "D" or nothing in the eleventh position of the serial number. If there is no letter or an "A", the product comes with a (1) one year warranty. Products that have a "D" have a (2) two year warranty. Products that have a "Y" or a "B" have a (3) three year warranty, and products that have a "P" or a "C" have a (5) five year warranty commencing from the date of installation. The warranty time period for radiotelephone accessories and batteries is as follows:

PCS portable telephone batteries 1 year

Carrying cases Defect free at time of shipment

Other radiotelephone accessories 1 year

Motorola, at its option, will, at no charge, either repair, replace, or refund the purchase price of the PCS Subscriber Radiotelephone Product during the warranty period, provided it is returned in accordance with the terms of this warranty to the Motorola National Service Center or Service Providers service shop qualified by Motorola. Repair, at Motorola's option, may include the replacement of parts or boards with functionally equivalent reconditioned or new parts or boards. Replaced parts or accessories, batteries or boards are warranted for the balance of the original time period. All returned accessories, batteries, parts and PCS telephone equipment shall become the property of Motorola.

II. Warranty Conditions:

This express limited warranty is extended by Motorola to the original subscriber buyer or lessee only and is not assignable or transferrable to subsequent subscriber buyers or lessees. This is the complete warranty for PCS Subscriber Radiotelephone Products by Motorola. Motorola assumes no obligation or liability for additions or modifications to this warranty unless made in writing and signed by an officer of Motorola. Unless made in separate written agreement between Motorola and you, Motorola does not warrant the installation, maintenance or service of the equipment, accessories, batteries or parts. Rechargeable batteries are warranted only if battery capacity falls below 80% of rated capacity, or the battery develops leakage. This warranty becomes void for all types of batteries if:

a. the batteries are charged by other than Motorola approved battery chargers specified for the charging of the battery.

b. any of the seals on the battery are broken or show evidence of tampering.

c. the battery is used in equipment or service other than the PCS radiotelephone equipment for which it is specified.

Motorola cannot be responsible in any way for any ancillary equipment not furnished by Motorola which is attached to or used in connection with Motorola's PCS Subscriber Radiotelephone Products, or for operation of our equipment with any ancillary equipment and all such equipment is expressly excluded from this warranty. Furthermore, Motorola cannot be responsible for any damage to Motorola equipment resulting from the use of ancillary equipment not furnished by Motorola for use with PCS subscriber equipment.

When the product is used in conjunction with ancillary or peripheral equipment not manufactured by Motorola, Motorola does not warrant the operation of the product/ peripheral combination, and Motorola will honor no warranty claim where the product is used in such a combination and it is determined by Motorola that there is no fault with the Motorola product. Motorola specifically disclaims any responsibility for any damage caused in any way by the use of portable radiotelephone accessories and peripherals (specific examples include, but are not limited to: batteries, chargers, adapters, and power supplies) when such accessories and peripherals are not manufactured or supplied by Motorola. Motorola disclaims liability for range, coverage, availability, or operation of the PCS System which is provided by the Service Provider.

III. What This Warranty Does Not Cover:

(a) Defects or damage resulting from use of the product in other than its normal and customary manner.

(b) Defects or damage from misuse, accident or neglect.

(c) Defects or damage from improper testing, operation, maintenance, installation, adjustment, or any alteration or modification of any kind.

(d) Breakage or damage to antennas unless caused directly by defects in material or workmanship.

(e) Products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.

(f) Products which have had the serial number removed or made illegible.

(g) Defects or damage due to spills of food or liquid.

(h) All plastic surfaces and all other externally exposed parts that are scratched or damaged due to customer normal use.

(i) Products rented on a month- to- month basis.

(j) The portable phone keypad assembly and displays are not covered after the first year.

IV. How To Get Warranty Service:

To receive warranty service, present your equipment to the facility described below, along with your bill of sale or comparable substitute proof of sale or lease bearing the date of purchase, transceiver serial number and place of purchase or installation if applicable.

Warranty service is available by returning Motorola branded Radiotelephone Products to a Motorola Service Center, authorized in writing by a Motorola Area Service Manager to perform warranty work on Motorola PCS Subscriber Radiotelephone products. A Carrier or Distributor branded Radiotelephone Product may be returned to either (a) the specific service shop qualified by Motorola's National Service Center in writing and operated by or affiliated with the PCS Service Provider, or (b) a Motorola Authorized PCS Service Center.

In most cases the service shop which sold your PCS Radiotelephone and accessories will provide warranty service. If you need additional information, contact that shop, the customer service department of your Service Provider, or Motorola at the address at the end of this document. The unit or accessories, together with any detachable parts such as antennas, battery packs, and chargers, must be delivered to a qualified Motorola Service Center, or a Motorola- qualified service shop, transportation and insurance prepaid. When sent or brought to the servicer, the Radiotelephone Product must be accompanied by your name, address, and telephone number, name of Service Provider, and a description of the problem.

V. General Provisions:

This warranty sets forth our responsibilities regarding this product. Repair, replacement or refund of the purchase price at Motorola's option, is your exclusive remedy. This warranty is given in lieu of all other express warranties, implied warranties, including without limitation implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of this limited warranty. Further, as the Service Provider is not controlled by Motorola, no warranty is made as to coverage, availability or grade of service provided by the Service Provider. In no event shall Motorola be liable for damages in excess of the purchase price of the PCS radiotelephone product, for any loss of use, loss of time, inconvenience, commercial damages arising out of the use or inability to use such product, to the full extent such may be disclaimed by law.

VI. Patent And Software Provisions:

Motorola will defend at its own expense, any suit brought against you to the extent that it is based on a claim that the PCS Subscriber Radiotelephone Product parts infringes a United States patent, and Motorola will pay those costs and damages finally awarded against you in any such suit which are attributable to any such claim, but such defense and payments are conditioned on the following:

(i) that Motorola will be notified promptly in writing by you of any notice of such claim; and

(ii) that Motorola will have sole control of the defense of such suit and all negotiations for its settlement or compromise; and

(iii) should the PCS Radiotelephone, accessory, battery or parts become, or in Motorola's opinion be likely to become the subject of a claim of infringement of a United States patent that you will permit Motorola, at its option and expense, either to procure for you the right to continue using the PCS Radiotelephone or parts or to replace or modify the same so that it becomes non- infringing or to grant you a credit for such PCS Radiotelephone or parts as depreciated and accept its return. The depreciation will be an equal amount per year over the lifetime of the PCS Subscriber Radiotelephone, accessories, battery or parts as established by Motorola.

Motorola will have no liability to you with respect to any claim of patent infringement which is based upon the combination of the PCS Radiotelephone or parts furnished hereunder with software, apparatus or devices not furnished by Motorola, nor will Motorola have any liability for the use of ancillary equipment or software not furnished by Motorola which is attached to or used in connection with the PCS Radiotelephone. The foregoing states the entire liability of Motorola with respect to infringement of patents by the PCS Radiotelephone, accessories, batteries or any parts thereof.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce in copies and distribute copies of such Motorola software. Motorola software may be copied into, used in and redistributed with only the PCS Subscriber Radiotelephone Product associated with such Motorola software. No other use, including without limitation disassembly, of such Motorola software or exercise of exclusive rights in such Motorola software is permitted.

VII. State Law Rights:

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Index

A

Accessories 65
accessory connector port 13
adjusting volume 14
answering calls
  automatic answer 47
  multiple key answer 46
antenna 13
audible timers
  one minute 36
  repeating 36
  single 37
Authentication Entry 44
auto display timer 36
auto lock 42
automated systems
  calling 26–27
  storing number 26–27
automatic answer 47
automatic redial 21

B

banner 48
Batteries
  Charging 16
  Installing the Batteries 15
  Low battery warning 18
  Maintaining 16
  Removing 17
battery
  life 67
Battery charge indicator 15
Bookmark 62
Bookmarks 61
browsing the web 59–63
busy signal 67
button
  Message 13
  Smart 13

C

call
  ending 20
  placing 14, 19
  receiving 20
Call Back messages 57
Call Options 46–47
Call Timers 34–37
  road map 34
Caller ID 20
  deleting 54
  number preference 32
  options 54
  viewing 54
calling card
  storing information 68
calling cards
  storing numbers 27
  using 28
changing lock code 43
changing secure code 43
changing the banner 48
checking your voice mail 55
Clear, Master 44
clearing
  Caller ID 54
  Messages 57
  settings 43
  Voice Mail notification 56
clearing a memory entry 25
clock
  display format 49
Confirm at Start-up 50
connector port 13
cumulative call timer 35

D

deleting
- Caller ID 54
- Messages 57
- Voice Mail notification 56

dialing
- priority call 42
- restricting 44

digital
- indicator 14

Display 14

display
- individual call timer 35, 36
- last ten numbers dialed 21
- lock code 43
- system ID 50
- your number 32

Display Options 48–49

displaying
- caller's numbers 32

displaying phone information 46

displaying the 24-Hour Clock 49

DTMF tones 40
- storing 26–28

E

earpiece 13

editing memory 33

ending a call 20

F

Fault finding 67, 69

function keys 13

H

headset jack 13

Home Only Mode 51

I

In Use Indicator 14

indicator
- Digital 14
- In Use 14
- No Service 15

indicators
- Roam 14

individual call timer 35
- auto display 36

Installing the Batteries 15

Instant Redial 47

Internet 59–63

J

jack, headset 13

K

Keypad Tones 39

L

last ten numbers dialed 21

lock
- automatically 42
- manually 42
- messages 57

lock code
- changing 43
- viewing 43

Lock/Security 41–44
- road map 41

Low battery warning 18

M

Master Clear 44
Master Reset 43
memory
  editing 33
  Phone Book 30–32
  recalling 31
  storing 32
memory location
  using phone book 23
menu features 29
menus
  entering 13
  navigating 3, 29
Messages
  Call Back 57
  lock/unlock 57
  options 57
  reading 56
Messaging Menu button 13
microphone 13
MiniBrowser
  In-Box 62
  launching 49, 59
  Menu 62–63
  using 59–63
MiniBrowser Alerts 61
MiniBrowser Navigation 60
MiniBrowser Options 49–50
multiple key answer 46

N

names
  recalling 31
  viewing 32
navigating the web 59–63
No Service Indicator 15
number
  viewing others 32
  viewing yours 32
number character 27–28
Number Preference 32

O

one minute timer 36
outgoing calls
  controlling 44

P

Pause Dialing 26–27
personalizable banner 48
Phone Book 30–32
  editing 33
  recalling 31
  road map 30
  status 31
  storing 32
phone book
  clearing entry 25
  entering a name 24
  entering letters 24
  entry
    recalling by location 31
    recalling with short cuts 25
  recalling entry
    by location 25
    by name 24
  storing names and numbers 23
  using 23
phone information 46
phone lock
  automatically 42
  manually 42
phone number
  viewing others 32
  viewing yours 32
Phone Options 45–51
  road map 45
phone overview 13
placing a call 14, 19
placing calls
  priority call 42
  redial 21
power button 13, 67
Power Up Mode 49
Priority Call 25
priority call 42

R

reading your messages 56
recalling
  by name 31
recalling entry by location 25
recalling entry by name 24
receiving call
  procedure 20
receiving calls
  automatic answer 47
  multiple key answer 46
receiving messages 53
redial 21
  automatic 21
  Instant 47
  last ten numbers dialed 21
redialing a number 21
Removing your battery 17
repeating timer 36
Reset URL 62
Reset, Master 43
resettable call timer
  resetting 35
  viewing 35
retractable antenna 13
ringer
  style 39
  volume 14
road map 29
road maps
  Call Timers 34
  Lock/Security 41
  Phone Book 30
  Phone Options 45
  Tone Control 38
Roam Indicator 14
roam list version 51

S

scratchpad notes 26
Scratchpad Tones 40
secure code, changing 43
Secure Options 43–44
security 41–44
selecting ringer style 39
service level 44
Service Tones 40
Short message service symbol 15
Show URL 62
Signal strength symbol 14
single timer 37
Smart Button 13
Soft Keys 60
Speed Dial 25
Standard Mode 51
storing 32
  Call Back number 57
  names and numbers 23
Symbols 14
system ID, viewing 50
system mode 50
System Options 50–51

T

timers
  audible 36–37
  cumulative 35
  individual 35, 36
  one minute 36
  repeating 36
  resettable 35
  single 37
Tone Controls 38–40
  road map 38
  volume 14
tones
  alternating high/low 67
  keypad 39
  service 40
  storing 26–28
Transmit Tones 40
  storing 26–28
transmit tones 68
Troubleshooting 67, 69
Turbo Dial® keys
  priority call 42
Turbo Dial™ 23, 25
turning the phone off 19
turning the phone ON
  mode 49
turning the phone on 19

U

unanswered call indicator 20
unlock phone 67
unlock/lock 42
Using Messaging 53–57
Using the MiniBrowser 59–63

V

viewing
- Caller IDs 54
- cumulative call timer 35
- individual call timer 35, 36
- lock code 43
- resettable call timer 35
- your number 32

Voice Mail
- calling 26–27
- checking 55
- deleting notification 56
- options 56
- storing number 26–27

voice mail 68
volume
- adjusting 14
- muting 21

volume keys 13

W

What to do if... ..... 67, 69

Z

Zero Install Car Kit 65