Mail

Mail Functions of FOMA Handset 168
What is i-mode Mail? 168
Displaying Mail Menu<Mail Menu> 172

Creating i-mode Mail/Deco-Mail

Creating and Sending i-mode Mail<Creating/sending i-mode mail> 172
Creating and Sending Deco-mail<Deco-mail> 174
Creating Deco-mail Using Template<Template> 175
Attaching a File<File attachment> 175

Receiving/Operating i-mode Mail

When i-mode Mail is Received<Automatic reception of mail> 176
Selecting and Receiving i-mode Mail<Receive option> 176
Checking for i-mode Mails<Check new message> 177
Replying to i-mode Mail<Replying i-mode Mail> 177
Forwarding i-mode Mail to Another Destination
<Forwarding i-mode Mail> 177
Registering Mail Address to Phonebook 178
Replaying/Saving Melody from i-mode Mail<Save Melody> 178
Displaying/Saving Image of Image Mail<Receiving Image Mail> 178
Replaying/Saving i-motion from i-motion Mail 178

Operating Mail Box

Displaying Mails in Outbox/Inbox/Unsentbox
<Outbox/Inbox/Unsentbox> 178

Configuring Mail Settings

Setting FOMA Handset Mail Functions<Mail setting> 184

Using Chat Mail

Chat Mail.....186
Creating and Sending Chat Mail<Creating/sending chatmail>.....186

Using SMS (Short Message)

Creating and Sending SMS (Short Message) <Creating/Sending SMS> 187
Automatically Receiving SMS (Short Message)<Receiving SMS>.....188
Checking for SMS (Short Message)<Check New SMS> 189
Configuring SMS (Short Message) Settings<SMS Settings> 189

Mail Functions of FOMA Handset

FOMA handset provides 2 mail functions: i-mode mail and SMS.

- Using i-mode mail requires i-mode subscription.
- Using SMS requires no i-mode subscription.

Sending and Receiving Mail

FOMA handset → FOMA handset



FOMA Handset → i-mode Service

SMS sent from FOMA handset is received by mova service i-mode handset as i-mode mail.



*: If "Report request" is set to "ON", SMS cannot be sent to mova.

mova service i-mode handset → FOMA handset

Short mail* sent from mova service i-mode handset can be received by FOMA handset as SMS.



*: Short mail is a service that allows to send and receive text messages between DoCoMo mobile phones.

What is i-mode Mail?

Upon subscription to i-mode, you can send and receive messages via internet as well as between i-mode handsets (including mova handsets). The default mail address specified at i-mode subscription is as given below.

■ **When you have newly subscribed to i-mode**

A combination of random alphanumeric characters is succeeded by @. After subscription to i-mode, check your mail address.

Example: abc1234 ... 789xyz@docomo.ne.jp

Checking your mail address

iMenu" → "ENGLISH" → "Function" → "Mail Settings" → "Confirm Mail Address"

- Between i-mode handsets (including mova handsets), mails can be sent and received using only the address preceding @.
- When sending mails from PC, etc. to FOMA handset, use the whole address containing @docomo.ne.jp.



■ **Receive option**

You can check subjects of i-mode mails stored in i-mode Center and select ones to be received or deleted without reception from the i-mode Center. →P176

Mail Setting

You can make various settings as described below.

■ **Setting procedure**

→ "iMenu" → "Function" → "Mail Settings" → 【Each Setting】

- For details, refer to "i-mode User's Manual".

■ **Changing your mail address 【Mail Address (Change Mail Address)】**

You can change characters preceding mark @ in a mail address, e.g., "docomo.△△_ab1234yz@docomo.ne.jp".

■ **Confirm Mail Address 【Mail Address (Confirm Mail Address)】**

You can confirm the current mail address.

■ **Registering secret code 【Mail Address (Other Settings) → Register a Secret Code】**

When using a mail address of format "mobile phone number@docomo.ne.jp", you can register 4-digit secret code in addition to the mail address. Because mails with no secret code attached are not received, you can avoid receiving unnecessary i-mode messages.

■ **Resetting mail address 【Mail Address (Other Settings) → Reset Mail Address】**

You can set your mail address to "mobile phone number@docomo.ne.jp".

■ **Spam Mail Prevention**

You can restrict reception of messages by setting mail reception/rejection in one of the procedures given below.

① Reject/Receive Mail Settings 【Receiving Mail (Spam Mail Prevention) → Reject/Receive Mail Settings】

- You can receive mails from one of carriers selected from au, Vodafone, DoCoMo, TU-KA and WILLCOM.
- You can receive mails from the specified domain address of those sent from the carriers other than the above.
  (You can reject mail pretending to use a mobile phone or PHS domain from the Internet.)

② SMS Rejection Settings 【Receiving Mail (Spam Mail Prevention) → SMS Rejection Settings】

- You can restrict incoming SMS by selecting one from "Reject All SMS", "Reject Anonymous SMS", "Reject International SMS", and "Reject Anonymous and International SMS". You can also view the current settings.

③ Restricting reception of mails from mass i-mode mail senders 【Receiving Mail (Other Settings)→ Reject Mass i-mode Mail Senders】

- You reject 201st and subsequent i-mode mails sent from one i-mode handset (including mova handset) a day. "Reject" is set by default, so you do not have to change the settings to reject messages sent from mass mail senders.

④ Reject Unsolicited Ad Mail 【Receiving Mail (Other Settings)→ Reject Unsolicited Ad Mail】

- You reject reception of mails with "Reject Unsolicited Ad Mail" description added to a mail subject which are sent unilaterally for advertisement and/or promotion without agreement of the receiver. "Reject" is set by default, so you do not have to change the settings to reject such messages. (Senders are obligated by law to give description Unsolicited Ad Mail (6 full-pitch characters) to the beginning of the mail subject field.

■ **Limiting mail size [Receiving Mail (Limit Mail Size)]**

You can limit i-mode mails to be received with the predetermined size.

■ **Confirm Settings [Receiving Mail (Confirm Settings)]**

You can check the current settings of mail reception/rejection and others.

■ **Suspending mail function 【Suspend Mail】**

You can suspend the mail function in the i-mode Center when it is not necessary.

■ **Number of characters that can be sent/received**

The number of characters that can be sent/received in i-mode mail is as listed below.

Items	Full-pitch characters (kanji characters, hiragana characters, pictographs, etc.)	Hal-pitch characters (alphabetic characters, numerals, katakana characters, etc.)
Subject	15 characters	30 characters
Destination	—	50 characters
Text	5000 characters	10000 characters

*: The number of characters that can be sent/received will be reduced when a file such as melody, image, i-motion is attached or the text is decorated.

Note

- Up to 5000 full-pitch characters (10000 bytes) can be sent/received in i-mode mail text, but the number of characters that can be sent/received is reduced depending on the data size of an attached file.
- When i-mode mail text exceeds the number of characters that can be received, "/" or "//" is inserted in the end of the text and the excessive part is automatically deleted.
- When sending i-mode mail to a mova handset, the text can contain up to 2000 full-pitch characters. In addition, i-shot or i-motion mail is sent as a mail containing URL and other attachment files are deleted.
- When the number of characters in a subject exceeds the allowable limit for reception, excessive characters are deleted.
- Do not use half-pitch katakana or pictographs except in mails sent or received between i-mode handsets (including mova handsets). Such characters, if any, used for other terminals may not be displayed correctly on the receiver side.

When i-mode Mail Cannot Be Received

i-mode mail delivered to i-mode Center will be immediately sent to your i-mode handset. Note that, however, when your i-mode handset is turned off or out of the service area, the i-mode mail is stored in i-mode Center. i-mode mail stored in i-mode Center is resent up to 3 times with a predetermined interval. In addition, Receive Option can also be used to select and receive i-mode mail stored in i-mode Center.

- The maximum number of i-mode mails and storage period in i-mode Center are as listed below.

	Maximum number of mails stored	Maximum storage period
i-mode mails	207 to 1000 mails	720 hours

- Expired i-mode mails are automatically deleted.
- The maximum number of stored mail varies depending on the i-mode mail data sizes. When the maximum number of stored mails is exceeded, $★$ appears on the i-mode handset. At this time, i-mode Center does not receive an i-mode mail and returns it to the sender with an error message. Note that with Receive Option "ON", $★$ does not appear even when the maximum number of stored mails is exceeded.
- You can receive i-mode mails stored in i-mode Center by "Check new message" or "Receive Option" settings. In addition, when a new i-mode mail is delivered, you can receive it together with other i-mode mails and Message R/F stored.
- When i-mode mail stored in i-mode Center is received, it is deleted from i-mode Center.
- i-mode message with an excessive size may not be accepted by i-mode Center.

Other Convenient Functions

■ File attached mail

Melody attached mail

You can send/receive a melody file downloaded from a site or Web site through mail attachment. Note that, however, a melody file whose mail attachment or output from FOMA handset is prohibited cannot be sent.

Sending →P175　Receiving →P176

Image attached mail

You can send/receive a still image file downloaded from a site or Web site through i-mode mail attachment. Note that, however, a still image file whose mail attachment or output from FOMA handset is prohibited cannot be sent.

Sending →P175　Receiving →P176

■ i-shot

You can send/receive a still image shot with a terminal with Camera function to/from i-mode handsets (including mova handsets), PCs or mobile phones of other carriers. It is sent to the receiver as a mail of attachment file format or that containing URL (or icon) for image viewing with an image storage period described. When URL is sent, the image can be acquired by selecting the URL.

A mail text sent to an i-mode handset of mova service can contain up to 184 full-pitch characters (369 bytes). When 2 or more files are attached, they are deleted and only the mail text is sent.

Sending →P175　Receiving →P176



*: When a mail containing URL of an attached image is received

- The image is stored in i-shot Center a maximum 10 days and automatically deleted after expiration.
- i-mode handset can send a still image of up to 500K bytes. When a message attached with an image exceeding 20K bytes is sent to an i-mode handset, it acquires an image with its size automatically reduced.

i-motion Mail

You can send/receive videos shot with an i-motion mail compatible handset or those acquired from sites to/from i-motion mail compatible handsets, PCs or mobile phones of other carriers. Note that, however, a video file cannot be sent if its mail attachment or output from FOMA handset is prohibited cannot be

sent.
Sending →P172 Receiving →P178

■ **Service scheme**

- A video file attached to i-motion mail is sent to and stored in i-motion mail Center.
  If it is for a PC, etc., it is directly sent as an attachment file. When it is received by an i-motion mail compatible handset, a video can be acquired by selecting URL indicated in the message text.
- When a video file attached to i-motion mail is sent to a handset incompatible with i-motion mail, it is received as a mail containing URL with i-motion converted to continuous still images. The receiver can acquire the continuous images by selecting the indicated URL.



- Video is stored in i-motion mail Center for up to 10 days and automatically deleted after expiration.
- An i-motion compatible handset can receive video of a maximum 500K bytes. The size of the received video is automatically converted so that it matches the screen of the i-motion mail compatible handset.

■ **Deco-mail**

You can create and send or receive enjoyable i-mode mail edited in a decorative manner such as changing the font size and/or background color or pasting an image in the text. Note that, a decorated mail received from a PC may not appear exactly in the same way as on the PC, because some decorations are not available on i-mode handsets. When a Deco-mail is sent to an incompatible handset, it is received as a mail containing URL. The receiver can view the Deco-mail by selecting the indicated URL.
Editing/Sending →P174

- Applicable models: Available on Deco-mail compatible handsets. For details, refer to "i-mode User's Manual".

■ **Simultaneous mail sending**

Same i-mode mail can be sent to multiple (up to 5) addresses at a time. →P173

- The communication fee is the same as that for sending one i-mode mail. Note that the communication fee will increase for the information size of added destinations.

■ **CC or BCC sending/receiving**

Similarly to PC, TO, CC and/or BCC can be selected as destinations. Note that mail with no TO destinations cannot be sent. →P173

■ **Chat mail**

Mail can be exchanged in a similar manners as chatting with multiple parties. →P186

- The communication fee for exchanging chat mail with multiple parties is the same as that for simultaneous mail sending.

■ **i-appli attached mail**

You can activate i-appli from URL (link) pasted to received i-mode mail. →P157

SMS (Short Message)

You can send/receive text messages using only the mobile phone numbers without subscription to i-mode.
Sending →P187 Receiving →P188 Checking →P189

■ **SMS (Short Message) destination**

SMS destination is "subscribed mobile phone number".

- For destinations used for sending/receiving SMS to/from overseas carriers other then DoCoMo, see DoCoMo's web site.

■ **Number of characters that can be sent/received**

The number of characters that can be sent/received in SMS is as listed below.

Destination	21 characters (including "+")	
SMS text entry settings	Full-pitch character entry (70 characters)	Half-pitch alphanumeric entry (160 characters)

■ **When SMS (Short Message) cannot be received**

SMS delivered to SMS Center will be immediately sent to your FOMA handset. Note that, however, when your FOMA handset is OFF or out of the service area, the SMS is stored in SMS Center.

Note

- The maximum storage period of SMS in SMS Center is 72 hours. The sender can specify the storage period. →P184
- SMS expired is automatically deleted.
- SMS stored in SMS Center can be received by SMS inquiry. →P189

Continued on the next page

- When SMS stored in SMS Center is received, it is deleted from SMS Center.

Mail Menu

Displaying Mail Menu

1 [✉] ▶ **Perform the following operations**

Mail Menu screen

Inbox
Display an Inbox list screen. →P178

Outbox
Display an Outbox list screen. →P179

Unsentbox
Display an Unsentbox list screen. →P179

Compose message
Create a new i -mode mail. →P172

Compose SMS message
Create new SMS (Short Message). →P187

ChatMail
Display chat mail screen. →P186
- When you use chat mail for the first time, the member setup screen appears. →P186

Deco-mail template
Display Decorated mail template screen. →P175

Swap
Call up another function from mail menu. →P226

Check new message
Receive i-mode mail stored in i-mode Center by i-mode check. →P177

Check SMS
Receive SMS stored in SMS Center by SMS check. →P189

Receive option
You can check subjects of i-mode mails stored in i-mode Center and select ones to be received or deleted without reception from the i-mode Center. →P176

Message setting
Set the mail function. →P184

Creating/sending i-mode mail

Creating and Sending i-mode Mail

- To send with attached file → "Attaching a File" (P175)

1 **Mail Menu screen (P172) ▶ "Compose message"**

Compose message screen

2 **Select the $★$ (Receiver) field ▶ (●) ▶ Enter the receiver**

- Enter up to 50 half-pitch characters.
- After the address is entered, a new $★$ (Receiver) field is added automatically allowing you to send more than 1 recipient.
  Up to 5 addresses can be entered.
- You can select and enter an address from the Phonebook or call logs. Press [Function]. →P173

3 **Select the $★$ (Subject) field ▶ (●) ▶ Enter subject ▶ (●)**

- Up to 15 full-pitch or 30 half-pitch characters can be entered.

4 **Select the $★$ (Message) field ▶ (●) ▶ Enter text ▶ (●)**

- Up to 5000 full-pitch or 10000 half-pitch characters can be entered.
- To decorate mail →P174



Message entry screen

5 [✉] **[Send]**

Note

- Characters may not be sent correctly to the receiver depending on the signal wave conditions.
- Do not use half-pitch katakana and pictographs except for mail exchanged between i-mode handsets. These characters may not be displayed correctly.
- The secret code is added automatically when the mail whose address is set with the secret code is sent. However, the address of the sent mail does not display the secret code.
- If there is not enough free space, or if the maximum number of mail to be saved is exceeded, i-mode mail cannot be created. Delete unnecessary i-mode mail or SMS from folders in the Outbox. →P180
- Even if i-mode mail is sent successfully, an error message indicating the mail could not be sent may appear depending on signal conditions.

- If the number of sent mail saved on the FOMA handset exceeds the maximum allowed, the oldest sent mail will be overwritten first. (Checking the specifications). However, protected mail will not be overwritten.

Function Menu on Compose message Screen

1 Compose message screen (P172) ▶ [Function] ▶ Perform the following operations

Send
Send mail.

Save
Save mail being created or edited in Unsentbox. Press $★$ [Yes].

Select Template
Read a template to create Deco-mail. Press [Yes].

Change to To
The addresses of recipients. The mail addresses entered in the To fields will be shown to other recipients.

Change Cc
The addresses of carbon copy recipients. You can specify additional addresses to send a copy of the same mail to other recipients in addition to the direct recipients. The mail addresses entered in the Cc field will be shown to other recipients.
- The mail address may not be displayed depending on the recipient's handset, device or mail software.

Change to Bcc
The addresses of blind carbon copy recipients. You can specify addresses of people to receive copies but whose identity will not be shown to other recipients. The mail addresses entered in the Bcc field will not be shown to other recipients.

Delete Receiver
Delete a selected destination. Press $★$ [Yes].

Quote Phonebook
Select a destination from a phone book.

Quote Received Address
Select a destination from received mail history.

Quote Sent Address
Select a destination from sent mail history.

Quote Sending Group
Select a destination from a sent group.

Quote Profile
Display a profile screen. A destination from the profile.

▶ **Enter the Security Code**

Direct Input
Directly enter a destination.

Note

Save
- Mail which $★$ (Receiver), $★$ (Subject) or $★$ (Message) is not entered or with no attachment cannot be saved.

Function Menu on Message Entry Screen

1 Message entry screen (P172) ▶ Select "Message" ▶ ● ▶ [Function] ▶ Perform the following operations

Decorate mail
Display a palette. →P174

Reset decoration
Cancel all of decoration.

Template
Use a template to create Deco-mail.

Copy
Select and copy characters in text. →P265

Cut
Select and cut characters in text. →P265

Paste
Paste copied or cut characters to text. →P265

Undo
Restore character entry, deletion, paste, decoration, etc. to the previous state.

Import
Quote characters from signature, phone book or local phone information (profile) and enter them to text.

Signature : Select and enter a signature.

Phonebook : Select mail address and/or phone number from phone book and enter them to text.

Owner Information : Select mail address and/or phone number from local phone information (profile) and enter them to text.

Common phrases
Select and enter a fixed phrase to text.

Entry Mode
Switch the entry mode. →P260

Entry Setup
Set conversion prediction function and character entry.

Japanese Prediction : Set "J Matching" and "J Next Word". →P263

English setting : Set the English entry mode ,"E Matching" and "E Next Word". →P263

Cursor timeout : Set the automatic cursor function. →P263

Pitch mode : Switch between full-/half-pitch mode. →P263

Default : Change default character entry mode. →P263

Continued on the next page ●●•

English functions

Set English character entry function. "Turn on"/"Turn off" (Checking the specifications)

Preview

Display preview screen of text being edited.

- [OK]: Display text edit screen.
- [Save]: Save as Deco-mail template.

Deco-mail

Creating and Sending Deco-mail

You can create your own designer mail by adding decorations such as changing font size, font color or background color, or inserting images when you edit i-mode mail messages.

1 **Perform Steps 1 to 3 in "Creating and Sending i-mode Mail" (P172)**

2 **Select the $★$ (Message) field ▶ ● ▶ [Function] ▶ "Decorate mail"**

- Decorating operations →P174

Palette display screen

3 **[Close]**

■ **To view set Deco-mail**
[Function] ▶ Select "Preview"

■ **Cancel the set Decoration**
[Function] ▶ Select "Reset decorate"

4 **● ▶ [Send]**

Note

- When Deco-mail is sent to or received from a handset other than Deco-mail compatible i-mode handsets, decorations may not be displayed correctly.

Decorating Operations

Decorate characters using the palette.
You can decorate entered characters or select decoration before entering characters.

■ **Enter characters then decorate them**
Select "tennis" from the message and decorate the word.



■ **Select decoration then enter characters**
Select decoration from the palette and apply it to characters to be entered after the cursor.
In the screen on the right, the characters to be entered after "a tennis" will be decorated.

Palette

The following table describes operations for decorating mail using the palette:

Palette display screen

[Message]/[Decorate]	Each press of the key toggles between message entry and mail decoration.
[Close]	Close the palette.

*: Unable to select" is displayed next to any decoration that cannot be set.

1 **Select decoration ▶ ●**

$★$ (Edit decoration)

Specify the range of text to decorate.

▶Move the cursor to the front of the character to be selected▶ [Start]

- [Select All]: You can select all sentences.

▶Move the cursor to the back of the character to be selected▶ [End]

- [Return]: Returns to the previous operation. (Checking the specifications)
- : You can cancel the selection. (Checking the specifications)

$★$ (Font color)

Set a color of characters.

▶ Select color ▶ ● ▶ Enter characters

$★$ (Blink)

Make characters flashing.

▶ Move the cursor to the starting point of flashing ▶ ● [Begin blink]

▶ Enter characters ▶ ● [End blink]

$★$ (Background color)

Set a background color of mail text.

▶ Select color ▶ ●

$★$ (Insert image)

Insert an image saved in "My Pictures" to mail text.

$★$ (Undo)

Restores a set decoration to previous setting.

$★$ (Font size)

Set a font size.

▶ Select from "Large"/"Standard"/"Small" ▶ ●

$★$ (Word alignment)

Set a position to enter characters or insert an image.

▶ **Select from "Left"/"Center"/"Right"** ▶ ●

$★$ (Ticker)

Set a ticker to the text.

▶ **Move the cursor to the starting point of the ticker** ▶ ● **[Begin ticker]**

▶ **Enter characters** ▶ ● **[End ticker]**

$★$ (Swing)

Set swing to text.

▶ **Move the cursor to the starting point of the swing** ▶ ● **[Begin swing]**

▶ **Enter characters** ▶ ● **[End swing]**

$★$ (Insert line)

Insert a line in mail text.

$★$ (Copy/Cut/Paste)(Checking the specifications)

Select characters, images or lines and copy, cut or paste them.

■ **Select characters to be copied or cut**

See "$★$ (Edit decoration)".

■**Pasting characters**

▶ **Select copied/cut characters** ▶ **$★$**

▶ **Select inserting position** ▶ **$★$**

Note

Edit Decoration／Copy／Cut

- When characters with "Ticker" or "Swing" set are selected and "Copy" or "Cut" is carried out, the settings for "Ticker" or "Swing" are not affected.

Template

Creating Deco-mail Using Template

Templates are form data for Deco-mail with decorations such as the font size and image insertion already set. In addition to templates preinstalled, you can use those downloaded from sites.

- Templates preinstalled →P288

1 **Message entry screen (P172)** ▶ **[Function]** ▶ **"Select template"**

2 **Select a template** ▶ ●

The selected template is inserted in the message text.

Creating/Editing a Template

Create original templates or edit saved templates.

1 **The Mail Menu screen (P172)** ▶ **"Deco-mail template"**

Decorated mail template screen

Compose template

Create a new template.

▶ **[Function]** ▶ **"Decorate"**

- Basic decorating operations →P174

Template list

Edit templates saved in the "Databox".

▶ **Select decoration** ▶ ● ▶ **(Checking the specifications)**

File attachment

Attaching a File

You can send i-mode mail attached with images or melodies.

■ **File that can be attached**

File type	Maximum number of attached files
Melody	Total of 10*1
Image of 10000 bytes or smaller (JPEG or GIF)	
Image over 10000 bytes (JPEG)	One of either*2
Video/i-motion Movie	

*1: The total data size including melodies, images and text of these 10 files should not exceed 5000 full-pitch characters (10000 bytes). The number of files that can be attached differ depending on their data sizes.

*2: One of image or video/i-motion of up to ●● Kbytes can be attached. It is counted as one, besides melodies and images of 10000 bytes or less.

- A file prohibited to be attached to mail or to be output from FOMA handset cannot be attached.
- When a JPEG format image or i-motion exceeding 10000 bytes is attached, the number of characters that can be entered to text is reduced by 100 full-pitch characters (200 half-pitch characters).
  When decoration is made, it is reduced by 200 full-pitch characters (400 half-pitch characters).
- Up to 11 files can be attached to mail. It is reduced depending on the file sizes.

Continued on the next page ●••

1 **Compose message screen (P172) ➧ $★$ (Attach) ➧ ● ➧ Perform the following operations**

Attach image
Select a file from those saved in "My Pictures".

Attach i-motion
Select a file from those saved in "i-motion".

Attach melody
Select a file from those saved in "Melody".

Snap photo
Shoot and attach a still image.
➧ **Shoot a still image** ➧ [Insert] **[Insert]**
[Discard]: Re-shoot a still image.

Shoot movie
Shoot and attach a video.
➧ **Shoot a video** ➧ [Insert] **[Insert]**
[Discard]: Re-shoot a video.

microSD
Select a file from those saved in microSD memory card.

Deleting/Changing an Attached File

You can delete, change, replay or confirm information of an attached file.

1 **Select an attached file ➧ ●**

Play/Display : Replay/display a selected file.
Change : Change a selected file.
File properties
: Display information about a selected file.
Delete : Delete a selected file. Press [Yes].

Automatic reception of mail

When i-mode Mail is Received

When FOMA handset is in a service area, i-mode mail is automatically sent from i-mode Center.

1 **When i-mode mail is received, $★$ goes flashing and "Receiving messages･･･" appears.**

When reception has completed, the reception result appears on the screen.

- Returns to the Standby screen if no operation is performed for 30 seconds.

Receiving message screen

Message Reception status screen

2 **"Mail"**

Display an Inbox list screen.

Note

- When new i-mode mail is delivered, other i-mode mail and/or Message R/F stored in i-mode Center are received at the same time.
- i-mode mail allows to receive melodies and/or still images as attached files. Incompatible attached files are automatically deleted in i-mode Center.
- When Receive Option for i-mode mail has been set, sent i-mode mail is stored in i-mode Center. You can confirm a subject, etc. of i-mode mail stored in Center and select and receive it. →P176
- When received mails exceed the limit, they are overwritten from the oldest ones. Note that unread or protected mails are not overwritten.

Displaying New i-mode Mail Received

1 **Message Reception status screen (P176) ➧ "Mail" ➧ Select a folder ➧ ●**

2 **Select mail to be displayed ➧ [Select]**



Inbox detail screen

Receive option

Selecting and Receiving i-mode Mail

You can confirm a subject, etc. of i-mode mail stored in i-mode Center and select mail to be received or delete it in i-mode Center before reception.

- To use Receive Option, set "Receive Option" to "On" in advance. Note that when it is "On", i-mode mail cannot be automatically received. →P184

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

1 **Mail Menu screen (P172) ▶ "Receive option"**

Subsequently, perform the operations in "i-mode User's Manual".

Note

- Receive option can also be carried out from "iMenu". Select "iMenu"→"English"→"Menu List"→"Receive option".
- Even with Receive option set to "On", all mails are received when "Check new message" is used. When you do not want to receive mails, delete "Mail" from the inquiry items. →P184

Check new message

Checking for i-mode Mails

i-mode mails, if any, that could not be received because FOMA handset was out of the service area or for other reasons are stored in i-mode Center. You can receive stored i-mode mails by checking to i-mode Center.

- You cannot inquire from out of the service area.

1 **Mail Menu screen (P172) ▶"Check new message"**

When check has completed, the mail reception result appears on the screen.

Note

- When new i-mode mail is delivered, other i-mode mail and/or Message R/F stored in i-mode Center are received at the same time.
- When received mails exceed the limit, they are overwritten from the oldest ones. Note that unread or protected mails are not overwritten.

Replying i-mode Mail

Replying to i-mode Mail

You can reply to i-mode mail sender. Replying can be made by entering new text or quoting the text of received i-mode mail.

1 **Received mail list screen (P179)/Inbox detail screen (P179) ▶ [Function]**

■ Replying by quoting received mail text

Select "Reply with quotation".

- When the mail has been sent to multiple receivers simultaneously, you can select "Sender" or "All".

■ Not quoting received mail text

Select "Reply".

- You can reply to mail also by pressing [Reply] on Inbox detail screen.
- When the mail has been sent to multiple receivers simultaneously, you can select "Sender" or "All".

2 **Entering subject and text ▶ ●**

- "Re:" is added to a subject.
- When replying by quoting, ">" is added to the beginning of quoted text.
- Editing subject and text → "Creating and sending i-mode mail" (P172).

3 **[Send]**

Note

- When the storage capacity of Outbox has been exceeded, replying cannot be made. Delete mails saved in Outbox before replying.
- You cannot send i-mode mail in self mode.
- The reply to received Deco-mail with quotation has original decoration and images entered in the message text. However, restricted images and highlighted URLs will not be quoted.

Forwarding i-mode Mail

Forwarding i-mode Mail to Another Destination

You can forward received i-mode mail to another party.

1 **Received mail list screen (P179)/Inbox detail screen (P179) ▶ [Function] ▶ "Forward"**

2 **Enter destination ▶ ●**

- "Fw:" is added to a subject.
- Editing destination and text → "Creating and sending i-mode mail (P172)

3 **[Send]**

Note

- When a file whose mail attachment or output from FOMA handset is prohibited has been attached or pasted to i-mode mail forwarded, such file and information are deleted.
- When the storage capacity of Outbox has been exceeded, forwarding cannot be made. Delete mails saved in Outbox before forwarding.
- The forwarded Deco-mail has original decoration and images entered in the message text. However, restricted images and highlighted URLs will not be forwarded.

Registering Mail Address to Phonebook

You can register sender's mail address, phone number and URL contained in text of received mail to phonebook.

1 **Inbox detail screen (P179) ▶ Select mail address, phone number and/or URL to be registered in phonebook ▶ [Function] ▶ "Save in Phonebook"**

2 **Register to phonebook**

Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Save Melody

Replaying/Saving Melody from i-mode Mail

Playing Melody

1 **Inbox detail screen (P179) ▶ Select attached or pasted melody ▶ ●**

Saving Melody

1 **Inbox detail screen (P179) ▶ [Function] ▶ "Check attachment"**

List files attached to received mail.

Screen to be inserted

Attached file list screen

2 **Select a melody file to be saved ▶ [Save]**

Receiving Image Mail

Displaying/Saving Image of Image Mail

Displaying an Image

1 **Inbox detail screen (P179) ▶ Select an attached image ▶ ●**

Note

- An image larger than the display size is reduced for display. Note that, however, an image that is too large may not be displayed. (Checking the specifications)

Saving an Image

1 **Inbox detail screen (P179) ▶ [Function] ▶ "Check attachment"**

List files attached to received mail.

2 **Select an image file to be saved ▶ [Save]**

Replaying/Saving i-motion from i-motion Mail

Select URL contained in i-motion mail received, acquire i-motion stored in i-motion mail Center and save it.

1 **Inbox Detail Screen (P179) ▶ Select URL ▶ ● ▶ $★$ [Yes]**

Acquisition of i-motion starts.

- When "i-motion auto playing setting" has been set to "Auto replay", i-motion is automatically replayed after acquisition.

2 **"Save" ▶$★$ [Yes] (Checking the specifications)**

Outbox/Inbox/Unsentbox

Displaying Mails in Outbox/Inbox/Unsentbox

Displaying Mails in Inbox

Up to ●●● mail items including i-mode mails and SMS can be saved.

- The number of items that can be saved varies depending on their data sizes.

1 Mail Menu screen (P179) ▶ "Inbox"

Inbox list screen

2 Select a folder ▶ ●

- ⊖: Display the previous or next page when there are 2 or more pages.
- [Sort]: Sort mail by selecting keys such as received date and time, subject or sender. →P180

Received mail list screen

3 Select a mail ▶ ●

- ⊕: Scroll the screen.
- ⊖: Display the previous or next mail.
- [Reply]: Reply to the sender and/or receivers of simultaneous mail sending. →P172, P187



Inbox detail screen

Displaying Outbox Mails

Up to ●●● mail items including i-mode mails and SMS can be saved.

- The number of items that can be saved varies depending on their data sizes.

1 Mail Menu screen (P172) ▶ "Outbox"

Outbox list screen

2 Select folder ▶ ●

- ⊖: Display the previous or next page when there are 2 or more pages.
- [Sort by]: Sort mail by selecting keys such as sent date and time, subject or sender. →P180

Sent mail list screen

3 Select mail ▶ ●

- ⊕: Scroll the screen.
- ⊖: Display the previous or next mail.
- [Edit]: Display Compose message or SMS creation screen. →P172, P187



Sent mail detail screen

Displaying Mails in Unsentbox

Mails created but not sent are saved. Up to ●● mail items including i-mode mails and SMS can be saved.

- The number of items that can be saved varies depending on their data sizes.

1 Mail Menu screen (P172) ▶ "Unsentbox"

Unsentbox list screen

2 Select folder ▶ ●

- ⊖: Display the previous or next page when there are 2 or more pages.
- [Sort]: Sort mail by selecting keys such as saved date and time, subject or sender. →P180

Unsent mail list screen

3 Select mail ▶ ●

- ⊕: Scroll the screen.
- ⊖: Display the previous or next mail.
- [Edit]: Display Compose message or SMS creation screen. →P172, P187



Unsent mail detail screen

Continued on the next page ●••

Note

- To display contents of a folder with mail security set, enter the Security code.

Sorting Mail in Inbox/Outbox/Unsentbox List Screen

Sort mail by specifying keys such as chronological or reverse chronological order. (Checking the specifications)

1 Inbox list screen (P179)/Outbox list screen (P179)/Unsentbox list screen (P179) ▶ [Sort]

Received date (new>old)/Sent date (new>old)/ Saved date (new>old)
Sort mail in chronological order of received, sent or saved date.

Received date (old>new)/Sent date (old>new)/ Saved date (old>new)
Sort mail in reverse chronological order of received, sent or saved date.

Subject (ascending order)
Sort mail in ascending order of subject.

Subject (descending order)
Sort mail in descending order of subject.

Sender (ascending order)
Sort mail in ascending order of sender.

Sender (descending order)
Sort mail in descending order of sender.

■ Notice
Saved contents may be lost by failure, repair or other handling of FOMA handset. DoCoMo is not liable to such loss and recommends you to store contents saved in FOMA handset to microSD memory card. They can be stored in a PC, if available, using data link software and FOMA USB connection cable (optional).

Reading Box List/Mail List/Mail Detail Screen

Icons on Inbox/Outbox/Unsentbox List Screen

Icons	Description
$★$	Folder containing unread mails/SMS
$★$	Folder containing no unread mails/SMS
$★$	Folder with security set
$★$	Created folder containing unread mails/SMS
$★$	Created folder containing no unread mails/ SMS
$★$	Mail-linked i-appli folder

Icons on Received/Sent/Unsent Mail List Screen

Icons	Description
$★$	Unread mail
$★$	Read mail
$★$	Unread SMS
$★$	Read SMS
$★$	Protected mail
$★$	Replied mail
$★$	Forwarded mail
$★$	Mail with acquired image attached
$★$	Mail with acquired melody attached
$★$	Mail with not acquired image attached
$★$	Mail with not acquired melody attached
$★$	SMS saved in UIM

Function Menu on Inbox/Outbox List Screen

1 Received mail list screen (P179)/Outbox list screen (P179) ▶ [Function] ▶ Perform the following operations

Create folder
Create a folder.
▶ Enter folder name

Edit folder name
Edit a selected folder name.
▶ Enter folder name

Auto sort
Set conditions for automatically saving mails in specified folders. →P185

Sort folders
Sort folders.
▶ Select a folder to be sorted ▶ [Select] ▶ Select location to move the folder ▶ [Define] ▶ [Complete]
- [Return]: Go back to the previous operation.

Set security/Release security
Set or release security to the selected folder. Setting security requires the security code entry to view the contents of the folder.
▶ Enter the Security Code

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

Delete folder
Delete a selected folder.

Mail list
Display contents of a selected folder.

Delete All Messages
Delete all mail in Inbox/Outbox.

▶ **Enter the Security Code**

Send all entries
Send all received mails by Bluetooth. (Checking the specifications)

Note

Sort folders/Delete folder
- Folders registered by default cannot be sorted or deleted.

Delete folder
- A folder containing protected mails cannot be deleted.
- When there is mail-linked i-appli, the folder for i-appli cannot be deleted.

Delete All Messages
- Protected mails or SMS saved in UIM are not deleted. For a folder with security set, a confirmation message appears asking whether to delete it. Press [Yes] to delete the folder.

Function Menu on Received Mail List Screen

1 Received mail list screen (P179) ▶ Select mail ▶ [Function] ▶ Perform the following operations

Reply
Reply to mail. →P177

Reply w/quotation
Reply to received mail quoting its contents.

Forward
Forward mail. →P177

Search
Search for received mail under set conditions.

Search unread : Search for only unread mails.
Search read : Search for only read mails.
Search protected : Search for only protected mails.
Search attached : Search for only mails with file attached.
Re-search* : Search again.
Release search* : Cancel searching state.

Protect/Release
Protect or release the selected mail.

Release : Release the selected mail.
Release all : Release all mail.

Move to folder
Move a selected folder.

▶ **Select a move destination ▶ [Select] ▶ [Yes]**

Switch display
Select information to be displayed on received mail list screen.

▶ **"Date/Subject/Sender"/"Date/Sender"/"Subject/Sender"**

Check address
Display addresses of the sender and simultaneous receivers of a selected mail.
- [Detail]: Display detail screen of a selected address.

Create message : Reply to a selected address/phone number. →P177, P187
Save in Phonebook : Register a selected address/phone number for phonebook. →P178
Auto sort : Set to automatically save a selected address/phone number to a specified folder under specified conditions. →P185
Register sending group : Register a selected address to a send group. →P185
Copy E-mail : Copy a selected address/phone number.

Send
Send a selected mail via Infrared communication.

UIM
Copy or move a selected SMS to UIM/FOMA phone.

Move to UIM : Move SMS to UIM. Press [Yes].
Copy to UIM : Copy SMS to UIM. Press [Yes].
Move to Phone : Move SMS to the phone. Press [Yes].
Copy to Phone : Copy SMS to the phone. Press [Yes].

Delete
Delete : Delete a selected mail. Press [Yes].
Delete multiple : Select and delete 2 or more mails. Select mails to be deleted ▶ ● ▶ [Execute] ▶ Press $★$ [Yes].
Delete all : Delete all messages in the folder, or delete all messages found using "Search". Enter the Security Code ▶ Press $★$ [Yes].

Note

Delete
- Protected mails cannot be deleted.

Protect
- Up to ●● mails can be protected.

Function Menu on Inbox Detail Screen

1 Inbox Detail screen (P179) ▶ [Function] ▶ Perform the following operations

Reply
Reply to mail. →P177

Continued on the next page●••

Reply w/quotation
Reply to received mail quoting its contents.

Forward
Forward a mail →P177

Protect/Release
Protect or release the displayed mail.

Scroll
Set a number of lines to be scrolled. →P184

Font size
Set a font size. →P184

Save to template
Save Deco-mail as a template. (Checking the specifications)

Move to folder
Move the displayed mail to another folder.

▶Select a move destination ▶ [Select] ▶ [Yes]

Check address
Display addresses of the sender and simultaneous receivers of a displayed mail.
- [Detail]: Display detail screen of a selected address.

Compose message : Reply to a selected address/phone number. →P177, P187

Save in Phonebook : Register a selected address/phone number to phonebook. →P178

Auto sort : Set to automatically save a selected address/phone number to a specified folder under specified conditions. →P185

Check image
Save images contained in the displayed mail. Select an image then go to Step 2 in "Saving Images from a Site or Message" (P155).

Check Attachment
List files attached to a displayed mail.
- [Save]: Save the selected file.

Attached file list screen ▶ [Function]

Set up : Display a setup screen after saving a file. (Checking the specifications)

File Properties : Display information of a selected file.

Delete : Delete a selected file.

Send
Send a displayed mail via Infrared communication.

UIM
Copy or move a selected SMS to UIM/FOMA phone.

Move to UIM : Move SMS to UIM. Press [Yes].

Copy to UIM : Copy SMS to UIM. Press [Yes].

Move to Phone : Move SMS to the phone. Press [Yes].

Copy to Phone : Copy SMS to the phone. Press [Yes].

Delete
Delete a displayed mail.

Save in Phonebook
Register a selected mail address/phone number to phonebook. →P178

View URL
Display URL of pasted to mail text. (Checking the specifications)
- [Copy]: Copy URL.

Note

Save to template
- A large-size still image file or melody file attached to Deco-mail is deleted when saving the mail.

Delete
- Protected mails cannot be deleted.

Protect
- Up to ●● mails can be protected. (Checking the specifications)

Function Menu on Sent Mail Detail Screen

1 Sent mail Detail screen (P179) ▶ Select a mail ▶ [Function] ▶ Perform the following operations

Edit
Edit and send a sent mail. →P172, P186

Search
Search sent mail under set conditions.

Search protected : Search only protected mails.

Search attached : Search only mails with file attached.

Re-search : Search again.

Release search : Cancel searching state.

Protect/Release
Protect or release the selected mail.

Release : Release the selected mail.

Release all : Release all mail.

Move to folder
Move a folder.

Move : Move a selected folder. Select a move destination ▶ [Select] ▶ Press [Yes].

Move multiple : Select and move 2 or more mails. Select mails to be moved ▶ ● ▶ [Execute] ▶ Select $★$ [Yes].

Move all : Delete all messages in the folder, or delete all messages found using "Search". Enter the Security Code ▶ Press $★$ [Yes].

Switch display
Select information to be displayed on sent mail list screen.

▶"Date/Subj./Sender"/"Date/Sender"/"Subject/Sender"

Check address
Display addresses of the sender and simultaneous receivers of a selected mail.
- [Detail]: Display detail screen of a selected address.

Compose message (Compose SMS)
: Reply to a selected address/phone number. →P177, P187

Save in Phonebook : Register a selected address/phone number to phonebook. →P178

Auto sort : Set to automatically save a selected address/phone number to a specified folder under specified conditions. →P185

Register sending group
: Register a selected address to a send group. →P185

Copy E-mail・Copy phone No.
: Copy a selected address/phone number.

Send
Send a selected mail via Infrared communication.

UIM
Copy or move a selected SMS to UIM/FOMA phone.

Move to UIM : Move SMS to UIM. Press [Yes].

Copy to UIM : Copy SMS to UIM. Press [Yes].

Move to Phone : Move SMS to the phone. Press [Yes].

Copy to Phone : Copy SMS to the phone. Press [Yes].

Delete
Delete a sent mail.

Delete : Delete a selected mail. Press [Yes].

Delete multiple : Select and delete 2 or more mails. Select mails to be deleted ▶ ● ▶ [Execute] ▶ Select $★$ [Yes].

Delete all : Delete all messages in the folder, or delete all messages found using "Search". Enter the Security Code ▶ Press $★$ [Yes].

Note

Delete
- Protected mails cannot be deleted.

Protect
- Up to ●● mails can be protected. (Checking the specifications)

Function Menu on Sent Mail List Screen

1 Sent mail display screen (P179) ▶ [Function] ▶ Perform the following operations

Copy
Copy contents of a displayed sent mail.

Address : Copy a destination. When there are simultaneous receiver addresses, copy destinations from sent mail address confirmation screen.

Subject : Copy a subject.

Message : Select and copy contents of text. →P264

Protect/Release
Protect or release the displayed mail.

Scroll
Set a number of lines to be scrolled. →P184

Font size
Set a font size. →P184

Save to template
Save Deco-mail as a template. (Checking the specifications)

Move to folder
Move the displayed mail to another folder.

▶Select a move destination ▶ [Select] ▶ [Yes]

Check address
Display addresses of the sender and simultaneous receivers of a displayed mail.
- [Details]: Display detail screen of a selected address.

Compose message (Compose SMS)
: Send mail or SMS to a selected address/phone number. →P177, P187

Save in Phonebook : Register a selected address/phone number to phonebook. →P178

Auto sort : Set to automatically save a selected address/phone number to a specified folder under specified conditions. →P185

Register sending group : Register a selected address to a send group. →P185

Copy E-mail・Copy phone No.
: Copy a selected address/phone number.

Check image
Save images contained in the displayed mail. Select an image then go to Step 2 in "Saving Images from a Site or Message" (P155).

Check Attachment
List files attached to a displayed mail.
- [Save]: Save a selected file.

Attached file list screen ▶ [Function]

Set : Display a setup screen after saving a file. (Checking the specifications)

File Properties : Display information of a selected file.

Delete : Delete a selected file.

Send
Send a displayed mail via Infrared communication.

Continued on the next page●••

UIM
Copy or move a selected SMS to UIM/FOMA phone.

Move to UIM : Move SMS to UIM. Press [Yes].

Copy to UIM : Copy SMS to UIM. Press [Yes].

Move to Phone : Move SMS to the phone. Press [Yes].

Copy to Phone : Copy SMS to the phone. Press [Yes].

Save in Phonebook
Register a selected mail address/phone number to phonebook. →P178

Delete
Delete a displayed mail.

- Items displayed on the function menu vary depending on the displayed mail.

Note

Protect
- Up to ●● mails can be protected.(Checking the specifications)

Save to template
- A large-size still image file or melody file attached to Deco-mail is deleted when saving the mail.

Delete
- Protected mails cannot be deleted.

Mail setting

Setting FOMA Handset Mail Functions

Default	Check new message: Checked All (Checking the specifications) Receive attachment: Image and Melody Receive option: OFF Melody auto play: Auto Play Receive preference: Prefer receive notice Font size: Standard Scroll: 1-line

Set the mail and SMS functions.

1 **Mail Menu screen (P172) ▶ "Mail setting"**

Mail setting screen

2 **[Select] ▶ Perform the following operations**

Check new message
Set items to be checked for "Check new message".

▶Select the items to be checked ▶ [Select]

Receive attachment
Set attachment files to be acquired when receiving mail, Message R/F, etc.

Image and Melody : Acquire images and melodies.

Image : Acquire only images.

Melody : Acquire only melodies.

Not receive : Acquires no attachment files.

Receive option
Set whether to set Receive Option.

ON : Do not automatically receive mails.

OFF : Automatically receive mails.

Melody auto play
Set whether to automatically replay a melody attached or pasted to a mail received and displayed.

▶"Auto Play"/"Not auto play"

Receive preference
Set whether to display a receiving or reception result screen of a mail or Message R/F received during FOMA handset operation.

Prefer receive notice : Displays the Receiving screen and Received result screen.

Prefer user operation : Gives priority to the operation of the FOMA handset without displaying the Receiving screen and Received result screen.

Signature
Set a signature to be inserted to mail text. →P185

Edit quotation mark
Set a symbol indicating quotation from a received mail used for replying by quoting.

▶Enter quotation mark

Font size
Set a font size for text on mail display screen.

▶"Large"/"Standard"/"Small"

Scroll
Set a number of lines to be scrolled when is pressed on a mail detail or mail creation screen.

1-line : Scroll 1 line.

3-line : Scroll 3 lines.

5-line : Scroll 5 lines.

1/2-page : Scroll 1/2 page.

1-page : Scroll 1 page.

Register sending group
Register a mail address of a group. You can send a mail simultaneously to multiple members registered in the group. →P185

SMS report request
Set whether to request for SMS delivery notification for SMS sent. →P189

SMS message validity
Set duration SMS is preserved in SMS Center. →P189

SMS Center
Set SMS Center access point. →P189

Mail status request
Confirm the mail settings. After confirming, press [OK].

Reset mail
Reset the mail settings to the Default.

▶Enter the Security Code ▶ [Yes]

Note

Receive attachment
- Even when "Image and Melody" or "Image" has been set, a large-size still image file cannot be acquired.

Auto sort

Sorting Sent/Received Mails Automatically to Folders

Set conditions for automatically saving mails in specified folders.

1 Inbox list screen (P179)/Outbox list screen (P179) ▶ [Function] ▶ "Auto sort"

- [Delete]: Delete the set sort condition by "delete this"/"delete all".

Auto sort setting screen

2 "Add rule" ▶ Perform the following operations

Sender address・Receiver address
Set mail address as a sort keys.

▶Select the following item ▶$★$▶After setting ▶ [Complete]

Quote phonebook	:	Select and set from a phonebook.
Quote rcvd adrs	:	Select and set from received mail history.
Quote sent adrs	:	Select and set from sent mail history.
Quote sending grp	:	Select and set a group from send groups.
Quote profile	:	Select and set from a profile.
Direct input	:	Directly enter and set a mail address.

Subject
Set a mail subject as a condition.

▶ Enter a subject ▶ [Complete]

All inbox messages・All outbox messages
Sort all received/sent mails to a selected folder. Press [Complete].

■ Changing sort conditions

When a set sort condition is selected from automatic sort setup screen (P185) and ● is pressed, a screen for confirming condition change appears.
Select [Yes] to change a sort condition.

Note

- When the same condition has been set for another folder, a message for confirming the change appears. When [Yes] is selected, the condition set for another folder is cancelled and set for a selected folder.

Signature

Add a Signature to Mail

Default	Off

Edit and set a signature to be inserted to mail text.

1 Mail setting screen (P184) ▶"Signature"

■ Changing signature title
Select "Signature 1"/"Signature 2"/"Signature 3" ▶ [Title] ▶ Enter a title

■ Registering and editing signature text
Select "Signature 1"/"Signature 2"/"Signature 3" ▶ ● ▶ Enter signature text
- Entering characters →P260

Signature setting screen

2 $★$

Register Sending Group

Registering a Destination to a Mail Group

Register a mail address of a group. Up to 5 mail address can be registered for a group. You can send a mail simultaneously to multiple members registered in the group.

1 Mail setting screen (P184) ▶"Register sending group"



Sending group list screen

Continued on the next page●●•

2 **Select a group ➧ ●**

Register sending group screen

3 **"[Unregistered]" ➧ Perform the following operations**

Quote phonebook
Select and register a mail address from a phonebook.

Quote received group
Select and register a mail address from a received mail history.

Quote sending group
Select and register a mail address from a sent mail history.

Quote profile
Select and register a mail address from a profile.

Direct input
Directly enter a mail address.

4 **[Complete]**

Function Menu on Send Group List Screen

1 **Send group list screen (P185) ➧ Select a group ➧ [Function] ➧ Perform the following operations**

Edit group name
Edit/changes a group name.
➧**Enter a group name**

Delete
Delete all addresses saved for a selected group. Select [Yes].

Deleting an address saved in a category

1 **Send category registration screen (P186) ➧ [Delete]**

Delete
Delete the selected address. Press [Yes].

Delete all
Delete all addresses registered in a category.
➧**Enter the Security Code ➧ [OK]**

Chat Mail

Chat mail allows you to exchange mail among multiple parties on a single screen.

Chat Mail Screen (Checking the specifications)



Chatmail screen

Creating/sending chatmail

Creating and Sending Chat Mail

To use chat mail, you have to register other parties' mail addresses as chat members in advance. →P187

- When "Receive option" is "ON", you cannot use chat mail. Set "Receive option" to "OFF".
- Select $★$ (Subject) "ChatMail" on the Received mail list screen (P179) to launch Chat mail and reply to mail arriving from a member.

1 **Mail Menu screen (P172) ➧ "ChatMail"**

Chatmail screen

2 **● ➧ Enter characters ➧ ● (Checking the specifications)**

Entered characters are highlighted.

- Up to 250 full-pitch or 500 half-pitch characters can be entered.

Chatmail text entry screen

3 [Send]

A sent chat mail appears in the top of the display.

Screen to be inserted

Screen after sending chatmail

4 Receive chatmail

5 [Function] ▶ "End Chatmail" ▶ $★$ [Yes]

Chat mail ends.

Note

- Communication fee for exchanging chatmail with multiple parties is the same as that for sending one mail. Note that the communication fee will increase for the information size of added destinations.

Function Menu on Chat Mail Screen

1 Chat mail screen (P186) ▶ [Function] ▶ Perform the following operations

Send
Send chat mail.

Renewal
Receive chat mail.

Check recent rcver
Confirm destination of the latest mail.
- [Set]: Set a member again. Put $★$ on an address to be set as a chat member and press [Complete].

Member setting
Set a chat member.

Delete chatmail
Delete a chat mail. Press $★$ [Yes].

Quit chatmail
End chat mail.

Change font size
Change a font size used for chat mail to "Standard character"/ "Small character".

Setting chat members

Setting Chat Members

To perform Chat Mail, you need to register mail addresses to chat members in advance.

- Up to 5 chat members can be saved.
- When performing Chat Mail, from the Mail Menu screen (P172) → select "ChatMail".

1 Chat mail screen (P186) ▶ [Function] ▶ "Member setting"

Member setting screen

2 [Function] ▶ Perform the following operations

Register new entry
Specify the name and mail address for a new chat member.

Search a phonebook	: Select from a Contact.
Direct entry	: Directly enter the mail address and name.
History of sent mails	: Select from sent addresses.
History of received mails	: Select from received addresses.
Group reference	: Select from sent groups.

Edit
Specify a nickname and font color.

Nickname	: Enter a nickname.
Address	: Edit the address of a member.
Font Color	: Select a font color for a member from 30 colors.

Delete

Delete One	: Delete the selected member. Press $★$ [Yes].
Delete All	: Delete all registered members. Press $★$ [Yes].

3 [Complete]

Creating/Sending SMS

Creating and Sending SMS (Short Message)

Create and send SMS.

- You can send and receive SMS to/from parties of overseas carriers other than DoCoMo. See DoCoMo's web site for countries and overseas carriers available.

1 Mail Menu screen (P172) ▶ "Compose SMS message"

Compose SMS message screen

Continued on the next page

2 Select $★$ (Receiver) ▶ ● ▶ Enter a phone number

Enter a phone number.

- Select and enter from a phonebook, received mail address history, sent mail address history or profile. →P186

3 Select $★$ (text) ▶ ● ▶ Enter text

4 [Send]

Note

- For a destination of an overseas carrier other than DoCoMo, enter in the order of "+", "Country Code" and "receiver's mobile phone number". For the mobile phone number, omit leading "0", if exist. Numbers may be entered in the order of "010", "Country Code" and "receiver's mobile phone number" (to reply to overseas SMS received, enter "010").
- Characters may not be sent correctly to the receiver depending on the signal wave conditions.
- When sent mails saved in FOMA handset exceed the limit, they are overwritten from the oldest ones. Note that protected mails are not overwritten.
- You cannot reply to SMS sent with Private ID or Unknown ID or from a public phone.

Function Menu on SMS Creation Screen

1 SMS creation screen (P187) ▶ [Function] ▶ Perform the following operations

Send
Send SMS.

Save
Save SMS being created or edited in Unsentbox.

SMS report request
Set whether to request for SMS delivery notification for SMS sent. →P189

Message validity
Set a period a sent SMS is stored in SMS Center.
- When "0 day" is selected, sent SMS is not stored in SMS Center. →P189

Quote phonebook
Select a destination from phonebook.

Quote rcvd adrs
Select a destination from received mail history.

Quote sent adrs
Select a destination from sent mail history.

Quote sending grp
Select a destination from a sent group.

Quote profile
Select a destination from the profile.

▶Enter the Security Code

Direct input
Directly enter a destination.

Receiving SMS

Automatically Receiving SMS (Short Message)

When FOMA handset is in a service area, SMS is automatically received.
Up to ●●● items including i-mode mails and SMS can be saved.

1 When SMS is received, $★$ goes flashing and "Retrieving Message･･･" appears

When reception has completed, the reception result appears on the screen.

- Returns to the Stand-by screen if no operation is performed for 30 seconds.

Message Reception status screen

Note

- When new SMS is delivered, other i-mode mail and/or Message R/F stored in i-mode Center are received at the same time.
- When received mails exceed the limit, they are overwritten from the oldest ones. Note that unread or protected mails are not overwritten.

Displaying New SMS Received

1 Message Reception status screen (P188) ▶ "Mail" ▶ Select a folder

2 Select SMS to be displayed ▶ [Select]



Inbox detail screen

Check New SMS

Checking for SMS (Short Message)

SMS, if any, that could not be received because FOMA handset was out of the service area or for other reasons are stored in SMS Center. You can receive stored SMS by checking to SMS Center.

- You cannot check from out of the service area.

1 **Mail menu screen (P172) ➧ "Check SMS"**

When check has completed, the mail reception result appears on the screen.

Note

- When new SMS is delivered, other i-mode mail and/or Message R/F stored in i-mode Center are received at the same time.
- When received mails exceed the limit, they are overwritten from the oldest ones. Note that unread or protected mails are not overwritten.

SMS Settings

Configuring SMS (Short Message) Settings

SMS Report Request

Default	OFF

Set whether to request an SMS delivery report after sending SMS. If this option is set to "ON", a message indicating that the SMS has been delivered to the recipient will be sent to you.

1 **Mail setting screen (P184) ➧ "SMS report request" ➧ "ON"/"OFF"**

SMS message validity

Default	For 3 days

Set the duration that a sent SMS can be kept undelivered at the SMS center.
When "For 0 day" is set, SMS will not be kept undelivered at the SMS center.

1 **Mail setting screen (P184) ➧ "Message validity" ➧ "For 0 day"/"For 1 day"/"For 2 days"/"For 3 days"**

SMS Center

Default	DoCoMo

Set the SMS center address.

You usually do not need to change this setting.

1 **Mail setting screen (P184) ➧ "SMS Center"**

DoCoMo : Set DoCoMo as SMS Center address.
Others : Enter the address.

Note

- To set "Type of Number" to "International", enter "+" at the beginning of the address. If the address contains "*" or "#", "International" cannot be set.

i-appli

What is i-appli? 192
Downloading i-appli from Site 193
Activating i-appli 194
Automatically Starting i-appli<Auto-Start> 195
Setting the i-appli Standby Screen<Stand-by> 196
Managing i-appli<i-appli Settings>.....197
Using Various Functions of i-appli.....197

What is i-appli?

By downloading i-appli from site, i-mode compatible FOMA handset (hereinafter, referred to as i-mode handset) can be made more convenient. For example, you can enjoy various games downloaded to i-mode handset and automatically check price by downloading i-appli for stock price information. In addition, map i-appli downloads only necessary data, allowing smooth scrolling. Some i-appli allows to directly register data to phonebook or schedule or link with Databox for saving and acquiring images.



- Downloading i-appli →P193
- Activating i-appli →P194
- Automatically activating i-appli →P195

Note

- Some i-appli may use a serial No. of i-mode handset phone/UIM.
- Some i-appli may perform communications during execution. You can set to disable communications. →P196

■ **Using registered data**

Some i-appli software may be able to refer to, register or operate your i-mode handset registration data (phonebook, bookmark, schedule, images). Following operations are enabled using registration data:

- Phonebook registration
- Bookmark registration
- Schedule registration
- Image acquisition from Databox
- Image saving to Databox
- Melody saving to Databox

What is i-appliDX?

With i-appliDX, you can use i-appli more conveniently in such manners as to create mail with your favorite character screen or let you notified of the sender of received mail with a character's comment by linking with i-mode handset information (such as mail text, sent/received mail history, redial, phonebook data) or to update necessary information such as stock price or promote real-time progression of games by linking with mail.

■ **Using registered data**

Some i-appliDX software may be able to refer to, register or operate registration data such as mails, sent mail history, received mail history, ring alert, in addition to registration data available to ordinary i-appli (phonebook, bookmark, schedule and images).

Following operations are enabled using registration data:

- Phonebook registration
- Phonebook referencing
- Icon information
- Bookmark registration
- Schedule registration
- Using mail menu
- Using Compose message screen
- Referencing latest sent mail history
- Referencing latest received mail history
- Referencing latest unread mail
- Saving ring alert
- Changing ring alert (phone, mail, message)
- Image acquisition from Databox
- Image saving to Databox
- Changing screen settings (the stand-by display, incoming/outgoing calls, mail send/reception, Message R/F reception)

Note

- i-appliDX may perform communications regardless of software communication settings to confirm software validity. The communications count and timings differ from software.

What is Mail-linked i-appli?

Mail-linked i-appli, a kind of i-appliDX, allows you to use i-appli more conveniently in such manners to update in real-time the information such as stock price and progression of games by exchanging information with i-mode mail.

- Mails used with mail-linked i-appli may not be displayed correctly.

Other Convenient Functions

■ **i-appli Standby screen**

You can receive mails and make calls using i-appli as the stand-by display. You can make the

stand-by display more convenient by setting latest news or whether information on the wallpaper screen or letting your favorite character inform you of mail reception and alarms. →P196

- This function is available with i-appli compatible with the i-appli Standby screen.

■ **Automatically starting i-appli**

You can automatically start software at a specified time, date or day of week. Some software can be automatically started at a time interval predefined in the software. →P195

■ **Using camera**

You can use i-mode handset Camera from i-appli.

- This function is available with i-appli compatible with Camera function.

■ **Infrared communication**

You can communicate with a device installed with Infrared communication function using the software. →P223

- This function is available with i-appli compatible with Infrared communication function.
- Depending on the other party's device, communications of some data may be disabled even with Infrared communication function installed.

■ **Infrared remote control**

You can operate various device from i-appli such as household electrical appliances compatible with infrared remote control. →P195

For example, "Gガイド番組表リモコン (G-Guide Program List Remote Controller)" registered by default can be used as a remote TV controller linked with TV program. →P195

- This function is available with i-appli compatible with infrared remote control function. The other party's device must have related software.

Downloading i-appli from Site

You can download software from a site and save it to FOMA handset.

- You can register ●● to up to ●●● software items downloaded (the number of items that can be saved may be reduced depending on the software date size).

1 Display a site containing i-appli ▶ Select software ▶ ●

- [Cancel]: Cancel downloading.

2 After downloading has completed ▶ [OK]

■ **When software setup screen appears**

Set "Set stand-by", "Network set" and "Stand-by net".

Each setting can also be performed from "Permissions". →P195, P196

- [Change]: Change the settings.
- [Complete] : Complete the settings.

3 [Yes]

The downloaded software starts.

■ **Downloading mail-linked i-appli**

The folder for i-appli mail is automatically created in the inbox/outbox list if you download mail-linked i-appli. The folder name will be the title for the downloaded mail-linked i-appli, which cannot be changed.

- If there are ● folders for i-appli mail in the inbox/outbox list, mail-linked i-appli cannot be downloaded.
- If mail security is activated, you need to enter the Security Code for download. (Checking the specifications)

■ **Re-downloading mail-linked i-appli**

If you attempt to re-download mail-linked i-appli with only the folder for i-appli mail left, you can use the existing folder for i-appli. If you do not want to use the existing folder for i-appli mail, delete the folder and create a new one for i-appli mail. You cannot download mail-linked i-appli without creating a new folder. (Checking the specifications)

Note

- At downloading, the conformation screen might appear asking whether to send the "serial number of your mobile phone/UIM". Select "Yes" to start downloading. In this case, the "serial number of your mobile phone/UIM" is sent to the ISP (Internet Service Provider) over the Internet, so could be deciphered by third parties. However, your phone number, address, age, and gender are not notified to the ISP (Internet Service Provider) or others by this operation.
- At downloading, the confirmation screen might appear asking whether to use the phone-information data (stored data and serial number of your mobile phone/UIM). Select "Download" to start downloading. Select "Details" to check the details of the phone-information data you want to use.
- If you attempt to re-download the software that was downloaded with a different UIM, the confirmation message appears asking whether to overwrite it. Select "Yes" to display the screen to check the version and size of the software. Select "Download" to download.
- If download of i-appli fails due to the conditions of the radio waves, etc., the i-appli is not saved in you FOMA handset.
- You cannot download if the maximum number of software is saved or there is not enough memory space available. Download after deleting the saved software.
- Some software automatically carries out transmission after downloaded. You can change the settings in "Network set" of "Permissions" not to automatically carry out transmission. →P195

Activating i-appli

1 ● ▶ $★$ (i-appli)

Screen to be inserted

Software list screen

2 Select software ▶ ●

- : Terminate the software. Select "Resume" or "End".

Icons on software list screen

Icons	Description
$★$	i-appli
$★$	i-appliDX
$★$	Mail-linked i-appli
$★$	i-appli that can be set on the wallpaper screen
$★$	i-appliDX that can be set on the wallpaper screen
$★$	Mail-linked i-appli that can be set on the wallpaper screen
$★$	i-appli set on the wallpaper screen
$★$	i-appliDX set on the wallpaper screen
$★$	Mail-linked i-appli set on the wallpaper screen
$★$	i-appli/i-appliDX/mail-linked i-appli with automatic start set
$★$	i-appli/i-appliDX/mail-linked i-appli downloaded from SSL site

Note

- At i-appli launch, the confirmation screen might appear asking whether to upgrade the software to the latest one. Select "Yes" or "No".
- You cannot start up software downloaded using a different UIM.
- Some i-appli DX software automatically does communication to confirm the validity even if "Network set" is set to "Not". Communication frequencies and timing vary depending on the software.
- If communication frequencies are extremely many within a certain period of time during i-appli launch, the confirmation screen appears asking whether to continue communication. Press [Continue] to continue communication. Press [End] to end the i-appli.

Function Menu on Software List Screen

1 Software list screen(P194)▶ Select software ▶ [Function] ▶Perform the following operations

Upgrade
Upgrade the software. Press [Yes].

Delete
Delete software. →P196

Auto-start
Set the auto start method and auto start date and time for the selected software. →P195

Stand-by
Set selected software on the i-appli Standby screen. →P196

Software Info
Display selected software information such as name, version, size.

Permissions
Set communications and/or i-appli To function for selected software. →P196

Note

Upgrade

- At version upgrade, the conformation screen might appear asking whether to send the "serial number of your mobile phone/UIM". Select "Yes" to start downloading. In this case, the "serial number of your mobile phone/UIM" is sent to the ISP (Internet Service Provider) over the Internet, so could be deciphered by third parties. However, your phone number, address, age, and gender are not notified to the ISP (Internet Service Provider) or others by this operation.

Software Preinstalled

(Checking the specifications)

i Pictograph Mail

(Checking the specifications)

Ope it out

(Checking the specifications)

Hungry Fish

(Checking the specifications)

Guide Program List Remote Controller

This is a convenient application which combines a TV program list and a TV remote controller, and is free of monthly usage charges.
You can obtain TV program information for any time slot, from anywhere and at anytime. You can acquire information on a program title, program description, start and end times and the G-code for your local TV station.
When you find a program of interest, you can send mail, using the "Recommendation Mail" function, with the program title and broadcast schedule to your friends. You can also control your TV remotely (some models cannot be controlled).

- When using this application for the first time, you need to configure the settings and agree to the license agreement.
- Separate packet communication charges apply.
- For details, refer to the "i-mode Operation Guide".

■ Infrared Remote Controller

You can use the FOMA handset as a remote controller of infrared remote controlled devices. An i-appli sends remote control signals using the infrared port.

- In order to use a remote controlled device, you need to download software that is designed for the device. Key operations for remote control vary depending on the software.
- Some devices may not be controlled.
- Depending on the controlled device or ambient brightness, communications may not be possible.
- When Self-mode is set, the infrared remote controller cannot be used.
- Point the infrared port of the FOMA handset directly in front of the device's infrared sensor to operate.



Software Settings

Setting i-appli Operating Conditions

Default	Network set: Yes Stand-by net: Yes Start from browser: Yes Start from mailer: Yes Start from IR: Yes Start from Barcode: Yes Change ring/image: Yes Phbook/Dials acc.: Yes (Checking all the specifications)

Set operating conditions for each software. You can set to make communications automatically while software is active or whether to start i-appli via infrared communications.

1 On software list (P194)▶ Select software ▶ "Permissions"▶ Select the following items▶ [Change]

Network set
Set whether to make communications while software is active.
▶**"Yes"/"No"/"Once"**

Stand-by net
Set whether to make communications while the i-appli Standby screen is active.
▶**"Yes"/"No"**

Start from browser
Set whether to start software from site.
▶**"Yes"/"No"**

Start from mailer
Set whether to start software from a mail.
▶**"Yes"/"No"**

Start from IR
Set whether to start software via infrared communications.
▶**"Yes"/"No"**

Start from Barcode
Set whether to start software from barcode reader.
▶**"Yes"/"No"**

Change ring/image
Set whether to allow, when software is started, to automatically change an image and/or melody set for ring alert or on the wallpaper screen.

Yes : Automatically change ring alert and/or the stand-by display settings. To let display a confirmation screen for each change, successively select [Yes].

No : Do not automatically change the settings.

Phbook/Dials acc.
Set whether to allow to reference the phonebook and reception history when software is started.
▶ **"Yes"** ▶ **"No"**

Auto-Start

Automatically Starting i-appli

There are 2 types in automatic start:

- Automatic start by software function
- Automatic start by FOMA handset settings

Setting whether to Automatically Start

Set whether to allow automatic start of software

1 ●▶$★$ (Settings)▶"i-appli Settings"▶"Auto-start"▶ [Change]

On : Permit Auto-start.

Off : Do not permit Auto-start.

Setting Start Date/Time

Validating Automatic Start Date/Time Set in Software

Default	Off (Checking the specifications)

When automatic start previously set for software is allowed, the software automatically starts at the date/time set in the software.

1 **Software list screen (P194)▶ Select software ▶ [Function]▶"Auto-start"**

2 **"Permissions"▶ [Edit]▶"On"/"Off"▶ [Complete]**

Setting Software Start Date/Time on FOMA Handset

Default	Off (Checking the specifications)

Set to automatically start software at the set date/time.

1 **Software list screen (P194)▶ Select software ▶ [Function]▶"Auto-start"**

2 **"User"▶ [Edit]**

Off	:	Do not set Auto-start.
Once	:	Set to start only once.
Daily	:	Set to start every day.
Weekly	:	Set to start every week.
Monthly	:	Set to start every month.
Yearly	:	Set to start every year.

3 **Perform the following operations**

User
Select a repeating pattern of Auto-start using .

Day
Set the date. Press [Change].
▶ Use to select "Year", "Month" or "Day" field ▶ Select a number using ▶ [OK]

Day
Set a day of the week using .

Time
Set the time. Press [Change].

Software
▶ Use to select "Hour", "Minute" or "am/pm" field ▶ Select a number using ▶ [OK]

4 **[Complete]**

Note

- 10 minutes before or after an automatic start time set for other software cannot be set.
- Software is not started at a automatic start time if other software is active at that time. An i-appli start failure icon appears in the top of the display. To delete the icon, press ▶$★$ (i-appli)▶ [Detail]. Note that the start failure history is not deleted. →P197

Stand-by

Setting the i-appli Standby Screen

1 **Software list screen (P194)▶ Select software ▶ [Function]▶"Stand-by"▶"ON/OFF"**

Note

- Only one software item can be set on the i-appli Standby screen.
- Some software may not be set on the i-appli Standby screen.
- Site connection from the i-appli Standby screen is disabled.
- When software for communication is set on the i-appli Standby screen, it may not function correctly for some signal conditions.
- When "Stand-by net" is set to "Not", timely information may not be provided.

Starting the i-appli Standby Screen

Activate software set on the i-appli Standby screen.

1 **On the opened i-appli Standby screen ▶ ▶ [Yes]**

■ Exiting active i-appli
Press .
- Resume: Return to software running screen.(Checking the specifications)
- End: Return to the i-appli Standby screen.(Checking the specifications)
- Remove from stand-by: Cancel the i-appli Standby screen.(Checking the specifications)

Note

- Some software may allow to return to the i-appli Standby screen state by key operations while the i-appli Standby screen is ON. Note that the i-appli Standby screen cannot be restored while other menu function is active.

Deleting i-appli

1 **Software list screen (P194)▶Select software ▶ [Function] ▶"Delete"▶Perform the following operations**

Delete One
You can delete the selected software. Press [ch] [Yes].

Delete Several
You can select and delete multiple software programs. Select software to delete ▶ Press [●] ▶ [i-α] [OK] ▶ $★$ [Yes]

Delete All
You can delete all the software saved.

▶Enter the Security Code ▶ [ch] [Yes]

i-appli Settings

Managing i-appli

Default	Sort by: Name Auto-start: On Softw. info display: Off Light: Phone Settings Vibrate: Phone Settings (Checking all the specifications)

You can set up/manage the software saved in the FOMA handset.

1 **[●]▶$★$ (Settings)▶"i-appli Settings"▶ Select the following items ▶ [ch] [Change]**

Sort by
Sort software items displayed on software list screen.

Name	:	Sort software items by name.(Checking the specifications)
Size	:	Sort software items in an descending order of size.(Checking the specifications)
Downloaded Time	:	Sort software items by download date.
Access Time	:	Sort software items by date of use.

Auto-start
Set whether to automatically start software. →P195

Softw. info display
Set whether to display software information when downloading the software.

▶"On"/"Off"

Lights
Set lighting used while software is active.

▶"Light Phone Settings"/"Software Settings"

Vibrate
Set vibrator operation type used while software is active.

▶"Phone Settings"/"Software Settings"

Start failure history
Display a log of software failures to auto-start.

- [ch] [Function]: You can copy or delete the entries of Start failure history. ▶ Select "Clear All"/"Copy All Text".

Abnormal exit history
Display a log of abnormal termination of the i-appli Standby screen.

- [ch] [Function]: You can copy or delete entries of the Abnormal exit history. ▶ Select "Clear All"/"Copy All Text".

Security error history
Display a log of errors of software terminated due to a security error.

- [ch] [Function]: You can copy or delete the entries of Security error history. ▶ Select "Clear All"/"Copy All Text".

Trace output
Display the trace information of the software.

- [ch] [Function]: You can copy or delete the contents of the trace information. ▶ Select "Clear All"/"Copy All Text".

Note

Trace output

- Trace information does not appear if it does not exist.

Using Various Functions of i-appli

You can connect to a site and use FOMA function while i-appli is active.

- For some i-appli, operations may be different or disabled.

Starting up Other Software from i-appli

You can start up software saved in the FOMA handset during i-appli launch.

1 **Select a running i-appli ▶ [●] ▶ [ch] [Yes]**

The software list screen is displayed.

2 **Select that the software ▶ [ch] [Yes]**

Displaying Site i-appli from Site

- You have to download related i-appli in advance.

1 **Select URL during i-appli launch▶$★$ ▶ [ch] [OK]**

Software exits and site appears.

Using Barcode Reader from i-appli

- You have to download related i-appli in advance.

1 **Start barcode reader from i-appli (Checking the specifications)**

A screen appears indicating that the read data will be used and saved by i-appli.

2 **Read code**

i-Channel

What is i-Channel?.....200
Using i-Channel.....201
Setting i-Channel<i-Channel Setting>.....201

What is i-Channel?

This is a service provided by DoCoMo or IP (Information Service Provider) to deliver news and/or weather information as graphical information to handsets compatible with i-Channel.
Information is periodically received and latest information is displayed as ticker on the wallpaper screen; in addition, it can also be displayed in a channel list by pressing [ch]. Moreover, rich detail information can be acquired by selecting favorite channels from a channel list.

- For precautions and details of using i-Channel, see "i-mode User's Manual".

Before subscribing to the service

1

After the service subscription procedures have been completed



2 3 4

* Screens shown are images. They differ from actual ones.
1. When you have not subscribed to i-Channel
2. After you have subscribed to i-Channel, ticker appears on the wallpaper screen at a timing information is received or channel list is displayed.
3. A channel list is displayed by pressing [ch]. You can view in list format information, etc. given in ticker of each channel.
4. You can view detail information screen of each channel by selecting it.

Channel

There are 2 types of channels: "Basic Channel" and "Favorite Channel".
"Basic Channel" is channel provided by DoCoMo. Because it is registered by default, it is immediately available upon subscription to i-Channel. Packet communication fee charged for automatic update of information delivered for "Basic Channel" is contained in i-Channel service fee.
"Favorite Channel" is provided by IP (Information Service Provider) other than DoCoMo and available when you register a favorite one. Packet communication fee charged for automatic update of information delivered for "Favorite Channel" is not contained in i-Channel service fee.
Information that can be displayed as ticker on the wallpaper screen is only that of "Basic Channel".



- i-Channel is a chargeable service requiring subscription (i-mode contract is necessary for subscription).
- Operations →P201
- Applicable models: 701i, 902i, 702i Series, P851i

Note

- Some "Favorite Channel" may require information fee for using.
- Some "Favorite Channel" may require separate subscription to IP (Information Service Provider) that provides information for use.
- Both "Basic Channel" and "Favorite Channel" require packet communication fee for viewing detail information from a channel list besides i-Channel service fee.

Trial Service

When you use an i-Channel compatible handset and have subscribed to i-mode, but not to i-Channel for the subscriber line using the i-Channel compatible handset, you can use "Basic Channel" for a predetermined period of time without service fee. Note that you will be charged packet communication fee for viewing detail information from a channel list.
Trial service will be started automatically in principle when a predetermined period of time has elapsed after inserting UIM and starting to

use i-Channel compatible handset. When it is not started automatically, press [ch] to start it. Trial service can be used only once for one subscriber line. Trial service will be terminated automatically when a predetermined period of time has elapsed after the start. For the procedure to terminate it halfway, see "i-mode User's Manual".

- For precautions and details of using the trial service, see "i-mode User's Manual".

Using i-Channel

When you have subscribed to i-Channel, information automatically appears as ticker on the wallpaper screen upon reception of information.

- To automatically display ticker, set "Ticker display set" to "ON". →P201
- When "Phone Lock" or "UIM PIN" is On, no ticker appears on the wallpaper screen even with "Ticker display set" set to "ON". Enter Handset Security Code to display ticker. (Checking the specifications)
- The ticker cannot be displayed when an i-appli Standby screen is set.

1 [ch]



Ticker　　Channel list screen

2 Select a channel item ▶ ●

The site is connected and detail information appears.

- ⊖: The channel list screen returns.

Note

- Even when information is received, no ring alert or vibrator operates. In addition, reception lamp does not go ON or flashing.(Checking the specifications)
- Information may not be received when the FOMA handset is turned off, or when the signal reception is weak such as while out of the service area. In this case, select a channel for non-subscribers that appears by pressing [ch] to receive information. The ticker on the Standby screen will show the information automatically. Also, information may not be received using the default settings. In this case, press [ch] to receive information. The ticker on the Standby screen will show the information automatically.
- Depending on the operating conditions, information may be received at the timing a channel list is displayed.
- If you change the connection destination in "Host setting" of "i-mode setting", the connection destination of i-Channel is also changed. (Normally, you do not need to change the settings).
- A message to the effect of failure of channel information acquisition may appear in the following cases:
  - When i-Channel connection destination has been changed
  - When the handset has been initialized
  - When UIM has been replaced

i-Channel Setting

Setting i-Channel

Default	Ticker display set: ON Ticker speed set: Usually Ticker display: Font Color (Green)/ Background Color (Black)

You can set whether to display ticker on the wallpaper screen or set the ticker display style.

1 Channel list screen (P201) ▶ [ch] [Function] ▶ Perform the following operations

Ticker display set

Set whether to display channel information in the ticker style on the wallpaper screen.

▶ **"ON"/"OFF"**

Ticker speed set

Set the ticker moving rate.

▶ **"Low speed"/"Usually"/"High speed"**

Ticker display

Set font color and/or background color of ticker.

Font Color : Select a font color or "Default"▶ [ch] [Select].

Background Color : Select a background color or "Default"▶ [ch] [Select].

Swap

Call up another function such as phonebook or mail. →P226

Note

Telop display

- When "Default" is selected, the default color is used.

Data Display, Edit, Management/Music Playback

Databox.....204

Still Images
Displaying Images<Picture Viewer>.....204
Editing Still Images<Edit Still Images>.....207

Video Clips/i-motion
Playing Videos/i-motion Movies<Video/i-motion Player>.....208
Editing Videos/i-motion Movies<Edit Videos/i-motion Movies>.....210
Using Albums<Picture Albums/i-motion Movie Album>.....211

Chara-den
What is Chara-den?<Chara-den>.....213

Melody
Playing Melodies<Melody Player>.....214
Creating a Playlist<Playlist>.....216

Voice Notes
Using Voice Notes<Voice Notes>.....218

microSD Memory Card
microSD Memory Cards.....221
Inserting/Removing a Memory Card.....221
Structure of Folders on the Memory Card.....222
Using a Memory Card.....222
Reading and Writing to a Memory Card.....222

Exchanging Data via Infrared Communication/Cable Connection

Infrared Communication<Infrared Communication>.....223
Exchanging Data One Piece at a Time<Ir data/IrDA link> 223
Exchanging All Data<Send All/Receive All> 224

Databox

The Databox contains the items and folders shown in the following table. Data obtained from sites or i-mode mail are saved in folders according to their respective types.

My Pictures	
Pictures (All)	All still images saved in My Pictures
Camera	Still images captured by the Camera
i-mode/Other	Still images obtained from sites, via Email or data communications
Pre-installed	Still images provided by default
Picture Albums	Most Viewed
	User-created picture albums
i-motion	
i-motion (All)	All videos/i-motion movies saved in the i-motion folder
Camera	Videos captured by the Video Camera
i-mode/Other	Videos obtained from sites, via Email or data communications
Pre-installed	Videos provided by default
i-motion Albums	Most Viewed
	User-created i-motion albums
Melody	
Melody (All)	All melodies saved in Melody
i-mode/Other	Melodies obtained from sites, via Email or data communications
Pre-installed	Melodies provided by default
Playlists	Most Played
	User-created playlists
Artists	Lists per artists
Albums	Lists per albums
Genres	Lists per genre
Composers	Lists per composers
Chara-den	
Chara-den (All)	All Chara-den saved in Chara-den
i-mode/Other	Chara-den obtained from sites, via Email or data communications
Pre-installed	Chara-den provided by default
Animations	
Animations (All)	All Flash movies saved in Animation
i-mode/Other	Flash movies obtained from sites, via Email or data communications
Pre-installed	Flash movies provided by default
Voice Notes	
Voice Notes (All)	All Voice Notes saved in Voice Notes
My Notes	User-created categories

■ **Notice**

Stored content may be lost due to the handset failure, repair or mishandling. DoCoMo is not responsible for lost data. It is recommended that you keep saved content from the FOMA handset on a microSD memory card. You can connect the handset to a PC using data link software and a FOMA USB cable (optional) and save the data to the PC.

Function Menu on the Databox

1 ● ▶ **$★$ (Databox)** ▶ **[Function]** ▶ **Perform the following operations**

Now Playing/Hide

Show or hide the Playback screen for the melody played in background. →P214

Rename microSD

Specify a name to the initialized microSD memory card.

Format microSD

Format the microSD memory card.

Free Space

Display the free space on the handset or the microSD memory card.

Picture Viewer

Displaying Images

You can display still images you have captured, or obtained from sites or i-mode mail.

■ **Available file formats**

File Format*	JPEG, GIF, Flash
Pixels	1024 x 1280 dots or fewer
File Size	XXX Kbytes
File Extension	jpg, gif

*: Even if a file is in a compatible file format, it may not display, depending on the file.

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

1 ●▶$★$ (Databox) ▶ "My Pictures/ Animations"

My Pictures screen

2 Select a folder ▶●

Screen to be inserted

Image file list

3 Select a file ▶●

Still image display screen

Screen to be inserted

Flash playback screen

■ **Operations on the Image display screen**

Button/Key	Description
◎	Display the previous/next file
✱/#	Display the full screen (press ◎ to restore the previous screen)
•	Display a slide show of files in the folder
✉	Create i-mode mail with the file attached Go to Step 2 in "Creating and Sending i-mode Mail" (P172).

■ **Operations on the Flash movie playback Screen**

Button/Key	Description
◎	Display the previous/next file
▲/▼	Increase/decrease the volume

■ **Icons Displayed on the image file list**

Icon	Description
$★$	Files saved on the handset
$★$	Files saved on the memory card

Function Menu on the My Pictures Screen

1 My Pictures screen (P205) ▶ [ch] [Function] ▶ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Create New
Start the Camera.
▶ "Picture"

Pictures Setup
Specify how to display files in the folder. →P206

Function Menu on the My Picture Screen

1 My Picture screen (P205) ▶ Select a file ▶ [ch] [Function] ▶ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

View
Display the selected file.

Play
Play a Flash movie.

Add To Album
Add the selected file to an Album.

Edit
Edit the selected file. →P207

Create New
Start the Camera.
▶ "Pictures"

Filter by
Change the saving destination of the selected file. (Checking the specifications)
▶ "Storage Location"

All : Save the file to both the handset and memory card.
Phone Memory : Save the file to the handset.
microSD : Save the file to the memory card.

Send
in Email : Create i-mode mail with the file attached. Go to Step 2 in "Creating and Sending i-mode Mail" (P172).
to IrDA : Send one file using Infrared communication.
to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting Bluetooth Device" (P239).

Continued on the next page●••

Apply As
Set the selected file as Wallpaper or Screen Saver.

Wallpaper : Set as Wallpaper.

Screen Saver : Set as the Screen Saver.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P95).

Camera Off Image : Set the file as the alternate image for video calls.

Manage
Rename, delete, move or copy the selected file.

Rename : Change the name of the file.

Delete : Delete the selected file.

Move : Move the selected file to the handset or the memory card.

Copy : Copy the selected file to the handset or the memory card.

Select Multiple to

Add To Album: Select more than one file and add to an Album. Select a file to delete ▶ Press ● ▶ [Complete] ▶ $★$ [Yes].

Delete : Select multiple files and move to the other folders, etc.

Move : Select and move more than one file to another folder. Go to Step 3 in "Selecting and Moving/Copying Multiple Files".

Copy : Select and copy more than one file to another folder. Select a file to copy ▶ ● ▶ [Execute] ▶ Select a copying destination folder ▶ Press [Select].

Details
Display the file size, resolution and file format, etc. of the selected file.

▶Scroll with ▶ [Function]

Restrict File : Restrict the file.

Copy All Text : Copy the file information.

Pictures Setup
Set the display method of the selected file. →P206

Function Menu on the Image Display Screen

1 Image display screen (P205) ▶ [Function] ▶ Perform the following operations

View Full Screen
Display an image to the whole screen.

- [CLR]: Cancels the full-screen display.

Add to Album
Select a file and add to an Album.

Create New
Start the Camera.

▶ "Picture"

Send

In Email : Create i-mode mail with the file attached. Go to Step 2 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send one file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the displayed file as Wallpaper or Screen Saver.

Wallpaper : Set as Wallpaper.

Screen Saver : Set as the Screen Saver.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P95).

Camera Off Image: Set the file as the alternate image for video calls.

Manage
Rename, delete, move or copy the displayed file.

Rename: Change the name of the file.

Delete : Delete the displayed file.

Move : Move the displayed file to the handset or the memory card.

Copy : Copy the displayed file to the handset or the memory card.

Zoom

Fit-to-screen : Display an image to the whole screen.

50% : Enlarge and display the file by 50%.

75% : Enlarge and display the file by 75%.

Original Size : Restore the original size of the enlarged image.

Properties
Display the file size, resolution and file format, etc. of the selected file.

▶Scroll with ▶ [Function]

Restrict File : Restrict the file.

Copy All Text : Copy the file information.

Video Quality
Set the quality of the displayed Flash.

▶"Good"/"Better"/"Best"

Replay
Play a Flash movie.

Setting the Image Display

Default	**Auto Repeat: OFF** **Slide Interval: 4 seconds** **Full-Screen: Left (90 CCW)**

Set the display method for an image.

1 **Image file list (P205) ▶ Select a file ▶ [Function] ▶ "Pictures Setup"**

Pictures Setup screen

2 **Select from the following items ▶ [Change]**

Auto Repeat
(Checking the specifications)

▶ **"On"/"Off"**

Slide Interval
Set the interval for a slide show between 1 - 999 seconds.

▶ **Enter a number of seconds**

- [Function]: Edit the entered characters (number of seconds).

Full Screen
Set the angle of the image to be displayed to full screen.

▶ **"Left (90 CCW)"/"Right (90 CW)"**

Edit Still Images

Editing Still Images

You can edit still images. Edited images are saved in "(Checking the specifications)".

- Only JPEG files can be edited. However, you may not be able to edit some files.

1 **Image file list (P205)/Image file list in an Album (P211) ▶ Select a file ▶ [Function] ▶ "Edit" ▶ "Edit Picture"**

The Edit Brightness screen opens.

2 **Use to select the value for Brightness ▶ [Apply]**

- The Brightness value can be selected from -3 - 0 - +3.

Screen to be inserted

Edit image screen

3 **Use to select from the following editing items**

Contrast
Set contrast of the image.

▶ **Use to select the value ▶ [Apply]**

- Select the contrast from -3 - 0 - +3.

Blur/Sharpen
Set the sharpness of the image.

▶ **Use to select the value ▶ [Apply]**

- Select Blur/Sharp from -3 - 0 - +3.

Mirror
Set the direction for mirroring the image. Set an option and press [Apply].

None Selected	Mirroring is not set. (Checking the specifications)
Horizontal	Invert the image horizontally.
Vertical	Invert the image vertically.

Rotation
Set an angle to rotate an image.

▶ **"0 Degrees"/"90 Degrees"/"180 Degrees"/"270 Degrees" ▶ [Apply]**

Borders
Add a frame to an image.

▶ **"border1_filename"/"border2_filename"/"None Selected" ▶ [Apply]**

Image Style
Set special effects for an image. Set an option and press [Apply].

None Selected	No image effect is set. (Checking the specifications)
Black&White	Change the image into black and white.
Negative	Change the image into negative.
Sepia	Change the image into sepia tone.
Solarize	Invert the image horizontally.
Reddish	Emphasize red.
Bluish	Emphasize blue.
Greenish	Emphasize green.

4 **[Save] (Checking the specifications)**

Function Menu on the Edit Image Screen

1 **Image edit screen (P207) ▶ [Function] ▶ Perform the following operations**

Exit
End editing. (Checking the specifications)

Save As
Save the edited image as a new file.

▶ **Set the following items ▶ [Complete]**

File Name	Enter a file name.
Storage Location	Select a location from "Phone"/"Memory Card".

Save
Save an edited image.

Undo
Restore the original image.

Continued on the next page

Crop

Trim away a fixed part of an image to a determined size.

- ⊕: Moves up or down. (Checking the specifications)
- [Function]: Select a cropping size or edit text to be added to an image. (Checking the specifications)

▶ **"3.5x5"/"4x6"/"5x7"/"8x10"/"8 1/4x11 3/4" (A4)"/"Manual"** ▶ **[Apply]**

Screen to be inserted

Cropping screen

Resize

Change the size of the image.

- [Cancel]: Cancel resizing the image.

▶ **Select a size** ▶ ● ▶ **[Yes] (Checking the specifications)**

Add Graphic

Add a graphic to an image.

▶ **Select a graphic** ▶ **[Select]**

Add Text

Add text to an image.

▶ **Set the following items** ▶ **[Complete]**

Text : Enter text to add to the image.

Font Size : Select a font size from "Large"/"Standard"/"Small".

Text Color : Select a text color from 9 colors.

Screen to be inserted

Adding text screen

Note

Borders/Crop/Add Graphic/Add Text

- "Borders", "Crop", "Add Graphic" and "Add Text" cannot be set for an image of 120 x 160 dots or smaller.

Resize

- You cannot "Resize" an image to a larger size than the original image.

Add Text

- "Add Text" cannot be set for an image of 640 x 480 dots or larger.

Video/i-motion Player

Playing Videos/i-motion Movies

You can play video clips you have captured, or i-motion movies obtained from sites or i-mode mail.

■ Available file formats

File Format*	MP4 (Mobile MP4)
Encoding Method	MP4 file Graphics: (Checking the specifications) Audio: (Checking the specifications)
File Extension	mp4 and 3gp

*: Even if a file is in a compatible file format, it may not play, depending on the file.

1 ● ▶ **$★$ (Databox)** ▶ **"i-motion"**

i-motion screen

2 **Select a folder** ▶ ●



i-motion file list

3 **Select a file** ▶ ●

Screen to be inserted

i-motion playback screen

Screen to be inserted

i-motion with ticker screen

■ When the ticker has highlighted text

Select the highlighted area to use the Web To or Mail To function. Select the highlighted area ▶ Press ● ▶ [Yes].

■ Operations on the i-motion playback screen

Button/Key	Description
●	Pause/Play
⊕	Fast Forward/Rewind

■ Operations on the i-motion with ticker screen

Button/Key	Description
●	Pause/Play
● (while a ticker is selected)	Perform Phone To, AV Phone To, Web To or Mail To function

Function Menu on the i-motion Screen

1 **i-motion screen (P208)** ▶ **[Function]** ▶ **Perform the following operations**

Now Playing/Hide

Show or hide the Playback screen for the melody played in background. →P216

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

Create New
Start the Video Camera.
▶ "i-motion"

i-motion Setup
Set the playback method of the selected file. →P210

Function Menu on the i-motion File List

1 i-motion file list (P208) ▶ Select a file ▶ [Function] ▶ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Play
Play the selected file.

Add to Album
Add the selected file to an Album.

Edit
Edit the selected file. →P210

Create New
Start the Video Camera.
▶ "i-motion"

Filter by
Change the saving destination of the selected file. (Checking the specifications)
▶ "Storage Location" ▶ Select from the following items

All : Save the file to both the handset and memory card.
Phone Memory : Save the file to the handset.
microSD : Save the file to the memory card.

Send
In Email : Create i-mode mail with the file attached. Go to Step 2 in "Creating and Sending i-mode Mail" (P172).
to IrDA : Send one file using Infrared communication.
to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the selected file as a Screen Saver or ringtone.

Screen Saver : Set as the Screen Saver.
Incoming Call Alert : Set as a ringtone.
Alarm : Set as an alarm tone.

Manage
Rename, delete, move or copy the selected file.

Rename : Change the name of the file.
Delete : Delete the selected file.
Move : Move the selected file to the handset or the memory card.
Copy : Copy the selected file to the handset or the memory card.

Select Multiple to
Add to Album : Select more than one file and add to an Album.
Delete : Select and delete more than one file. Select a file to delete ▶ Press ● ▶ [Complete] ▶ $★$ [Yes].
Move : Select and move more than one file to another folder. Select a file to move ▶ ● ▶ [Complete] ▶ Select a destination folder ▶ Press [Select].
Copy : Select and copy more than one file to another folder. Select a file to copy ▶ ● ▶ [Execute] ▶ Select a copying destination folder ▶ Press [Select].

Details
Display the file name, size and author, etc. of the selected file.
▶Scroll with ▶ [Function]

Restrict File : Restrict the file.
Copy All Text : Copy the file information.

i-motion Setup
Set the playback method of the selected file. →P210

Function Menu on the i-motion Playback Screen

1 i-motion playback screen (P208) ▶ [Function] ▶ Perform the following operations

Edit
Edit the i-motion that is in playback. →P210

Add to Album
Select a file and add to an Album.

Create New
Start the Video Camera.
▶ "Video"

Send
In Email : Create i-mode mail with the file attached. Go to Step 2 in "Creating and Sending i-mode Mail" (P172).
to IrDA : Send one file using Infrared communication.
to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the file in playback as a Screen Saver or ringtone.

Screen Saver : Set as the Screen Saver.
Incoming Call Alert : Set as a ringtone.
Alarm : Set as an alarm tone.
Video Call Alert : Set as the video call ringtone.
Video Call Message : (Checking the specifications)
Email Message Alert : Set as an Email ringtone.
R/F Message Alert : Set as a ringtone for Messages R/F.
Calendar Alarm : Set as an alarm tone for a Datebook event.

Continued on the next page

Manage
Delete, move or copy the file in playback.

Delete: Delete the file in playback.

Move : Move the file in playback to the handset or the memory card.

Copy : Copy the file in playback to the handset or the memory card.

Details
Display the file name, size and author, etc. of the file in playback.

▶ Scroll with ◎ ▶ [Function]

Restrict File : Restrict the file.

Copy All Text : Copy the file information.

Movies Setup
Set the playback method of the file in playback. →P210

Setting Videos/i-motion Movies Playback Method

Default	Auto Repeat: Off Fit-to-screen: Left (90 CCW)

Set the playback method for i-motion movies.

1 i-motion file list (P208) / i-motion playback screen (P208) ▶ [Function] ▶ "i-motion Setup"/"Movies Setup"

i-motion setup screen

2 Select from the following items ▶ [Change]

Auto Repeat
(Checking the specifications)

▶ "On"/"Off"

Full Screen
Set the angle of the image to be displayed to full screen.

▶ "Left (90 CCW)"/"Right (90 CCW)"

Edit Videos/i-motion Movies

Editing Videos/i-motion Movies

You can edit videos/i-motion movies. Edited videos/i-motion movies are saved in "(Checking the specifications)".

- Some files may not be edited.

Opening the Videos/i-motion Movies Edit Screen

1 i-motion file list (P208) / i-motion playback screen (P208) ▶ [Function] ▶ "Edit"

Screen to be inserted

Video/i-motion movie edit screen

Cropping a Video

You can crop a part of a video image while playing back a video/i-motion movie.

1 Video/i-motion movie edit screen (P210) ▶ "Extract clip"

- ●: Play a video/i-motion movie

2 Specify a starting point for cropping ▶ [Select]

Screen to be inserted

Cropping screen

3 Specify a cropping action ▶ [Select]

Screen to be inserted

4 Specify an ending point ▶ [Yes]

Cropping a Part of a Video as a Still Image

You can crop a still image from a video/i-motion movie.

1 Video/i-motion movie edit screen (P210) ▶ "Extract still"

2 Select an image to crop ▶ ●

3 [Save]

Compressing Video Files

1 **Video/i-motion movie edit screen (P210) ➧ "Compress"**

2 **"i-mode Mail (Small)"/"i-mode Mail (Large)"**

Deleting Sounds or Graphics from Videos

1 **Video/i-motion movie edit screen (P210) ➧ "Delete track"**

2 **"Video track"/"Audio track"/"Ticker"**

Recording Sounds to Videos (Checking the specifications)

1 **Video/i-motion movie edit screen (P210) ➧ "Record audio"**

2 **"Record new track"/"Use existing audio file"**

■ **To record new audio**
The original audio of the video/i-motion movie will be deleted. Press [Yes] to select "Record new track".

3 **[Save]**

Picture Albums/i-motion Movie Album

Using Albums

You can save captured still images/videos or files in My Pictures/i-motion in an Album and manage them.



Picture Album list

i-motion Album list

❶ **Most Viewed**
The Album with files that are most viewed (20 files).
❷ **User-defined Albums**
The created Album name is displayed.
❸ **Create New Album**
Create a new Album.

Function Menu on the Album List

1 **Picture Album list (P211)/i-motion Album list (P211) ➧ [Function] ➧ Perform the following operations**

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

View
Display the images in the selected Album.

Play
Play the i-motion movies in the selected Album.

Create New
Start the Camera/Video Camera and create a new Album.

Picture	:	Start Camera.
i-motion File	:	Start the Video Camera.
Album	:	Creates a new Album. →P211

Manage
Delete, move or copy the file in playback.

Rename	:	Change the name of the Album.
Remove	:	Deletes the selected Album.

Pictures Setup
Specify how to display files in an Album. →P206

i-motion Setup
Specify how to play files in an Album. →P208

Saving Images to an Album

1 **Picture Album list (P211)/i-motion Album list (P211) ➧ "[Create New Album]"**

Folder selection screen (Example: Picture Album)

2 **Select a folder ➧ [Open]**

3 **Select a file to save in an Album**

Screen to be inserted

Example: Add picture screen

Continued on the next page ●••

- Select [Function] ▶ "Select All" to select all files in the folder at once.

4 **[Complete] ▶ Enter an album name**

Displaying Images in an Album

1 **Picture Album list (P211)/i-motion Album list (P211) ▶ Select an Album**



File list in a Picture Album

File list in an i-motion Album

2 **Select a file ▶ ●**

■ Icons displayed on the file list in an album

Icon	Description
$★$	Files saved on the handset
$★$	Files saved on the memory card
$★$	Select a file to save in an Album.

Function Menu on the File List of an Album

1 **File list in an i-motion Album (P211)/File list in an i-motion Album (P211) ▶ [Function] ▶ Perform the following operations**

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

View
Display the selected image.

Replay
Plays the selected i-motion movie.

Edit Picture
Edit the selected image. →P207

Edit
Edit the selected i-motion movie. →P210

Create New
Start the Camera/Video Camera.

▶ "Pictures"/"Video Camera"

Sort by
Change the saving destination of the selected file. (Checking the specifications)

All : Save the file to both the handset and memory card.

Phone Memory : Save the file to the handset.

Memory Card : Save the file to the memory card.

Send
In Email : Create i-mode mail with the file attached. Go to Step 2 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send one file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the selected file as Wallpaper or Screen Saver.

Wallpaper : Set as Wallpaper.

Screen Saver : Set as the Screen Saver.

Incoming Call Alert : Set as a ringtone.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Camera Off Image : Set the file as the alternate image for video calls.

Alarms : Set as an alarm tone.

Manage
Delete or sort the selected file.

Remove : Delete files.

Reorder : Rearrange files. Select a file ▶ [Move] ▶ Select a destination ▶ Press [Insert].

Select Multiple to
Add More Pictures : Select a file to save in an Album.

Add i-motion : Select a file to save in an Album.

Remove : Select and delete more than one file. Select a file to delete ▶ Press ● ▶ [Complete] ▶ $★$ [Yes].

Details
Display the file size and file format, etc. of the selected file.

▶ Scroll with ▶ [Function]

Restrict File : Restrict the file.

Copy All Text : Copy the file information.

Pictures Setup
Set the display method of the selected file. →P206

i-motion Setup
Set the playback method of the selected file. →P210

- Items displayed on the function menu vary depending on the selected files and settings on the handset.

Chara-den

What is Chara-den?

Chara-den is an animation character representing you (an avatar) that can be sent to the other party as an alternate image instead of your own image during a video call.

■ **Chara-den registered by default**

DJ

ブンブン (Dimo)
©BVIG

■ **Pre-installed Chara-den**

Key	DJ	Dimo
1	Happy (Laugh)	Sadness
2	Angry	Anger
3	Cry (Sad)	Surprise
4	Shock (Surprise)	In love
5	Thank you	Let's eat
6	I'm sorry	Sorry
7	Bye bye	Sleep
8	Yes (OK)	Lonely
9	No (No way)	Hot spring

Displaying/Controlling Chara-den

1 **● ▶ $★$ (Databox) ▶ "Chara-den"**



Chara-den screen

2 **Select a folder ▶ ●**

Chara-den list

3 **Select Chara-den ▶ ●**

- ◎: Display the previous/next file
- ⊙: Enlarge the image/Restore the original size

Screen to be inserted

Chara-den playback screen

Function Menu on the Chara-den List

1 **Chara-den list (P213) ▶ Select a Chara-den ▶ [ch] [Function] ▶ Perform the following operations**

Now Playing/Hide

Show or hide the Playback screen for the melody played in background. →P216

Play

Play the selected Chara-den.

Apply As

Set the selected Chara-den as the alternate image for the videocall or to a Contact.

Camera Off Image : Set as the alternate image for the videocall.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Manage

Rename or delete the selected Chara-den.

Edit title : Change the name of the Chara-den.

Remove : Delete the selected Chara-den.

Select Multiple to

Select and delete more than one Chara-den. Select Chara-den to delete ▶ Press ● ▶ [i] [Complete] ▶ $★$

Details

Display the file size and file format, etc. of the selected Chara-den.

▶ Scroll with ⊙ ▶ [ch] [Function]

Restrict File : Apply the restriction to files.

Copy All Text : Copy the file information.

Function Menu on the Chara-den Playback Screen

1 **Chara-den playback screen (P213) ▶ [ch] [Function] ▶ Perform the following operations**

Continued on the next page ●●•

Enter V-Phone No.

Make a video call using the Chara-den in playback as the alternate image.

Enter Number : Make a call by entering a phone number directly. →P80

Phonebook : Make a call by searching the phonebook. →P97

Received Calls : Make a call by searching through Received Calls. →P67

Dialed Calls : Make a call by searching through Dialed Calls. →P56

Set Chara-den

Set the selected Chara-den as the alternate image for video calls.

Detail Info

Display the file size and file format, etc. of the Chara-den in playback.

- [Function]: Copy the content of the detailed information screen. Select "Copy All Text".

Delete

Delete the Chara-den in playback.

Change Size

Change the display size of the Chara-den in playback. (Checking the specifications)

- : Enlarge the image/Restore the original size

Chara-den Function

"Change Action"

Switches the character action mode.

Partial Action Mode : The character uses a part of the body to express actions.

Full Action Mode : The character uses the whole body to express actions.

"Action List"

Lists all actions assigned to operation keys.

- Select an action ▶ Press [Select] to make the character show the selected action.

Melody Player

Playing Melodies

You can play pre-installed melodies or melodies downloaded from sites.

■ Available File Formats

File Format*	SMF, MFi
File Extension	mid, mld, midi

*: Even a file in a compatible file format may not play depending on the file.

1 ● ▶ $★$ (Databox) ▶ "Melody"

Melody screen

2 Select a folder ▶ ●

Melody file list

3 Select a file ▶ ●

Melody playback screen

■ Operations on the Melody playback screen

Button/Key	Description
●	Pause/Play
◀▶	Play the previous/next file
▲/▼	Adjust the volume

■ Playing a melody with the FOMA handset folded(Checking the specifications)

If you fold the FOMA handset during melody playback, the artist name and song title are displayed on the Sub-display.

■ Sub-display



Melody playback screen **Song title list**

■ Key operation on the Melody playback screen

Key	Description
▪	Open the Song title list
▪ (press for X second or longer)	Stop melody playback
▲/▼	Adjust the volume

■ Key operation on the Song title list

- The Song title list returns to the Melody playback screen after five seconds.

Key	Description
▪	Pause/Play
▪ (press for X second or longer)	Stop melody playback
▲/▼	Adjust the volume
▲/▼	Display the previous/ next song title in the list

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

Function Menu on the Melody Screen

1 Melody screen (P214) ➧ [Function] ➧ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Melody Setup
Set the playback method and sound quality of the melodies in the selected folder. →P216

Function Menu on the Melody File List

1 Melody file list (P214) ➧ Select a file ➧ [Function] ➧ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Play
Play the selected melody.

Add To Playlist
Add the selected file to a Playlist.

Filter by
Change the saving destination of the selected melody. (Checking the specifications)

All : Save the file to both the handset and memory card.

Phone Memory : Save the file to the handset.

microSD : Save the file to the memory card.

Send
In Email : Create i-mode mail with the file attached. Go to Step 3 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send 1 file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the selected melody as a ring tone or to a Contact.

Incoming Call Alert : Set as a ringtone.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Alarm : Set as an alarm tone.

Manage
Rename, delete, move or copy the selected melody.

Edit title : Change the title of the selected melody.

Remove : Delete the selected melody.

Move : Move the selected melody to the handset or the memory card.

Copy : Copy the selected melody to the handset or the memory card.

Select Multiple to
Add to Playlist : Select more than 1 melody and add to a Playlist.

Delete : Select and delete more than 1 melody. Select melodies to delete ➧ Press ● ➧ [Complete] ➧ $★$ [Yes].

Move : Select and move more than 1 melody to another folder. Select melodies to move ➧ ● ➧ [Complete] ➧ Select a destination folder ➧ Press [Select].

Copy : Select and copy more than 1 melody to another folder. Select melodies to copy ➧ ● ➧ [Execute] ➧ Select a copying destination folder ➧ Press [Select].

Details
Display the name and size, etc. of the selected melody.

➧ Scroll with ➧ [Function]

Restrict File : Apply the restriction to files.

Copy All Text : Copy the file information.

Melody Setup
Set the playback method and sound quality of the selected melody. →P216

Function Menu on the Melody Playback Screen

1 Melody playback screen (P214) ➧ [Function] ➧ Perform the following operations

Add To Playlist
Add the melody in playback to a Playlist.

Send
In Email : Create i-mode mail with the file attached. Go to Step 3 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send 1 file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the melody in playback as the alternate image or to a Contact.

Incoming Call Alert : Set as a ringtone.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Continued on the next page

Manage
Reorder, delete, move or copy the melody in playback.

Reorder : Rearrange melodies. Select a melody ➧ [Move] ➧ Select a destination ➧ Press [Insert] ➧ [Complete].

Delete : Delete the melody in playback.

Move : Move the melody in playback to the handset or the memory card.

Copy : Copy the melody in playback to the handset or the memory card.

Remove : (Checking the specifications)

File Details
Display the name and size, etc. of the melody in playback.

➧ **Scroll with ➧ [Function]**

Restrict File : Apply the restriction to files.

Copy All Text : Copy the file information.

Melody Setup
Set the playback method and sound quality of the melody in playback. →P216

Hide
Return to the stand-by display. (Checking the specifications)

Using Another Function while Playing a Melody

You can call up and use another option while playing a melody.

■ Functions available during the background playback (Checking the specifications)

Function	

1 Melody playback screen (P214) ➧ [Function] ➧ "Hide"

Close the Melody playback screen and display the stand-by display. The melody in playback is played in background.

■ To return to the melody playback screen
You can display the Melody playback screen from the function menu of each screen.
- [Function] ➧ Select "Now Playing"

Setting the Playback Method and Sound Quality of Melodies

Default	Auto Repeat: Off Equalizer: On Spatial Audio: (Checking the specifications) Bass Boost: (Checking the specifications)

Set the playback method and sound quality of the melody.

1 Melody screen (P214)/Melody file list (P214)/Melody playback screen (P214) ➧ [Function] ➧ "Melody Setup"

Melody Setup screen

2 Select from the following items ➧ [Change]

Auto Repeat
(Checking the specifications)

➧ **"On"/"Off" ➧ [Select]**

Equalizer
➧ **"On"/"Off" ➧ [Select]**

Spatial Audio
➧ **"On"/"Off" ➧ [Select]**

Bass Boost
➧ **"On"/"Off" ➧ [Select]**

Playlist

Creating a Playlist

You can create a Playlist for your favorite melodies.

1 Melody screen (P214) ➧ "Playlists"

Playlist screen

❶ **Most Played**
Files played many times (●●files) are automatically saved in the Playlist.

 * You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

❷ **User-defined Playlists**
The created Playlist name is displayed.
❸ **Create New Playlist**
Create a new Playlist.

2 **"[Create New Playlist]" ▶ ●**

3 **Select a folder ▶ [Open]**

4 **Select a melody to save in the Playlist**

- Select [Function] ▶ "Select All" to select all melodies in the folder at once.

Add melody screen

5 **[Complete] ▶ Enter a Playlist name**

Function Menu on the Playlist Screen

1 **Playlist (P216) ▶ [Function] ▶ Perform the following operations**

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Play
Play a melody.

Create New
Creates a new Playlist.

Manage
Delete or rename Playlists.

Rename : Change the title of the selected Playlist.

Delete : Deletes the selected Playlist.

Melody Setup
Set the playback method and sound quality of the melody in playback. →P216

Editing Playlists

You can change the content of the created Playlists by deleting or adding melodies.

Adding Melodies

1 **Playlist screen (P216) ▶ Select a Playlist ▶ ●**

Playlist list

2 **"Add More Melodies" ▶ ●**

3 **Select a melody ▶ ●**

- Select [Function] ▶ "Select All" to select all melodies in the folder at once.

4 **[Complete]**

Deleting Melodies

1 **Playlist list (P216) ▶ Select a Playlist ▶ ●**

2 **Select a melody ▶ [Function] ▶ "Manage" ▶ "Delete"**

■ **To select and delete more than one melody**
Press [Function] and go to Step 3 in "Selecting and Deleting Multiple Files".

Function Menu on the Playlist List

1 **Playlist list (P217) ▶ Select a Playlist ▶ ● ▶ Perform the following operations**

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Play
Play a melody.

Filter by
Change the saving destination of the selected melody. (Checking the specifications)

▶ **"Storage Location"**

All : Save the file to both the handset and memory card.

Phone Memory : Save the file to the handset.

microSD : Save the file to the memory card.

Continued on the next page ●●●

Send

In Email : Create i-mode mail with the file attached. Go to Step 3 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send 1 file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As

Set the selected melody as the ringtone or alarm tone.

Incoming Call Alert : Set as a ringtone.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Alarm : Set as an alarm tone.

Manage

Reorder or delete melodies in a Playlist.

Reorder : Reorder the selected melody. Select a file ▶ [Move] ▶ Select a destination ▶ Press [Insert].

Remove : Delete the selected melody.

Select Multiple to

Add More Melodies : Select more than 1 melody and add to a Playlist.

Remove : Select and delete more than 1 melody. Select melodies to delete ▶ Press ▶ [Complete] ▶ $★$ [Yes].

Details

Display the file name, size and author, etc. of the selected file.

▶ **Scroll with ▶ [Function]**

File Restrictions : Apply the restriction to files.

Copy All Text : Copy the file information.

Melody Setup

Set the playback method and sound quality of the selected melody. →P216

Voice Notes

Using Voice Notes

You can save and manage Voice Notes on the handset.

Recording Voice Notes

1 **● ▶ $★$ (Databox) ▶ "Voice Notes"**

Voice Notes screen

2 **[Function] ▶ "Create New" ▶ "Voice Note"**

Screen to be inserted

Voice Note Ready screen

3 **●**

Recording starts. The recording time is 30 seconds.

- ●: Pause/resume the recording.
- [Stop]: Cancel the recording.

4 **After recording ▶ [Store]**

- When "Auto Save" is set to "On", the recording is saved automatically. →P219

Screen to be inserted

Voice Note recording completion screen

■ **Recording Voice Notes with the FOMA handset closed**

Hold down to keep recording a Voice Note. Release to end recording.

Note

- The recorded Voice Memo is saved with the recorded time and date as a file name as "XX-XX-XX.amr". (Checking the specifications)

Function Menu on the Voice Note Screen

1 **Voice Note screen (P218) ▶ [Select] ▶ Perform the following operations**

Now Playing/Hide

Show or hide the Playback screen for the melody played in background. →P216

Create New

Start recording. →P216

Function Menu on the Voice Note Ready Screen

1 **Voice Note ready screen (P218) ▶ [Function] ▶ Perform the following operations**

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

Go To Voice Notes
Open the Voice Note list.

Switch Storage Device
Set the saving destination for Voice Notes.

▶ **"microSD"/"Phone Memory"**

Voice Recorder Setup
Set the recording quality or time, etc.

Record Quality: Sets the recording quality. Select from "Good"/"Better"/"Best".

Record Length: Set the recording time. Select from "MMS"/"Maximum" (30 seconds).

Auto Save : Set whether to save the recorded Voice Notes automatically. Select from "On"/"Off".

Free Space
Display the storage space status of the Voice Notes folder.

Function Menu on the Voice Note Recording Completion Screen

1 Voice Note recording completion screen (P218) ▶ [Function] ▶ Perform the following operations

Discard
Delete recorded Voice Notes.

Preview
Play recorded Voice Notes.

Re-Record
Record again.

Apply as Ringtone
Set the recorded Voice Note for use as a Ring Tone.

Playing Recorded Voice Notes

The Voice Note screen has the following components:



Voice Notes screen

❶ **Voice Notes (All)**
All recorded Voice Notes are listed.

❷ **My Notes**
Recorded Voice Notes are displayed per category.

1 Voice Note screen (P219) ▶ Select "Voice Notes (All)"/"My Notes"

■ **When selecting Voice Notes (All)**
Select the voice note to play and press ●.

Voice Notes (All) list screen

■ **When selecting My Data**
Select "Category" ▶Press ● ▶ Select the voice note ▶Press ●.

Category list screen

Function Menu on the Voice Notes (All) List

1 Voice Notes (All) list (P219) ▶ Select a file ▶ [Function] ▶ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Play
Play the selected Voice Note.

Add to Category
Add the selected Voice Note to a category.

Create New
Record a Voice Note.

Filter by
Change the saving destination of the selected file. (Checking the specifications)

▶ **"Storage Location"**

All : Save the file to both the handset and memory card.

Phone Memory : Save the file to the handset.

microSD : Save the file to the memory card.

Send
In Email : Create i-mode mail with the Voice Note attached. Go to Step 3 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send one file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the selected Voice Note as the alternate image or to a Contact.

Incoming Call Alert : Set as a ringtone.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Alarm : Set as an alarm tone.

Manage
Rename, delete, move or copy the selected Voice Note.

Rename : Change the title of the selected Voice Note.

Delete : Delete the selected Voice Note.

Move : Move the selected Voice Note to the handset or the memory card.

Copy : Copy the selected Voice Note to the handset or the memory card.

Select Multiple to

Add to Category : Select and add more than one Voice Note to a category.

Delete : Select and delete more than one Voice Note. Select a Voice Note to delete ▶ Press ● ▶ [Complete] ▶ $★$ [Yes].

Move : Select and move more than one Voice Note to another folder. Select a Voice Memo to move ▶ ● ▶ [Complete] ▶ Select a destination folder ▶ Press [Select].

Copy : Select and copy more than one Voice Note to another folder. Select a Voice Memo to copy ▶ ● ▶ [Complete] ▶ Select a destination folder ▶ Press [Select].

Details
Display the name and size, etc. of the selected Voice Note.

▶ **Scroll with ▶ [Function]**

Restrict File : Apply the restriction to files.

Copy All Text : Copy the file information.

Function Menu on the Category List

1 Category list (P219) ▶ Select a file ▶ [Function] ▶ Perform the following operations

Now Playing/Hide
Show or hide the Playback screen for the melody played in background. →P216

Play
Play the selected Voice Note.

Create New
Record a Voice Note. →P218

Filter by
Change the saving destination of the selected file. (Checking the specifications)

▶ **"Storage Location"**

All : Save the file to both the handset and memory card.

Phone Memory : Save the file to the handset.

microSD : Save the file to the memory card.

Send

In Email : Create i-mode mail with the Voice Note attached. Go to Step 3 in "Creating and Sending i-mode Mail" (P172).

to IrDA : Send one file using Infrared communication.

to Bluetooth : Send via Bluetooth. Go to Step 2 in "Registering and Connecting a Bluetooth Device" (P239).

Apply As
Set the selected Voice Note as the alternate image or to a Contact.

Ring Tone : Set as a ringtone.

Phonebook Entry : Set to a Contact. Go to Step 2 in "Saving Contacts to the Phonebook from Received Calls or Dialed Calls" (P94).

Alarm : Set as an alarm tone.

Manage
Delete the selected Voice Note.

▶ **"Delete"**

Select Multiple to

Add More Voice Notes : Select and add more than one Voice Note to a category.

Delete : Select and delete more than one Voice Note. Select a Voice Note to delete ▶ Press ● ▶ [Complete] ▶ $★$ [Yes].

Details
Display the name and size, etc. of the selected Voice Note.

▶ **Scroll with ▶ [Function]**

Restrict File : Apply the restriction to files.

Copy All Text : Copy the file information.

Saving Voice Notes to My Data

You can manage recorded Voice Notes by saving them per category.

1 Voice Note screen (P219) ▶ "My Notes"

My Notes screen

2 Select "Create New Category" ▶ a folder

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

3 **Select a Voice Note ▶ ●**

- Select [Function] ▶ "Select All" to select all Voice Notes in the folder at once.

4 **[Complete] ▶ Enter a Category name**

Function Menu on the My Data Screen

1 **My Data screen (P220) ▶ [Function] ▶ Perform the following operations**

Now Playing/Hide

Show or hide the Playback screen for the melody played in background. →P216

Create New

Voice Note : Start recording. →P218

Category : Create a new Category. →P220

Manage

Rename or delete the selected Category.

Edit title : Edit the title name. Enter a title ▶ Press ●.

Delete : Delete a Category.

microSD Memory Cards

You can insert a microSD memory card into the handset and use it as external storage. A microSD memory card is a small size and lightweight, removable external storage media with a large capacity.

- You can purchase microSD memory cards and microSD memory card adapters from electric appliance mass sales stores, etc. The M702iG handset supports microSD memory cards up to ●●● Mbytes. (As of ●●, 2006)

Cautions on Using MicroSD Memory Cards

- microSD memory cards formatted by another device such as a PC may not be usable on the handset. Use memory cards formatted by the M702iG handset. →P222
- Memory cards may lose data or deform due to an accident or failure of the handset. It is recommended that you make a copy of important data and keep it in a separate place. DoCoMo is not responsible for loss or alteration of data.
- Do not turn the handset power off while data is being read or written.
- Do not apply labels or stickers on memory cards. Even the thickness of labels may cause loose contacts and data corruption.
- Do not touch the contacts with your hand or metal object.
- Do not apply strong force, do not bend or drop, and do not let the card become wet.
- Do not use or store the card in the following places:
  - In extremely high temperatures such as inside a very hot car or under scorching heat
  - In direct sunlight
  - In an environment with high humidity or corrosive substances
  - In a place where it can be affected by static electricity or electrical noise

Inserting/Removing a Memory Card

Remove the battery rear cover and the battery pack first. →P44

Inserting

Illustration to be inserted

Illustration to be inserted

Removing

Illustration to be inserted

Structure of Folders on the Memory Card

(Checking the specifications)

Using a Memory Card

(Checking the specifications)

Formatting a Memory Card

(Checking the specifications)
Format (initialize) a memory card so that it can be used for the FOMA handset.

1 Databox screen (P204) ➧ [Function] ➧ "Format Memory Card"

Moving/Copying Files between a Memory Card and the Handset

(Checking the specifications)

Reading and Writing to a Memory Card

Connect the FOMA handset with a memory card inserted to a PC and read data from/write data to the memory card.

To use a memory card, you need an optional memory card.

1 ● ➧ $★$ (Connection) ➧ $★$ (USB Mode Setting) ➧ "Default Connection" ➧ [Change] ➧ "microSD mode"

USB Mode Setup screen

2 Connect the handset and a PC using a USB cable (optional)

Setting the USB Mode

Set the USB mode when the FOMA handset and a PC are connected using a USB cable (optional). The USB mode is set to either "Data Connection" or "microSD mode".

■ Data/Fax Connection
Use the external connector terminal to transfer data via the cable connection.

Illustration to be inserted

* You need to obtain a microSD memory card separately to use the functions related to the microSD memory card. →P221

■ **Memory Card Mode**

Use the external connector terminal as a means of reading from/writing to the memory card.

Illustration to be inserted

1 **USB Mode Setup screen (P222) ▶ "Default Connection" ▶ [Change]**

2 **"microSD mode"/"Data Connection"**

■ **Notice**

Verify that the handset is correctly connected to a PC. If it is not connected correctly, data may not only fail to be exchanged but also may be lost.

Infrared Communication

Infrared Communication

You can exchange Contacts, Datebook events or Bookmarks with a device equipped with infrared communication capabilities.

Available Data for Data Transfer

(Checking the specifications)

	One	All
Contact		Up to ●●
Still Image File		Up to ●●
ToDo		Up to ●●
Datebook Event		Up to ●●
Memo (Checking the specifications)		Up to ●●
Bookmark		Up to ●●

■ **Notice**

Stored content may be lost due to the handset failure, repair or mishandling. DoCoMo is not responsible for lost data. It is recommended that you keep saved content from the FOMA handset on a microSD memory card. You can connect the handset to a PC using data link software and a FOMA USB cable (optional) and save the data to the PC.

Infrared Communication

To perform infrared communication

- When performing infrared communication, open the FOMA handset 90 degrees as shown below.
- Use the devices within 20 cm. However, if you place devices on a table, use the devices within 14 cm.
- Do not move the FOMA handset until data exchange completes.
- If you hold the FOMA handset in your hand, secure the terminal so that it is not shaky.



Cautions on Data Transfer

- Data may not be transferred depending on the other party's FOMA handset conditions. Depending on the other party's model, the filter setting of received mail or Bookmarks may not be reflected or the content of Deco-mail may not be saved correctly.
- Communication may take a while depending on the amount of data to be transferred. Also, it is possible that data may not be received correctly.

Ir data/IrDA link

Exchanging Data One Piece at a Time

Sending Data One Piece at a Time

1 **Data list ▶ [Function] ▶ "Send" ▶ "to IrDA"/"Infrared"**

Receiving Data One Piece at a Time

1 **◉▶$★$ (Connection) ▶ $★$ (Infrared Link) ▶ [ch] [Yes]**

Display preview of received data.

2 **Save data**

■ **When a Contact is received**
Press [ch] [Store].

■ **When a Calendar event is received**
Press [ch] [Function] ▶ [ch] [Store].

■ **When an image is received**
Press [ch] [Function] ▶ [ch] [Store Only].

Screen to be inserted

Received image preview screen

Function menu on the received image preview screen

1 **Received image preview screen (P224) ▶ [ch] [Function] ▶ Perform the following operations**

Send in Message
Create i-mode mail with the image attached. →P172

Store Only
Save the image.

Apply as Wallpaper
Set as Wallpaper.

Apply as the Screen Saver
Set as the Screen Saver.

Apply as "Camera Off" Image
Set the file as the alternate image for video calls.

Print and Store
(Checking the specifications)

Send All/Receive All

Exchanging All Data

You can transfer all data at once with a PC or another FOMA handset.

- To exchange all data, a password is used to identify the sender and receiver correctly. The password is any 6-digit number and should be entered both in the sending and receiving devices before sending/receiving data.
- Receiving all data overwrites the data on the FOMA handset and deletes all saved data including protected Email. Check whether important data has been saved elsewhere before sending or receiving all data.

Sending All Data

1 **From a screen showing data to be sent ▶ [ch] [Function] ▶ "Send All"**

2 **Enter the security code ▶ "Infrared"▶ Enter the authentication password**

Receiving All Data

1 **◉▶$★$ (Connection) ▶ $★$ (Infrared Link)**

2 **Enter the security code ▶ Enter the authentication password ▶ [ch] [Yes]**

3 **[ch] [Yes]**

Screen to be inserted

Overwrite data confirmation screen