90X135MM

正面

FLAME ATMOSPHERE BLUETOOTH SPEAKER

MANUAL DE USUARIO

BTS-596

Estimado cliente,

¡Gracias por comprar nuestro producto!

Por favor amablemente lea este manual del usuario antes de utilizar el producto cuidadosamente y consérvelo para futuras consultas.

Para empezar

Quite el altavoz de la caja.

Por favor guarde todo el embalaje hasta que haya comprobado y contado todas las partes y el contenido con la lista de piezas.

Contenido del paquete

1. Altavoz Bluetooth: x 1
2. Micro USB Cable de carga: x 1
3. Manual de usuario: x 1

Instrucciones de seguridad

1. por favor lea estas instrucciones antes de usar el producto.
2. no inserte cualquier objeto de metal en el dispositivo.
3. para evitar una carga estática, no utilice el dispositivo en un clima extremadamente seco.
4. no intente abrir o reparar el dispositivo usted mismo.
5. evitar golpes fuertes al producto y no dejarlo caer.

Descripción de partes

1	Energía/Play/Pause/FM Radio
2	Saltar hacia atrás/volumen disminución o la última estación - botón
3	Aumento de Skip Forward/volumen/botón + próxima estación
4	Botón de la luz
5	Ranura para tarjeta micro SD (TF)
6	Puerto de carga

INSTRUCCIONES DE USO

El altavoz de carga

Para mejores resultados, cargue completamente el altavoz antes de su primer uso.

1. Conecte el cable de carga USB (incluido) al puerto de carga del altavoz del 5V DC e Inserte el otro extremo en un puerto en tu computadora o tu cargador de móvil o similar fuente de energía.
2. LED rojo se ilumina indicando que la batería se está cargando. Una vez que esté completamente cargada, el LED rojo se apagará.
3. Una vez que el orador se recarga completamente, desconecte el Cable USB y cierre firmemente la tapa de goma, para cubrir el puerto de carga USB seguro. Si el puerto de carga USB no está bien cubierto, el agua puede tener fugas en el circuito de la electrónica y puede dañar la unidad. Este daño no cubrirá la garantía del producto.

Función de Radio FM

1. Prensa doble cambio de botón de "Power" en FM Auto scan estación, doble Pulse "Power" el botón otra vez cambio a la función Bluetooth
2. Presione el botón de la última estación
3. Pulse el botón + por emisora

(Nota: existe una antena FM interna dentro de la unidad; sin embargo, conectar el cable de carga para el puerto de carga puede mejorar la recepción FM.)

Luz de la llama LED potencia

4. Pulse brevemente el botón luz para activar el cuadro de LED
5. Pulse botón de la luz, ganancia, para desactivar el marco de LED

Activar o desactivar el altavoz

Presione y mantenga presionado el botón de encendido durante 2-3 segundos hasta que oiga el tono de indicación. Luz LED blanco luz de botón transparente, su altavoz ahora está encendido y está entrando en modo "sincronización". Presione y mantenga presionado el botón de encendido durante 2-3 segundos apagar el altavoz.

Emparejar el dispositivo con Bluetooth altavoz –

Altavoces Bluetooth inalámbrica puede transmitir el audio de cualquier dispositivo habilitado para Bluetooth dentro de la distancia de 10m. Simplemente siga los pasos siguientes.

Cuando la unidad está apagado, presione y sostenga el botón de encendido durante 2-3 segundos hasta que oiga el tono de indicación.

Luz LED blanco luz de botón transparente, su altavoz ahora está encendido y está entrando en modo "sincronización".

Activar el Bluetooth en tu teléfono móvil o Tablet u ordenador.

Buscará por varios dispositivos.

La sincronización de nuestro altavoz Bluetooth llamo "BT-350", vincular con este dispositivo.

Si es necesario, introduzca la contraseña '0000' para confirmar para finalizar la sincronización.

Una vez emparejado con éxito, escuchará otro tono de indicación, estancias de luz led blancas en.

Si no par dentro del tiempo o desea sincronizarlo con un dispositivo nuevo por favor, sigue los pasos descritos anteriormente.

Selecciona tu canción favorita en el dispositivo Bluetooth y música ahora corriente a través del altavoz de Bluetooth.

(Nota: altavoz automáticamente pares con los dispositivos anteriormente vinculados)

Escuchar música de forma inalámbrica

Por favor asegúrese que su dispositivo (iPhone, tableta o teléfono inteligente otros) se empareja con el altavoz Bluetooth para transmitir música de forma inalámbrica. Una vez que se empareja, reproducir música desde su dispositivo.

Función	Operación	Botón
Aumentar el volumen	Reproducción de música + fm radio	Presione y mantenga presionado el botón + para aumentar el volumen/la prensa una vez a la siguiente estación de fm
Disminuir el volumen	Reproducción de música + fm radio	Presione y mantenga presionado el botón - para disminuir el volumen/la prensa una vez a la última emisora de fm
Pausa	Reproducción de música	Pulse brevemente el botón de encendido se pone en pausa la música
Juego	Haciendo una pausa	Pulse brevemente el botón de encendido reanudará la música
Pista anterior	Reproducción de música	Pulsación corta - botón volverá de nuevo a la pista anterior
Pista siguiente	Reproducción de música	Pulsación corta el + botón te llevará a la siguiente pista

TWS maridaje –

Asegúrese de que dos altavoces Bluetooth ahora son "ON" y sin con cualquier dispositivo habilitado para Bluetooth, doble prensa "+" o "-" botón en cualquiera de los dos altavoces Bluetooth, el altavoz estará automáticamente combinarse durante 7-8 segundos, una vez emparejado con éxito, usted escuchará un tono de indicación.

Activar la función Bluetooth en su dispositivo fuente (teléfono móvil o Tablet). Por favor, consulte las instrucciones del fabricante para obtener instrucciones sobre la habilitación de Bluetooth en su dispositivo.

Búsqueda de dispositivos Bluetooth disponibles y se encontraría "BT-350" – enlazarlo con este dispositivo.

Si es necesario, escriba la contraseña "0000" a la par con el dispositivo.

Una vez emparejado con éxito, escuchará otro tono de indicación, puede ahora transmitir música inalámbrica por los altavoces a través de su dispositivo fuente.

Escuchar música desde la tarjeta Micro SD (TF)

1. Encienda el altavoz.
2. Inserte la tarjeta Micro SD (TF) precargada con canciones, en la ranura para tarjetas Micro SD (TF). Altavoz automáticamente empezar tocando canciones desde la Micro SD (TF) tarjeta de Nota: tarjeta Micro SD no incluida.
3. A Skip Track Forward – Pulse brevemente el botón +.
4. A Skip Track hacia atrás, pulse brevemente el botón.
5. Para pausar la pista-Pulse brevemente el botón de encendido.
6. Para reproducir la pista, pulse brevemente el botón de encendido.
7. Presione + para aumentar el volumen o - para disminuirlo.

ESPECIFICACIONES TÉCNICAS

Bluetooth® versión: V 4.2

Distancia de funcionamiento: hasta 10 metros en espacio abierto

Rango de frecuencia: 2.4-2.48 Ghz

Salida de altavoz: 1 x 3 W

Respuesta de frecuencia: 80 Hz – 20 Khz

Carga de alimentación: DC 5 V puerto de carga: (micro USB)

Tiempo de carga: aproximadamente 4 horas

Tiempo de reproducción: aprox. 4-5 horas LED: 96 PC

Batería recargable incorporada: 3.7V / 1200mAh

Tamaño de la unidad: longitud 179.2 x diámetro 100mm unidad de peso: 340 g aprox.

Nota: Duración de la batería y tiempo de carga pueden variar, basado en el uso y tipos de dispositivos utilizados.

El diseño del producto y las especificaciones pueden cambiar tema de sin previo

¡Aviso!

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the
receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help
Changes or modifications not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may
cause undesired operation.

反面

FLAME ATMOSPHERE BLUETOOTH SPEAKER

USER MANUAL

BTS-596

Dear Customer,

Thanks for purchasing our product!

Please kindly read this user manual before using the product carefully, and keep it for future reference.

Getting Started

Remove the speaker from the box.

Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

1. Bluetooth Speaker: x 1
2. Micro USB Charging Cable: x 1
3. User Manual: x 1

Safety Instructions

1. Please read these instructions before using the product.
2. Do not insert any metal object into the device.
3. To avoid a static charge, do not use the device in an extremely dry climate.
4. Do not attempt to open or repair the device by yourself.
5. Avoid heavy shocks to the product and do not drop it.

DESCRIPTION OF PARTS

1	Power /Play/Pause/FM Radio
2	Skip Backward/Volume Decrease/last station - Button
3	Skip Forward/Volume Increase/next station + Button
4	Light button
5	Micro SD (TF) Card Slot
6	Charging Port

INSTRUCTIONS FOR USE

Charging the speaker

For best results, fully charge the speaker before its first use.

1. Connect the USB charging cord (included) to the DC 5V charging port of the speaker and insert the other end into a port on your computer or your mobile charger or similar power source.
2. Red LED glows indicating that the battery is being charged. Once it is fully charged, the Red LED will turn off.
3. Once the speaker is fully recharged, disconnect the USB Cable and firmly close the Rubber Flap, to cover the USB Charging Port secure. If the USB charging port is not securely covered, water may leak into the electronics circuit and may damage the unit. This damage will NOT be covered under product warranty.

FM Radio Function

1. Double press "Power" button shift to FM Auto scan station, double press "Power" button again shift to Bluetooth function
2. Press the - button for last station
3. Press the + button for next station

(Note: There is an internal FM antenna inside the unit; however, connecting the charge cable to the charge port can improve FM reception.)

LED Flame light POWER

4. Short press light button to turn on the LED frame
5. Short press light button, gain, to turn off the LED frame

Turn On/Off the Speaker

Press and hold the POWER button for 2-3 seconds until you hear the indication tone. White LED light of transparent button will blink, your speaker is now ON and is entering "pairing" mode. Press and hold the POWER button for 2-3 seconds to turn off the speaker.

Pairing your device with Bluetooth Speaker –

Your **Bluetooth Speaker** can wirelessly stream audio from any Bluetooth enabled device within the distance of 10m. Simply follow the below steps.

1. When the unit is OFF, press and hold the POWER button for 2-3 seconds until you hear the indication tone.
2. White LED light of transparent button will blink, your speaker is now ON and is entering "pairing" mode.
3. Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.
4. It will search for various devices.
5. The pairing name of our Bluetooth Speaker is "**BT-350**", pair it with this device.
6. If required, enter the password '0000' to confirm to finalize pairing.
7. Once paired successfully, you would hear another indication tone, white led light stays on.
8. If you fail to pair it within the time or you want to pair it with a new device please follows the steps outlined above.

Select your favorite song at the Bluetooth device and music would now stream through Bluetooth speaker.

(Note: Speaker automatically pairs with the previously paired devices)

Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Increase Volume	Playing music+fm radio	Press and hold the + button to increase the volume/press one time to next fm station
Decrease Volume	Playing music+fm radio	Press and hold the - button to decrease the volume/press one time to last fm station
Pause	Playing music	Short press the Power button will pause the music
Play	Pausing	Short press the Power button will resume the music
Previous track	Playing music	Short press - button will return you to the previous track
Next track	Playing music	Short press the + button will take you to the next track

TWS Pairing –

1. Make sure two Bluetooth speakers are now "ON" and without paired with any Bluetooth enabled device, double press"+" or "-" button on any one of those two Bluetooth speakers, then the speaker will be automatically matched for 7-8 seconds, once paired successfully, you will hear an indication tone.
2. Activate the Bluetooth function on your source device (Mobile Phone or Tablet). Please refer to manufacturer's instructions for instructions on enabling Bluetooth on your device.
3. Search for available Bluetooth devices and you would find "BT-350" – Pair it with this device.
4. If required, enter the password "0000" to pair with the device.
5. Once paired successfully, you will hear another indication tone,
6. You can now stream wireless music on your speaker through your source device.

Stream music from Micro SD (TF) Card –

1. Turn ON the speaker.
2. Insert the Micro SD (TF) Card preloaded with songs, into the Micro SD (TF) Card Slot. Speaker would automatically start playing songs from the Micro SD (TF) Card

   Note: Micro SD Card not included.
3. To Skip Track Forward – Short press the + button.
4. To Skip Track Backwards – Short press the - button.
5. To Pause the Track – Short press the POWER button.
6. To Play the Track – Short press the POWER button.
7. Long press + to increase the volume or - to decrease the volume.

TECHNICAL SPECIFICATIONS

Bluetooth® version	: V 4.2
Working distance	: Up to 10 meters in open space
Frequency range	: 2.4 - 2.48 Ghz
Speaker Output	: 1 x 3 W
Frequency response	: 80 Hz – 20 Khz
Charging input power	: DC 5 V
Charging Port	: (micro USB)
Charging time	: about 4 hours
Playback time	: Approx. 4-5 hours
LED	: 96 Pcs
Built-In Rechargeable Battery	: 3.7V / 1200mAh
Unit size	: Length 179.2 x Diameter 100mm
Unit weight	: approx. 340 g

Note: Battery life & charging time may vary, based on usage & types of devices used.

The product design and specifications may be changed subject of without prior

notice!

NOTE: This equipment has been tested and found to comply with the limits for a
Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no
guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which
can be determined by turning the equipment off and on, the user is encouraged to
try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the
receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help
Changes or modifications not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may
cause undesired operation.