IMPORTANT NOTE: READ THIS FIRST!

When activating the on-line function of the XB-Comm you must be within 1~2 meters (roughly 3~6 ft.) of your console to ensure a strong signal. Press and hold the on-line button for 3 seconds (the LED will turn green). Once you are connected, you can then move away from your console. Please see the manual for further instruction on proper use of your XB-Comm controller.

Hip Gear XB-Comm™ Bluetooth® Xbox® Wireless Controller & Headset

Thank you for purchasing Hip Gear's XB-Comm ™ Bluetooth ® Xbox ® Wireless Controller & Headset for the Xbox ® Console. Please read this instruction manual thoroughly before use.

Features:

- Fully compatible with Xbox ® & Xbox Live ™
- Bluetooth ® Wireless Technology to ensure maximum signal strength
- Multi-channel scanning
- Light weight headset with microphone for On-Line gaming
- Turbo Fire
- Dual Vibration Feedback motors
- Low Battery Warning Indicator
- Auto Power Off (after about 30 hours (with vibration deactivated)
- Twin rubberized analog sticks and fully analog action buttons for precise control
- Rubberized grips to ensure comfort and prevent slipping during game play
- Optimal transmitting and receiving performance at 30ft. (10 meters) or less

Button Configurations:

a) Controller (Front View)



b) Controller (Top View)

c) Receiver

d) Headset / Earphone

Battery Replacement:

a) Open the battery compartment door.

b) Place the batteries into the controller (as marked on the bottom of the battery compartment).

c) Close the battery compartment door.

You are now ready to use your XB-Comm™ Bluetooth® Xbox® Wireless Controller & Headset.

Note:

- For longer playing time, always use Alkaline batteries.
- Do not mix new and used batteries, this will reduce the controller's transmitting and receiving distance and may cause the product to malfunction.
- Rechargeable batteries can be used with this product (rechargeable batteries are not included).
- Dispose of used batteries according to the battery manufacturer's instructions.

How to Use:

1) Turn on the power of the Xbox® console.
2) Slide the power switch to the ON position on the controller. The LED of the receiver will start to blink.

Note: Do not plug more than one receiver into the console at the same time. You can plug in up to four controllers simultaneously, depending on how many you plug in any other receivers, otherwise, a malfunction may occur.

3) Slide the power switch to the ON position on the controller. The controller's LED will also start to blink. The LED of the controller and the LED of the receiver will stop blinking when the connection has been completed.

4) If you want to play your game with vibration feedback, place the power switch into the vibration position.

5) Plug the headset / earpiece into the earphone jack of the controller and place the earpiece around either ear.

How to use Hip Gear Headset:

Once the Hip Gear Bluetooth communication and headset controller when using your XB-Comm on-line, follow all the instructions outlined in this manual about adjusting the headset.

6. a) Wear the headset as shown in figure1.

6. b) Adjust the bendable hook of the headset to custom fit securely around your ear as shown in figure 2.

NOTE: The speaker of the headset moves up and down for maximum snug and comfortable fit to your ear.

6. c) Adjust the microphone as shown in figure 3 as close to your mouth as possible to achieve the best sound quality.

7) Adjust the volume accordingly.

How to Connect the Controller for On-Line Gaming:

Press and hold the "on-line" button on the controller until the button's LED turns green. You are now ready for on-line gaming!

Mute Function:

The mute function allows you to disable your microphone so your opponent cannot hear you while playing on-line. Even when the mute function is active your microphone has been muted you will still be able to hear your opponent.
To use the on-line mute function, simply press the controller's "on-line" button once. The LED on the "on-line" button will turn red to indicate that the mute function has been activated. To deactivate the mute function, press the "on-line" button again. The button's LED will change from red to green. The microphone will now be on.

How to Deactivate On-Line Function of the Controller:

Press and hold the "on-line" button for 3 seconds. The green LED will go out and the "on-line" function will be deactivated. The controller will function as a controller only be used as a regular wireless Xbox controller. To reactivate the on-line function, press and hold the button until the button's LED once again turns green.

Note:

It is recommended that you deactivate the on-line function when it is not in use. This will extend the life of the controller's batteries.

Turbo Fire Setting:

Each action button of the controller has a built-in Turbo Fire Function. Simply follow the steps listed below to activate Turbo Fire:

1) Press and hold the Turbo button, the Turbo LED lights up.
2) Press the action button you wish to assign a Turbo Fire Function to. The Turbo LED will blink rapidly whenever the assigned Turbo Fire button is pressed.
3) The Turbo LED blinks rapidly whenever the assigned Turbo Fire button is pressed.
4) Repeat the procedure to assign another button for Turbo Fire Function.

Note:

The controller and the receiver must be connected before assigning a Turbo Fire to any of the action buttons.
The Turbo LED will remain lit when any button has Turbo Fire assigned to it.

To Clear a Turbo assigned button:

1) Press and hold the Clear button, the Clear LED lights up.
2) Press the button which has been set to Turbo Fire, the Turbo LED turns off.

The Turbo Fire function is now cleared. Follow the procedure for any other Turbo Fire cancellation.

Low Power Indication

The controller's LED starts to blink 2 times per second when the power is low. When this occurs, replace all your batteries with new ones.

For technical assistance please visit our website: www.hipgearproducts.com

CAUTION: XB-Comm uses Bluetooth Wireless Technology which operates on the 2.4GHz radio frequency band. This RF band is also used by many cordless phones, microwave ovens, and other wireless devices. Use of the XB-Comm XB-Comm controller in close proximity to any of these devices may result in interference and noise in the earpiece of the headset. Moving the receiver and/or console further away from the other devices will reduce the interference.
XB-Comm features an industry standard 2.5mm headset jack, allowing you to use any wired headset with a standard 2.5mm plug. Please note that only the included headset is covered by the Hip Gear warranty.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment does cause interference to radio or television reception, the user is encouraged to try one or more of the following corrective measures:
a) Reorient or relocate the receiving antenna;
b) Increase the separation between the equipment and receiver;
c) Connect the equipment into an outlet on a circuit different from that which the receiver is connected to;
d) Consult an experienced radio/TV technician for assistance.

Instruction Manual