9.36W" x 7.37H" x 7.37D"

Car requires 4 "AA" 1.5V alkaline batteries (not included).
See bottom panel for additional battery information.
Colors and styles may vary.

BLUE HAT
TOY COMPANY

TWO FREQUENCIES FOR COMPETITIVE RACING

360 DEGREE SPINS AND OTHER STUNTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

WIRELESS RC ACTION!

360 DEGREE SPINS AND OTHER STUNTS

BLUE HAT
TOY COMPANY

TWO FREQUENCIES FOR COMPETITIVE RACING

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

Requires 4 "AA" (1.5V) batteries (not included)

EXCITING RC DRIVING ACTION!

- Spinning Stunt Vehicle with LED Lights
- Rotates 360 Degrees on a Single Wheel
- Full-Function Wireless Radio Control
- Available in 2 Frequencies for Competitive Racing

BLUE HAT
TOY COMPANY

FULL FUNCTION REMOTE CONTROL

360 DEGREE SPINS AND OTHER STUNTS

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

- Spinning Stunt Vehicle with LED Lights
- Rotates 360 Degrees on a Single Wheel
- Full-Function Wireless Radio Control
- Available in 2 Frequencies for Competitive Racing

Car requires 4 "AA" (1.5V) batteries (not included). See bottom panel for complete operating instructions. Colors and styles may vary.

Toy RC Monster Spinning Car
DE2015A

360 DEGREE SPINS AND OTHER STUNTS

AGES 6+

BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING!
CHOKING HAZARD -
Small parts. Not suitable for children under 3 years.

THUNDER TUMBLER®

RADIO CONTROL 360° RALLY CAR

OPERATING INSTRUCTIONS

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Locate the battery compartment on the back of each item (see diagram on right).
3. Swivel latches on bottom of car to release battery pack and insert batteries.
4. Turn both car and remote buttons to "ON" position.
5. For best results use this car on hard surfaces such as wood or tile.

REMOTE CONTROL ASSEMBLY

USES ONE 9V BATTERY (NOT INCLUDED)

ON/OFF SWITCH

BATTERY PACK (4 "AA" BATTERIES NOT INCLUDED)

BATTERY DIAGRAM

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS

Reverse
Pull the right hand stick backward.

Forward
Push the right hand stick forward.

Spinning Action
Push both sticks in opposite directions to create the car spin.

ACTION BUTTON

Action Button
Press and hold this button when the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Do not wash, wax or polish this product.
- Do not expose to extreme temperatures.
- Never operate your car on the street or highway.
- Never operate your car in a crowded or crowded area and do not use people or animals as obstacles.
- Do not run your car onto furniture, objects of hard surfaces, as this will cause damage to the car and/or the furniture.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not place your transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not store your transmitter outside overnight. Dampness is harmful to the circuit boards.
- Remove all batteries when not in use to avoid accidental operation.
- Use only recommended batteries according to size.

BATTERY WARNING:
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries together.
- Insert batteries according to the correct polarity (+ and -) as marked on the battery and battery compartment.
- Remove dead batteries from the toy as they may leak acid.
- Do not short circuit the battery terminals.
- Do not attempt to recharge the batteries.
- Remove batteries from the toy if it will not be used for an extended period of time.
- Batteries should be replaced by an adult.
- Do not dispose of batteries in fire.

EAT FOR THANKS FOR PURCHASING THIS EXCITING AMERICAN OPERATION TOY.

©2011 MerchSource, LLC. Blue Hat Toy Company, Blue Hat Toy Company logo and Thunder Tumbler are trademarks of MerchSource, LLC. All rights reserved.

Distributed by MerchSource, LLC, Irvine, CA 92618.

China Patent No. ZL201120202268.1

For technical support, please call www.mycustomerservice.com or call 1-800-574-2744 between the hours of 9:00 AM and 5:00 PM Pacific Standard Time, Monday through Friday. Please have your product name or model number ready when you call. Please, do not return this product to the place of purchase. Customer service representatives will be able to help you with any questions or concerns you may have regarding your product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

2500042 (343A3)

94202 31553

Made in China