13 x 5.45 x 7 in

radio controlled action vehicle

turbo drifter

BATTERY INSTALLATION

NOTE: For best operation, operate car on a hard surface.

The car requires 4 "AA" 1.5V batteries (not included). The controller requires one 9V battery (not included). When changing batteries, adult supervision is required. Use alkaline batteries for the best performance.

Fig.1

- Carefully remove items from the package.
- Locate the battery door on the bottom of the car. Using a Phillips screwdriver, remove the screw.
- Pull the latch on the door to the left and lift up to access the battery compartment. Insert 4 "AA" batteries while observing the correct polarity (Fig.1).
- Replace the battery compartment door.
- Repeat process on the back of the remote control to open battery door.
- Insert one 9V battery while observing the correct polarity (Fig.2).
- Replace the battery compartment door.
- Switch both the car and controller power switches to the "ON" position.

Fig.2

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating vehicle.
- Do not submerge vehicle or controller in water.
- Never operate vehicle on the street or highway.
- Adult supervision is recommended when operating vehicle.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run vehicle into furniture, objects or hard surfaces, as this will cause damage to both the objects and the vehicle.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the vehicle is switched to "ON"
- Do not leave vehicle or controller near sources of heat or under direct sunlight for extended periods.
- Do not leave vehicle or controller outside overnight. Dampness is harmful to interior components.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Charge rechargeable batteries only under adult supervision.
- Follow the battery manufacturer's directions for use and storage.

DO NOT DISCARD BATTERIES IN FIRE. DO NOT CHARGE NONRECHARGEABLE BATTERIES.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2903057 (350011)

Made in China

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2010 Mattel, Inc. © Tan Style Game and all associated logos are trademarks of Mattel Games, S.C. All rights reserved.
Distributed by Mattel, Inc., El Segundo, CA 90245
(310) 252-2000. 800-524-TOYS(8697)
For parts and service, call 1-800-524-8697
The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notices from this package.

radio controlled action vehicle

turbo drifter

drift-style racing action on smooth surfaces

THE BLACK SERIES™

radio controlled action vehicle

turbo drifter

DRIFT STYLE RACER

THE BLACK SERIES™

BATTERY OPERATED (9V) VEHICLE
AGES 8 AND UP

WARNING:
Choking Hazard - Small Parts.
Not for children under 3 yrs.

radio controlled action vehicle

turbo drifter

DRIFT STYLE RACER

WIRELESS
REMOTE CONTROL FOR FULLY FUNCTIONAL RACING ACTION

FULL FUNCTION
FULL FUNCTION MULTI-DIRECTION REMOTE TO PERFORM AMAZING TRICKS

VERSATILE
DRIFT-STYLE RACING ACTION ON SMOOTH SURFACES