

1. Solder the headers on both sides of the Contact-PCB. Header must touch the PCB edge.
2. Push the Main-PCB between the other pin row and solder it.
3. Solder a pin or wire between the two PCBs



soldering a pin
or a piece of wire
contact PCB --> main PCB

