

Installation Description

DWBT001 shall be installed in the Bar-code Handy Terminal as shown in Fig. 1.

When DWBT001 is installed in the Bar-code Handy Terminal, we as OEM shall consider the following points;

1. Since DWBT001 owns its FCC ID number, we shall affix an exterior label on the outside of the Bar-code Handy Terminal if the FCC ID is not visible. The exterior label shall use wording such as either "Contains FCC IC : PZWDWBT001".
2. DWBT001 complies with requirements of sub-sections 15.203, 15.205, 15.209 and 15.247 in FCC Rules Part 15. We shall install DWBT001 in accordance with their requirements.
3. DWBT001 complies with requirements of the sub-section 2.1091. When installers install DWBT001 into the Bar-code Handy Terminal, they shall ensure that the public is not exposed to radio frequency energy levels in excess of the Commission's guidelines in accordance with the sub-section 15.247(b)(4) in FCC Rules Part 15.

(1) Assembling Bluetooth Board to holder.



(2) Assembling Bluetooth Board assembled holder in Lower Case of Bar-code Handy Terminal.



DWBT001

- (3) Assembling main circuit board, bar-code scanning module and LCD on lower case of Bar-code Handy Terminal.



(4) Assembling Upper Case

