



1008-00080

Revision 1.0

WF-10040

Label Placement Instructions

TITLE: WF-10040 WiFi Module Labeling Instructions
AUTHOR: Scott Lyle
Date: 6/17/2014
REVISION: 01

TOOLS REQUIRED:

ESD Wrist Strap
2110-00168 FCC/ICID Label for WF-10040 WiFi Module
Tweezers for applying label

STEP 1:

Locate the Jorjin module on the PCB. The module will look like the Jorjin module in picture below.



STEP 2:

Apply the FCC/ICID Label (2110-00168) as shown.

