

Photograph 1: Set-up for Spurious Emissions for below 30MHz



Photograph 2: Set-up for Spurious Emissions for 30 - 1000MHz



Photograph 3: Set-up for Spurious Emissions for 1 - 18GHz



Photograph 4: Set-up for Spurious Emissions for 18 - 26.5GHz



Photograph 5: Set-up for Conducted Emissions

