

SAR TEST SETUP

(SAR Measurement)



Back
(5mm with sensor on)



Front
(5mm with sensor on)



Top
(5mm with sensor on)



Bottom
(5mm with sensor on)




Left
(5mm with sensor on)



Back
(19mm with sensor off)



Front
(19mm with sensor off)




Top
(19mm with sensor off)



Bottom
(19mm with sensor off)



Left
(19mm with sensor off)




Spacers
(Trigger distances-1)

(SAR sensor –Trigger distance)



Back



Front



Top




Bottom



Left

Note: Plastic foam and low dielectric materials will not trigger sensor.

(SAR sensor –Tilt angle)



Top



Bottom



Left

Note: Trigger angle measurement only apply to edges such as top/bottom/left.