



LunaSafe™ Safety Products

LL63 INSTRUCTIONS






WARNING

The LunaSafe Safety product is not intended as a life saving device. It is not intended to replace any other safety considerations; such as adult supervision, lifeguards, fences, gates, pool covers, locks, and so fourth. The LunaSafe Safety Product is intended to be an additional layer of security to protect your loved ones. It is important to spend sufficient time in becoming familiar with the operation of your LunaSafe Safety Product and to properly test the unit so that it adequately covers all areas of the pool for the person(s) or pet(s) you wish to protect.

Transmitter



Transmitter Functions

Press once to turn on strobe.

Press again to turn on blue monitor light.

Press again to turn off.

When in blue monitor mode, blue LED will glow for approx 2 hours before automatically switching to strobe mode. You can change back to monitor mode by pressing the button.

Strobe will be at full brightness for a minimum of 8 hours even after the blue monitor mode is run for two hours after full charge.

When in blue monitor mode, strobe will automatically start when device is submerged in water and continue until battery is depleted or user turns off via button push.

If unit is in off mode, strobe will automatically start when device is submerged in water and continue until battery is depleted or user turns off via button push.

Device charge time is approximately 1 hour 45 minutes to full charge from being fully depleted. Less time is needed if device has some charge left.

Any Qi certified charger (similar to cell phone chargers) can be used.

Applying Graphic Label

Choose Graphic Label you would prefer.

Make sure the center and two holes where gold water sensor pins will protrude are punched out.

Remove protective backer from label. Apply label to unit making sure the gold pins push through the label completely. Use your fingernail or dull blunt object to secure around pins and on balance of label.

Test that sensor pins are not obstructed by wetting finger and making contact across pins.

WARNING: LABEL CAN NOT BE REMOVED ONCE PLACED. DOING SO WILL DAMAGE SEAL AND DEVICE WILL NO LONGER BE WATERPROOF.



Holes Clear



Remove Backer