

STUNT CAR INSTRUCTION

FCC ID :2A252-FC2004A

Note: This product has two remote control, random with a remote control, the actual reference.
please read this instruction manual carefully before use, and properly keep this manual for future use.

Packing list



Stunt car and remote control battery installation and charging




Connect the battery to the charging cable, then plug the USB charging cable into the USB port of the computer or the USB charger, and then turn on the power. When the red light is on, it means it is charging. When the red light is off, it means full.




Installation method of remote control battery

- 1) Use a screwdriver to open the battery cover on the bottom of the remote control.
- 2) Insert 2 1.5V "AA" batteries according to the correct polarity, close the battery cover, Fasten the screws.



After charging, open the battery cover and put the battery into the battery compartment.



Connect the interface between the battery pack and the body and close the battery cover.

Remote control function



Operation method


1. Press the power switch of the remote control car and put the remote control car on the flat surface, turn on the remote control switch and wait for the remote control indicator Stop flashing, you can move the joystick to operate.

(Note: The joystick cannot be moved when the indicator light of the remote control is flashing)

ON/OFF



Basic operation diagram of product use



Maintenance and repair

1. If you do not play for a long time, remove the battery.
2. Wipe the car gently with a damp cloth.
3. Do not put toys in high temperature, humidity and direct sunlight.
4. Don't put the toy in the water, it will damage the electronic components.

Matters needing attention

- Please pay attention to the polarity when installing or replacing the battery;
- Non-rechargeable batteries are not rechargeable;
- When charging rechargeable batteries, adult supervision is required;
- Do not use old, new or different types of batteries;
- When operating, pay attention to nearby signal interference, otherwise it will affect the remote control distance;
- When the vehicle speed slows down when trick-described body insufficient charge, the above method will be charged;
- If the power of the remote control is low and the indicator light becomes dark or does not light up, just replace the battery;
- When not in use for a long time, please the power is turned off, and the battery of the remote control body is removed

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.