# 单边无线耳机

产品说明书



| | | | |
|---|---|---|---|
| 无线版本 | Wireless V5.3.2 | 工作范围 | 0~10m(无障碍空间) |
| 支持协议 | A2DP、AVRCP、HSP、HFP | 通话时长 | 约4小时（80%音量） |
| 内置电池 | 锂电池-3.7V,70mAh | 充电时间 | 约2小时 |

## 按键功能操作

开机：长按多功能键约2秒开机

关机：长按多功能键约3秒关机

配对模式：长按多功能键约5秒进入配对状态

接听/挂断：单击多功能键实现来电接听与挂断

来电拒接：来电时快速双击多功能键松开实现来电拒接

末码重拨：双击多功能键开启末码重拨

播放/暂停：播放音乐时单击实现播放暂停功能

## 产品功能

◎支持连接无线设备播放音乐

◎支持无线连接高清晰通话

◎内置中文语音提示音

◎支持同时连接两个设备，一拖二功能

## LED指示状态

◎配对状态：红蓝灯交替闪烁

◎配对成功：蓝灯慢闪烁

◎开机:蓝灯闪烁三次

◎关机：红灯常亮2秒

◎待机：蓝灯5秒闪烁1次

◎充电中亮红灯

◎充满电亮蓝灯

## 无线耳机连接手机步骤

1.请将无线耳机和手机（或其他的连接设备）的距离在1米的范围内，越近越好

2.确保耳机在关机状态，长按多功能键约5秒直到红/蓝灯交替闪烁，此时进入配对状态，等待连接；

3.开启用户手机无线功能（或其他无线设备），并进行搜索或扫描，此时手机会搜索到附近所有的无线设备，点选搜索到的耳机名称：型号详见外包装，并输入密码0000（目前大部分手机不需要密码），成功配对连接后，耳机指示灯转为蓝灯闪动，表示配对连接成功！

## 手机一拖二连接步骤

1.无线耳机关机情况下，长按多功能键大约6秒，直到耳机提示灯出现红蓝交替闪烁，进入被搜索状态。

2.开启手机1的无线功能，搜索无线设备寻找耳机名称，点“配对”完成连接。

3.将手机1的无线关闭，长按耳机多功能键，直到亮红灯，关闭耳机。

4.再次打开无线耳机进入被搜索状态。

5.打开手机2无线功能，搜索无线设备寻找耳机名称，点击“配对”完成连接。

6.开启手机1无线功能，找到之前连接过的耳机，点击连接即可完成一拖二连接。

你手机与耳机之间的无线工作范围大约为10米，超出此距离，耳机有可能出现音质下降和失去连接。

## 如何重新连接

1.你的耳机会尝试重新连接失去的连接。

2.如果耳机未尝试重新连接，请轻按一次多功能按钮或通过手机的无线设备菜单以手动方式重新连接。

## 商品保修卡

一、由购买日起之三个月保修期内，机件如有发生故障时，经本公司技术人员证实故障属正常使用下发生，将提供免费修理及零配件更换服务

二、在下列情况，公司将拒绝提供保修服务

a、产品曾被错误操作，疏忽使用或因天灾人祸等意外事件引到机件损坏。

b、产品被非本公司技术人员修理及改造

c、产品机身号曾被转换、涂改或除去。

三、此保修卡提供之免费服务并不包括产品附件,及其它装饰等项目。

四、本公司将不负责任何于器材损坏而招致直接或间接损失

### 常见问题及其解决方法

| 问题描述 | 造成原因 | 问题解决方法 |
|---|---|---|
| 不开机 | 电池电量耗尽 | 充满电即可 |
| 耳机音效无立体感 | 手机不支持立体声 | 确认手机是否支持A2DP协议 |
| 不关机 | 误操作导致耳机程序出错 | 用充电器充电复位即可 |
| 搜索不到耳机 | 耳机没有进入被搜索状态 | 将耳机进入被搜索状态 |

正面

---

# WIRELESS EARPHONE

USER MANUAL



| | | | |
|---|---|---|---|
| Wireless version | Wireless V5.3 | Working range | 10meters |
| Wireless standard | A2DP、AVRCP、HSP、HFP | Talk time | About 4hours(80% volume) |
| Battery | –3.7V,70mAh | Charging input criteria | DC5V–500mA Micro USB |

## OPERATION

- Power–on：Press MFB 2seconds
- Power–off Press MFB 3seconds
- Pairing：Press MFB 5seconds
- Answer phone call：Short press MFB 1time
- End phone call：Short press MFB 1time
- Reject phone call：Double click MFB
- Redial the last phone number：Double click MFB 1time
- Pause/Play：Short press MFB 1time

## Indicator

- Pairing:Blue and red lights flash alternatively
- Pairing success:Blue light flash slowly
- Power–on:Blue light flash 3times
- Power–off:Red light is on for 2seconds
- Standby:Blue light flash 1time every 5seconds
- Red light is on when in charging status
- Blue light is on when full charged

## Connect with phone

1.Place earphone with phone within 1meter,the closer the better;

2.Long press MFB until red and blue lights flash alternatively,in pairing status;

3.Turn on wireless function on the phone,search the earphone model,click to connect without any passwords,when successfully connect indicator will turns to blue light flashes.

Congratulations!Successfully connect,now you can listen music and dial

## Multi–points connection

1.Long press earphone MFB until red and blue lights flash alternatively,in pairing status;

2.Turn on wireless function on the phone1,search the earphone model,click to connect;

3.Turn off wireless function of phone1,long press MFB to turn off earphone;

4.Long press earphone MFB until red and blue lights flash alternatively again,in pairing status;

5.Turn on wireless function on the phone2,search the earphone model,click to connect;

6.Turn on wireless function of phone1 to connect the earphone again.

Please keep earphone and phone1/2 within 10meters

## Problems&Solution

1.Couldn’t search earphone model on your phone

Reasons:

1.1 Earphone in power–off status;

1.2 Something goes wrong with earphone procedure;

1.3 Something goes wrong with phone procedure.

Solution:

1.4 After power–off earphone,long press MFB until red and blue lights flash alternatively to active earphone’s pairing status;

1.5 Re–set earphone;

1.6 Reboot your phone,and erase all connect or pairing data on your phone.

Notes

1.7 When earphone under pairing status,please connect earphone with your phone within two minutes,otherwise it will automatically power–off;

**Tips：Please use the charger which is below 1A, please disconnect AC power when full charged,please do not charge earphones with powerbanks**

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

反面