


True Wireless Sports Earphone User Manual
001-0300-001



IMPORTANT: Please read these instructions carefully before using.

Charging Instruction

1. Plug USB-C connector into USB-C power adapter; insert other end into charging case port.
2. Place earphones into the case; charging will begin.
3. Battery indicator lights will flash while charging; when all 4 LEDs stay steadily lit, earphones are fully charged.

Turn On/Turn Off

1. Turn on: Press the MFB (multi-function button) for 3-5 seconds until the blue light indicator is on. If voice settings are enabled on your device, earphones will automatically turn on once taken out of the case.
2. Turn off: Press MFB (multi-function button) for 5 seconds until the red light indicator flashes 2 times. If voice settings are enabled on your device, earphones will automatically turn off once placed into the case.


Charging Warning

1. After using for a long period of time, earphones may not charge/turn on due to an oxidized magnet connector. To resolve this problem, clean the magnetic connector on earphones and the charging case with rubbing alcohol.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product Demonstration



Specifications

Bluetooth Version: V5.0+EDR	Bluetooth working Frequency: 2.402GHz-2.480GHz
Transmission Distance:<10m (SNR(Signal Noise Ratio): >100dB	
Battery: Li-Battery 3.7V 50mAh	
Charging Time: 1-1.5 Hrs for earbuds/ 2Hrs for charging case	
Call/Music playing time: 3-4Hrs (Real using time based on type of music, volume sizeetc.)	
Bluetooth Protocol: AVRCP,V1.3/A2DP,V1.2/HFP,V1.5/HSP,V1.2	

Storage and Maintenance

1. Storage Please store in a cool and dry place.
2. Maintenance
 - a. Recommended operating temperature range is 0-35C; overcooling, overheating, or high temperature environment will reduce battery life and affect product performance.
 - b. Avoid water.
 - c. After a long period without use, charge beforehand.
 - d. Clean earphones with a soft, dry cloth.
 - e. If water or sweat seeps into earphones, wipe with a soft, dry cloth.
 - f. Avoid hard objects to prevent damage.

Basic Operation

Status	Operation	LED Light	Voice Prompt	Remark
Charging case closed		Light red power-on light		Light red light on
Charging case open		Light red power-on light		
Charging case closed	Press Power	Light red power-on light		Light red light on
Headset mode		Red light flashing		
Headset mode	Press Power	Headset status light		
Off operation	Long press Power button	Headset status light		
Power off	Long press Power button	Red light flashing		
Left/Right earbud only pairing	Press to touch a button on the earbud to enter pairing mode. Press to touch a button on the earbud to exit pairing mode. Press to touch a button on the earbud to enter pairing mode. Press to touch a button on the earbud to exit pairing mode.	Red light flashing		
LED Light	Press to touch a button on the earbud to enter pairing mode. Press to touch a button on the earbud to exit pairing mode. Press to touch a button on the earbud to enter pairing mode. Press to touch a button on the earbud to exit pairing mode.	Red light flashing		

Warranty Certificate



Warranty Card

This card is the product warranty certificate, please keep it properly

Product:	Model:
Purchase date:	Customer:
Contact:	

Maintenance records

Date	Negative Phenomena	Solution

Pairing your Bluetooth Device

1. Blue light indicates earphones have been turned on; blue-red flashing light on "R" earphone indicate earphones have entered pairing mode.
2. On your mobile device, go to your Bluetooth settings and select earphones (please note: pairing code "0000" may need to be entered to connect).
3. "L" earphone will flash blue to indicate pairing is complete. Automatic Reconnection: The last paired device will reconnect by default after the first successful connection.
4. Automatic Reconnection: The last paired device will reconnect by default after the first successful connection.