

QUICK START GUIDE

VENTURE

ZIZO BUILT FOR ADVENTURE

PACKAGE CONTENTS

IN THE BOX

2 x Venture Earbuds (L + R)
1 x Charging Case
1 x USB-C Charging Cable

4 x Earbuds (XS, S, M, L)
1 x Quick Start Guide

Case
• Charger port (USB Type-C)
• Battery indicator light
• Charging contacts
• Function button

LAYOUT

Touch/sensitive sensor
Charging contact
Earbud tip
Directional indicator
Microphone

GETTING STARTED

Before using your earbuds the first time, fully charge the earbuds.

CHARGING

1 Ensure both buds are securely placed in the charging case

LED Indicator

2 Close lid and connect included cable to power source

USING YOUR DEVICE

BLUETOOTH® PAIRING

1 Tap and hold earbuds simultaneously to enter True Wireless Mode

2 You will hear voice feedback confirming left and right channels

3 Navigate to your device's Bluetooth settings and select "ZIZO VENTURE" from the available device list

CONTROLS

Single Tap
Double Tap
Triple Tap
Tap & Hold

MUSIC

Left (L)
Single Tap (L or R)
Press & Hold for 2 seconds (L or R)
Play / Pause Music
Activate your phone's voice assistant

Right (R)
Double Tap (L or R)
Triple Tap (L or R)
Previous Song
Next Song

ADDITIONAL FEATURES

PHONE CALLS

Double tap either Venture Bud to answer incoming calls

LAUNCHING VOICE ASSISTANT

Press and hold either earbud for 2 seconds to activate your phone's voice assistant

TECHNICAL SPECIFICATIONS

SPECIFICATIONS

Model: Venture

Bluetooth® Wireless Technology: V 5.0
Wireless Transmission Distance: Up to 30 ft
Battery Capacity (Earbuds): 50 mAh
Battery Capacity (Charging Case): 300 mAh
Frequency: 2.4 GHz
Frequency response: 50Hz-20KHz
Sensitivity: 100 dB
Voice Track System: True Stereo (TWS)
SNR: > 85dB

IMPORTANT SAFEGUARDS:

1. Do not allow water to spill onto the surface or into the product.
2. Children should be supervised while operating this device.
3. If the product surface is damaged or if there is a mechanical or electrical malfunction, do not use the unit. Contact ZIZO customer support.
4. Do not place the unit in water.
5. Do not place the product in direct heat. This unit is to be placed in a dry and ventilated place.
6. Do not place heavy objects on the unit.

CE FC

WARRANTY INFORMATION

At ZIZO, we are 100% committed to your satisfaction. We stand behind our products and offer a 1-year manufacturer warranty against defects in materials or workmanship of your new ZIZO earbuds.

Should you find your item to be defective, simply visit [zizowireless.com/warranty](https://www.zizowireless.com/warranty) to submit a brief Warranty Service Request form. Warranty applies to products purchased from ZIZO Authorized resellers. International product registration is not available at this time. U.S. Customers Only.

CONTACT US

ZIZO CUSTOMER SERVICE

EMAIL
info@zizowireless.com

TELEPHONE
+1 (909) 444-7992 (English)

WEBSITE
[zizowireless.com/support](https://www.zizowireless.com/support)

#ZIZOWIRELESS | [f](#) [@](#) [t](#) [v](#) | [ZIZOWIRELESS.COM](#)

© 2021 ZIZO. All rights reserved. This document and all other documents are registered trademarks or service marks of ZIZO Inc. and any use of such marks by other parties without the express written consent of ZIZO Inc. is strictly prohibited.
*Images are for illustrative purposes only. Actual product may vary due to technical advancement.

GUIDE DE DÉMARRAGE RAPIDE

VENTURE

ZIZO CONSTRUIT POUR L'AVENTURE

CONTENU DU COLIS

DANS LA BOITE

2 x écouteurs Venture (L + R)
1 x cas de charge
1 x Guide de démarrage rapide

Case
• Port du Chargeur (USB Type-C)
• Voyant de Batterie
• Contacts de Charge
• Bouton de Fonction

DISPOSITION

Touch/sensitive sensor
Contact de charge
Embout intra-auriculaire
Directional indicator
Microphone

COMMENCER

Avant d'utiliser vos oreillettes pour la première fois, chargez-les complètement.

CHARGE

1 Assurez-vous que les deux bourgeons sont bien placés dans le coffre

Indicateur LED

2 Fermez le couvercle et connectez le câble fourni à la source d'alimentation

UTILISER VOTRE APPAREIL

BLUETOOTH® APPARIEMENT

1 Appuyez et maintenez enfoncés les écouteurs simultanément pour passer en mode True Wireless

2 Vous entendrez un retour vocal confirmant les canaux gauche et droit

3 Accédez aux paramètres Bluetooth de votre appareil et sélectionnez "ZIZO VENTURE" à partir de la liste des appareils disponibles

LES CONTRÔLES

Unique T Touche
Double T Touche
Triple T Touche
T Touche & Tenir

MUSIQUE

Gauche (G)
Unique T Touche (G or D)
Jouer / Pause La Musique

Droit (D)
Double T Touche (G or D)
Chanson Précédente

T Touche & Tenir pour 2 secondes (G or D)
Activer votre téléphone's Voice Assistant

Triple T Touche (G or D)
Prochaine Chanson

CARACTÉRISTIQUES SUPPLÉMENTAIRES

APPELS TÉLÉPHONIQUES

Appuyez deux fois sur Venture Bud pour répondre aux appels entrants

LANCER L'ASSISTANT VOCAL

Appuyez sur l'une des oreillettes pendant 2 secondes pour activer l'assistant vocal de votre téléphone

SPÉCIFICATIONS TECHNIQUES

CARACTÉRISTIQUES

Modèle: Venture

Bluetooth® Wireless Technology: V 5.0
Distance de transmission sans fil: Jusqu'à 30 ft
Capacité de la batterie (Oreillettes): 50 mAh
Capacité de la batterie (Boîtier de charge): 300 mAh
Fréquence: 2.4 GHz
Réponse en fréquence: 50Hz-20KHz
Sensibilité: 100 dB
Système de piste stéréo: True Stereo (TWS)
SNR: > 85dB

GARANTIES IMPORTANTES:

1. Ne laissez pas l'eau se répandre sur la surface ou dans le produit.
2. Les enfants doivent être surveillés.
3. Si la surface du produit est endommagée ou s'il existe un problème mécanique ou électrique, dysfonctionnement, n'utilisez pas l'appareil. Contactez le support client ZIZO.
4. Ne placez pas l'appareil dans l'eau.
5. Ne placez pas le produit à la chaleur directe. Cette unité doit être placée dans un endroit sec et aéré.
6. Ne placez pas d'objets lourds sur l'appareil.

CE FC

INFORMATIONS DE GARANTIE

Chez ZIZO, nous nous engageons à 100% pour votre satisfaction. Nous garantissons nos produits et offrons une garantie du fabricant d'un an contre les défauts de matériel ou de fabrication de vos nouveaux écouteurs ZIZO.

Si vous trouvez que votre article est défectueux, visitez simplement [zizowireless.com/warranty](https://www.zizowireless.com/warranty) pour envoyer un bref formulaire de demande de service de garantie. La garantie s'applique aux produits achetés auprès de revendeurs ZIZO agréés. L'enregistrement international du produit n'est pas disponible pour le moment. Clients américains uniquement.

CONTACTEZ NOUS

SERVICE CLIENT ZIZO

ADRESSE ÉLECTRONIQUE
info@zizowireless.com

SITE INTERNET
[zizowireless.com/support](https://www.zizowireless.com/support)

#ZIZOWIRELESS | [f](#) [@](#) [t](#) [v](#) | [ZIZOWIRELESS.COM](#)

© 2021 ZIZO. Tous droits réservés. Ce document et tous les autres documents sont des marques déposées ou des marques de ZIZO Inc. et toute utilisation de ces marques par d'autres parties sans la permission écrite de ZIZO Inc. est strictement interdite.
*Les images sont destinées à illustrer les produits. Les produits réels peuvent varier en raison des améliorations techniques.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.