



X Pro

Operating guide

● Product description and accessories



Earphones



Data cable



Charging bay



Operating guide

Note: All pictures in this operating guide are schematic diagrams, which may be different from the real product. Please see the real product.

● Charge description



● Earphones charging

Put the headset into the charging box for charging. The ice blue lamp of the charging box flashes when charging, and the lamp will be off when it is fully charged.

● Charging bay charging

The red light is flashing when charging; The ice blue light is on after full charge.

● Battery capacity

30mAh (earphones)
300mAh (charging bay)

Warning: The rechargeable battery of this product must be properly disposed for recycling. Please do not put it into the fire to avoid explosion events.

● One-Setp pairing



The earphones automatically powers on after being taken out.



The earphones automatically powers off after being put back.



Headset on: please take out the headphones together, The "di" prompt sound appears on the ear directly, that means it's power on successfully. (one headphone light shows the breathing state and the other is flash).



Open the electronic device (mobile phone, tablet, etc.) to find the matching name "x Pro" and click to connect

● Key operation



Answer calls: When a call coming in, click on the earphones.

Reject calls: When a call coming in, press about two seconds.

Hang up calls: When in a call, click on the earphones.

Pause/Play: Click the left earphone or right earphone

Next song: Double click the right earphone

Previous song: Double click the left earphone

Game mode: when the headset is connected, long press 1-2 seconds to hear the prompt tone and then release to enter the game mode; long press 1-2 seconds to hear the prompt tone and then release to exit the game mode.

● Specification parameters

Name: Wireless earphones
Model: X Pro
Impedance: 32 Ω
Frequency: 20-20KHz
Connection Range: ≥10M
Charging voltage: DC 5V=1A
Speaker specification: φ13mm
Earphones battery capacity: 30mAh
Battery capacity of charging bay: 300mAh
Product size: 59*51*28mm

● Frequently Asked Questions

No sound in the earphones

- Confirm whether the earphones are in working condition.
- Confirm whether the phone volume is proper.
- Confirm whether the earphones are properly connected to the phone.
- Confirm whether the earphones are in the normal area coverage.

Bad calling effect of the earphones

- Confirm whether the phone is in a strong signal area.
- Confirm whether there is no barrier between the earphones and the phone.

● 製品説明及び付属品



イヤホン



データケーブル



充電コンパートメント



使用マニュアル

注：本明細書の写真は全て概略図で、実際の商品と異なる場合があります。実物を基準にしてください。

● 充電説明



● イヤホンの充電

イヤホンを充電ケースに入れて充電します。充電する時、充電ケースの氷と青ランプが点滅します。電気がいっぱいになったら、消灯します。

● 充電コンパートメントの充電

充電する時、赤いランプが点滅します。充電が完成したら、赤いランプが長く点灯します。

● 電池容量

30mAh (イヤホン)
300mAh (充電コンパートメント)

警告：リサイクルするために、本製品の充電式電池を適切に保管してください。爆発事故を起こさないために、電池を火の中に入れてください。

● ヘッドセット



イヤホンを取り出すと、自動起動します。



イヤホンを充電コンパートメントに入れると、自動的にオフにします。



イヤホンの起動:両方のイヤホンを一緒に取り出してください。

直接耳につけると「滴」という表示音が出ます。すなわち起動成功です。



電子機器 (携帯電話、タブレットなど) を開いて、ペア名の「X Pro」を見つけたら接続をクリックしてください。

● ボタン操作



電話に出る:電話が来た場合、イヤホンをクリックします。

電話に出ない:電話が来た場合、二秒くらい長押しします

電話を切る:通話中、イヤホンをクリックします

中止/放送: 左耳または右耳のイヤホンをクリックします

次の曲: 右耳のイヤホンをダブルクリックします
前の曲: 左耳のイヤホンをダブルクリックします

ゲームモード:イヤホンが接続されている場合は、1〜2秒押して、プロンプトの音が聞こえたら、手を放してゲームモードに入ります。もう1〜2秒押して、プロンプトの音を聞いた後、手を離してゲームモードから退出します。退出します。

● 仕様パラメータ

名称:ワイヤレスヘッドフォン
型番:X Pro
インピーダンス:32Ω
周波数:20-20KHz
接続範囲:≥10M
充電電圧:DC 5V=1A
ホーン仕様:φ13mm
イヤホン電池容量:30mAh
充電コンパートメントの電池容量:300mAh
製品サイズ:59 * 51 * 28mm

● よくある問題

イヤホンから音が出ない

- イヤホンが作動状態であることを確認します。
- 携帯電話の音量の大きさを確認します。
- イヤホンと携帯電話とが正常に接続されていることを確認します。
- イヤホンが正常なエリアの範囲内にあるかを確認します。

イヤホンの通話効果がよくない

- 携帯電話が信号の強いエリアにあるかを確認します
- イヤホンと携帯電話との間に障害物がないことを確認します

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.