

User Manual



(Microphone transmitter) (receiver) (Charging compartment)

- ① Microphone
- ② Open key
- ③ Charging port/charging contact
- ④ Magnetic suction plate
- ⑤ Connection indicator light
- ⑥ Charging indicator light
- ⑦ Mute indicator light
- ⑧ Noise reduction indicator light
- ⑨ Receiver connection light
- ⑩ Type-C charging port
- ⑪ Type-C port
- ⑫ Charging compartment battery level display
- ⑬ Charging port of the charging compartment

Note: oppo / vivo / iqoo / realm brand mobile phones can be used normally only when they go to the settings (search "OTG" - turn on OTG power supply)

Diagram illustrating the location of the Switch Key on the back of the device. The key is located on the right side of the device's back cover, near the bottom edge.

Indicator always on

Note: Only 5V-1A charging is supported, not fast charger charging
Some models of the receiving end do not have this function,
subject to the actual product

Function/Status	Key operation	Lighting effect
Power on	Long press the power button	
Shutdown	Long press the power button	
Not connected	/	Connection indicator light flashing
Connected	/	Connection indicator light always on
Noise reduction	Click the power button	Turn on the noise reduction indicator light and turn off the noise reduction indicator light
Reverberation		
Mute	Double click the power button	Turn on the mute indicator light and turn off the mute indicator light
Charging	Insert charging cable/insert charging compartment	The charging indicator light comes on and goes off when fully charged
Low battery	/	The battery indicator light is flashing

Receiver		
Functional model	No buttons	LED status
Power on	Insert the phone charging cable	The indicator light is on
Shutdown	Turn off the phone by unplugging the charging port	The indicator light is off
Not connected	TX power on, RX power on, automatic pairing connection	The indicator light is flashing
Connected	TX power on, RX power on, automatic pairing connection	The indicator light is always on

Battery holder		
Functional state	No buttons	LED status
Installing the transmitter	Install the TX transmitter and change the transmitter	Digital battery level indicator of the charging case TX charging indicator display
Charging the battery compartment	Insert an external 5V to charge the battery compartment The battery compartment is fully charged	Digital light flashing slowly Light goes out
Low battery compartment	Battery voltage below 3.2V enters low battery protection mode	The red light flashes once every 5 seconds

Note: if one of the two microphones is flashing and not connected, turn off the microphone that has been successfully connected, then unplug the receiver, then turn on the microphone that has not been connected, and then press and hold the switch for 8 seconds until it flashes quickly, and then plug in the receiver. The connection is successful (there is no need to use too much force to switch on and off).

- (1) Microphone transmitter
- (2) receiver
- (3) charging cable
- (4) User manual