

KUMI Soar OH Smart Watch

USER MANUAL

Thank you for choosing KUMI smartwatch. This manual will give you a complete understanding of how to use the equipment. This device is mainly connected to the mobile phone through Bluetooth function, providing a variety of practical functions and services to facilitate your operation of the mobile phone, and has developed many functions for human sports and health.

This equipment is not a medical device, and the measurement data and results are only for reference, not for diagnosis and treatment.

Due to the continuous improvement, optimization and upgrade of the product, the user may expect slight difference between the actual product and the description in this manual.

Based on the principle of continuous improvement and continuous optimization, the company reserves the right to modify and improve any content and product information and functions described in the document without prior notice.

1. Packing List



KUMI Soar OH x1



User Manual x1



Magnetic
Charging Wire x1

2. Introduction to Watch Touch Operation



Messages

↑
Swipe Up



Custom

←
Swipe Left



↓
Swipe Down

→
Swipe Right



Shortcut Menu



Control Center

3. Introduction to Watch Button Functions



Digital Crown :

- 1) **Short Press:** Turn screen on/enter the menu/return to the dial
- 2) **Hold Down:**
 - a. Hold down to power on
 - b. Under the dial screen: Hold down for 2 seconds to power off

Down Button :

Long Press for 3 Seconds: Make an SOS emergency call

4. Downloading the App


Scan the following QR code, download and install the App



KUMI Model

5. Watch Charging and Activation

Charging the device to active before the first time using; To charge your device, plug the charging cable into the adapter or USB port on your computer.



6. Paring

Open the App and set up your profile



Go to the [Device], click Add a [Device]



Choose your device on the scanning list



Finish

The MAC address on the "Setting"-"About" page could help you identify your device on the scanning list.

7. Function Introduction



AI model

This feature is a large AI model that allows you to select DeepSeek, Wenxin Yiyao, or Doubao in the app to input text, or send voice commands from your watch for interaction, providing you with quick, detailed answers and assistance.



AI watch face

You can draw your own watch face through the AI voice function on the watch.



Activity

The watch can record and display the number of steps taken, calories burned, and exercise duration within seven days. More detailed information analysis and data records can be viewed in the client.



Sleep

After wearing the watch correctly, open the Sleep app in the watch app the next day to check your sleep status of the previous night.



Heart rate

Wear the watch correctly, open the "Heart Rate" app in the watch app, and automatically measure your heart rate after entering.



Phone call

You can view contacts and call records on the watch, and use the dialing function to make calls on the watch.



Exercise

100+ sports modes to choose from, including: walking, running, outdoor cycling, skipping, badminton, basketball, football, mountaineering, etc. More detailed information analysis and data records can be viewed in the client.



Exercise records

Display historical exercise data, recording information such as heart rate, distance, calories, and steps.



SpO2

After wearing the watch correctly, open the "Blood Oxygen" app in the watch app; click to measure manually, or set the blood oxygen automatic monitoring switch.



Stress

After wearing the watch correctly, open the 'Stress' app in the watch application; manually tap to measure and check your personal psychological stress status.



Weather

Connect to the APP to synchronize the real-time weather display on the watch, and you can check the weather data of the day.



Messages

The device can synchronize push notifications from social software.

Note: You can turn on/off message push notifications in the APP.



Shutter

After connecting to a mobile phone, the watch can be used as a remote control for the mobile phone camera. After opening the camera on the APP, click on the watch camera control page to trigger the mobile phone camera shutter.



Music

Open the "Music" app in the watch application; you can control the music player on your phone to play music, supporting operations such as play/pause, previous track, next track, and volume adjustment.



Relaxation

In this breathing training, there are two options: stress relief and sleep aid. The user clicks on the corresponding method to start breathing training. After clicking start, follow the breathing training icon to enlarge and inhale, and shrink and exhale.



AI voice

When connected to a wireless call, wake up the voice assistant on your phone through the watch.



Timer

The timer function allows you to set your own time settings. Click  to start the timer for any duration. Click  to pause the timer. Click  to exit the timer.



Alarm

You can set the smart alarm of the watch in the client. When you set the time, the watch will display the alarm icon and vibrate.



Stopwatch

After entering this function, click Start to start timing, click Pause to stop timing, and click Reset to return to zero. The stopwatch can record up to 100 times, but only supports viewing the last 20 records.



Cycle tracking

After the watch is connected to the APP, turn on the female health reminder on the APP and view female health information on the watch.



World clock

APP-"Device"-"World Clock"-"Add"
You can scroll down to select or click the search icon in the upper right corner to enter the region name to search and add.



Find phone

When connected, click Find Phone and the phone will vibrate and ring.



Calculator

It can complete the calculation of numbers within 5 digits (inclusive), and the maximum single input value is 10 digits.



Recording

Tap Record to start recording and save audio for the user.



Alipay

Use Alipay to scan the QR code and click "Agree to the Agreement and Bind" to complete the binding. After the binding is successful, the Alipay payment barcode or QR code will be displayed.



Intelligent voice

Bluetooth, visual style, watch face switching, custom card display and brightness, reminder mode, vibration & ringtone password, do-not-disturb mode, sleep mode, power-saving mode, offline voice, quick actions, bedside lamp mode, calls, system, about.



Settings

Display, Vibrate & ring, DND mode, Low power mode, Phone, Dynamic island, Intelligent voice, Encoder, Language, System, About.



NFC

Use the watch as a smart access card to enter the administrator mode of the smart door lock. According to the manual or the voice prompt of the door lock, place the watch screen close to the NFC sensing area of the door lock to enter/delete (some door locks do not support third-party door cards); for community access control, please go to the community management office to enter the door card.

*Currently only supports copying unencrypted 13.56MHz access cards available on the market.



SOS

You can turn on SOS and add emergency contacts on the watch. After turning on the SOS function, long press the shortcut key on the watch face interface to pop up the SOS.



Navigation

The navigation function needs to be initiated in the APP. Open the "Navigation" function in the APP and enter the destination. You can select the route preference through the "Recommendation" button. After confirmation, click to start navigation. During the navigation process, the watch will synchronously display the navigation direction and distance.

**Navigation services are for reference only. Please do not use this as the sole basis for your travel or driving. When you travel or drive, please refer to the actual traffic conditions and strictly abide by relevant laws, regulations, and traffic rules.*



Calendar

View date details for the day, including year, month, day, and week.



Photo album

You can upload photos on the mobile app, and after uploading, you can view them on the watch.



Video

You can upload videos on the mobile app, and after uploading, you can view them on the watch.

8. Frequently Asked Questions

The watch does not turn on

- 1) Check whether the power is sufficient, use the charging cable to charge the watch, and the charging voltage shall not be higher than 5V;
- 2) Check whether the watch screen is damaged by external forces, such as accidental drop;
- 3) Check whether the watch has water, damp caused by internal circuit short circuit can not be turned on.

Bluetooth not connected or unable to connect

- 1) Slide down the dial interface to enter the control center, and check whether the icon  is black and not connected;
- 2) Check whether the bluetooth of the mobile phone is enabled normally and whether the APP has obtained the location permission;
- 3) Try restarting the device or performing a factory reset.

Why android phones are easy to disconnect

APP must be running in the background, Bluetooth will not be automatically disconnected, but the android phone system memory management will force the APP to close, we need to manually close the phone system power saving mode or add the APP to the system management green background, APP will not be forced to close, specific settings please refer to the phone manual or consult the official customer service.

For more frequently asked questions, please check the App [My>FAQ] or send an email to our customer service email service@kumi.top

9. Safety Warning

Please read all safety information before using this product to ensure safe and proper use.

1. In case of equipment failure or factory reset, if you do not keep the backup file safely, you will not be able to recover the previous data. Be sure to back up all important data stored on the equipment and keep it in a safe place;
2. When using a power-intensive application or using an application on the device for a long time, the device feels hot to the touch, which is normal and does not affect the use or performance of the device;
3. If the touch screen is equipped with protective film or the hands are not clean, or the touch screen reacts slowly and may not work properly, if the touch screen is scratched or damaged, there may be a risk of water ingress and moisture;
4. This product is not suitable for children under the age of 14 to use alone;
5. All packaging materials (such as tape, plastic bags, plastic sheets, labels, binding lines, etc,) and small parts of the machine should not be touched by children under 3 years old to avoid suffocation risk.

Observe the following warnings to prevent personal injury or damage to equipment:

1. Do not allow children or animals to chew or swallow the equipment and accessories;
2. Do not poke eyes, ears or other body parts with the device or put the device in your mouth;
3. Do not store the equipment in an overheated or overcooled environment. It is recommended to use it in an environment with a temperature between -5°C and 40°C;
4. Do not store equipment near or inside heaters, microwave ovens, cooking equipment, or pressure vessels;
5. Do not drop, squeeze, impact or scratch the equipment;

5. Do not drop, squeeze, impact or scratch the equipment;
6. Do not use the equipment in thunderstorm weather;
7. Please keep the equipment dry and clean;
8. Please observe all safety warnings and regulations regarding the use of mobile devices while driving;
9. Do not wear or use this product while charging.

10. Legal Statement

- Copyright © KUMI Technology Co., Ltd. All rights reserved.
- The company has the right to modify any information in this manual at any time without notifying any third party, and does not assume any responsibility to the third party for such modification;
- Without the written consent of the company, any unit or individual shall not extract, copy or use the contents of this manual in any other way, and shall not transmit it in any form;
- This guide is for reference only and does not constitute any form of commitment. Products (including but not limited to color, size screen display, etc.) shall be subject to the actual product;
- Due to the upgrade of software version, the contents introduced in this guide are for reference only. Please refer to the actual product;
- This equipment is not a medical device. The measurement data and results are for reference only and should not be used as the basis for medical diagnosis. If you feel uncomfortable, please consult a medical institution.

11. Name and Content of Toxic and Hazardous Substances or Elements in the Product

Part Name	Toxic and Hazardous Substances or Elements					
	lead (Pb)	Cadmium (Cd)	Mercury (Hg)	Hexa-valent Chromium (Cr(VI))	Polybro-minated Biphenyls (PBB)	Polybro-minated Diphenyl Ethers (PBDE)
Screen	○	○	○	○	○	○
Metal Housing	○	○	○	○	○	○
Silicone Strap	○	○	○	○	○	○
Hardware	×	○	○	○	○	○
PCB	○	○	○	○	○	○

○: It means that the content of the toxic and hazardous substance in all homogeneous materials of this component is below the limit requirement specified in GB/T 26125 standard.

X: It means that the content of the toxic and hazardous substance in at least one homogeneous material of the component exceeds the limit requirement specified in GB/T 26125.

(Note: The components marked with "X" in the table cannot be completely lead-free due to the current limitations of the industry's technological development level.)



The number in the mark represents the environmentally friendly service life of the product under normal use. Under normal use conditions, the harmful substances or elements contained in the watch (excluding batteries) and its accessories will not leak or mutate, and the use of the electronic information product by the user will not cause serious pollution to the environment or serious damage to his or her personal or property.



12. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2A2L4-SOAROH



KUMI Technology Co., Ltd.

Website: en.kumi.top

Mail: service@kumi.top

Room 405, Block A, United Financial Holdings
Building, No.1 Shihua Road, Hetao Shenzhen-Hong
Kong Science and Technology Innovation Cooperation
Zone, Futian District, Shenzhen

Made in China