




Instructions for remote control car with deformation

1.Function introduction of remote control



2.Remote control/remote control car battery installation instructions



Power supply: Use three 1.5V "AA" non-rechargeable batteries;

- The battery should be taken out and loaded according to the polarity and voltage sign on the toy battery room for correct operation, battery should not short circuit;
- Non-rechargeable batteries cannot be charged;
- Different types of batteries or old and new batteries can not be mixed;
- Only the same or equivalent batteries as recommended can be used;
- Exhausted battery should be taken out from the toy, if not used for a long time, please take out the battery in the toy;
- Power terminal shall not short circuit;
- Do not connect to more than the recommended amount of power supply.




Remote control car

Frequency specification

Please turn on the remote control first. The red light of the remote control flashes quickly to turn on the car. Power switch remote control red light out, the car and the remote control frequency to complete.

3.Remote control operation instruction



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.