OLEAP

# User Manual

## Archer A1

English ·····EN
中文 ·····CN
中文繁体 ·····TCN

使用产品前请仔细阅读使用说明书，并请妥善保管
Please read the user manual carefully before using the product and keep it properly

### Introduction

### Indicator Light

Working Status Prompt:
Red and blue lights flashing alternately – Ready to pair
Solid red – Recording  Blue light flashing – Works fine
Red light flashing – Battery low
Charging Status Indicator:
Red light flashing – Charging  Solid blue – Fully charged

EN

### Using the Charging Case

Open the lid of the charging case. If the indicator light on the charging case is white, it means that the charging case has plenty of power. If the indicator light is red, it means that the charging case is running out of power and needs to be charged as soon as possible.
Please use a standard USB-C charging cable to charge the charging case. Charging will take about 1 hour when the charging case is empty. Charging case will flash red, and it will stay white when fully charged.
When the earbuds are put into the charging case and the lid is closed, click the button on the body of the charging case, the headset will enter the factory reset and connect mode according to device.
Pairing Connection
When the headset are put into the charging case and the lid is closed, the headset will automatically turn off. When the lid is opened, the headset will automatically turn on.




### Pairing Connection

1.Hold the power button until the headset indicator flashes red and blue alternately. Then the headset will turn on for 30 seconds without a connection, it will enter pairing mode.
2.Turn on the Bluetooth switch of the device you want to pair with the headset, search for the headset name in the Bluetooth menu and connect.

### Dual Device Connection

The headset can maintain simultaneous connections with two Bluetooth devices. After successfully connecting to the first Bluetooth device, press the headset power button three times. The headset indicator will flash red and blue alternately, indicating that the headset is in pairing mode for the second Bluetooth device.

### Button functions

Volume Up Area
Tap once ·····Volume up
Volume Down Area
Tap once ·····Volume down
Volume Up/Down Any Area
Hold during call ·····Start/Stop call mode recording on device
Hold during music ·····Start/Stop music mode recording on device
Hold during other states ·····Start/Stop memo mode recording on device
Mute Button
Tap during call ·····Mute/Unmute mic
Double tap during call ·····Switch to another call device
Double tap during playback ·····Switch to another playback device
Hold during non-call state ·····Activate phone's voice assistant
Power Button
Press for 3 s while power is on ·····Power on/off
Press for 5 s while the device is off ·····Enter Bluetooth pairing mode
Triple press ·····Start Bluetooth pairing for a second device
Tap during call ·····Answer call
Hold when incoming call ·····Reject call
Tap during call ·····Hang up call
Tap during playback ·····Play/Pause

### Packing list

EN

### Wearing

1.Select ear tips of the appropriate size: The earphones are equipped with ear tips of different sizes. Choose the size that fits your ear canal and the appropriate ear tips to conduct a wearing fit test so as to achieve a better wearing experience.
2.Please wear the headset in the correct direction: Gently rotate until you find the most comfortable and secure position. (the position closest to the mouth when making a call)



Note:
The headset can be worn on either the left or right ear. If you want to wear the headset on the other ear, please rotate the microphone arm upwards, turn the ear hook of the headset by 180 degrees, and then lower the microphone arm.

### Charging

Please use the magnetic charging cable included in the package or the optional charging case to charge the headset.

EN

### Connect to the Oleap APP

Scan the QR code to download and install the Oleap APP.
Follow the on-screen instructions in the APP to connect the headset.
Turn on Bluetooth and location services, and so on, and keep the headset near the phone during the use of the APP.
The APP supports iOS 13.0 and later and above and iOS 14.0 and above.
*Please update to the latest version of the APP.

Download the Oleap APP
Discover more intelligent features

### Dongle Connection

1.Connection Method
Insert the Dongle into the device's Type-C port. The Dongle's blue light will flash slowly. After powering on the headset, it will automatically pair with the Dongle. Once paired successfully, the Dongle's blue light will stay solid.
2.If the headset has not been connected to two devices, at least one device must be already connected before pairing with the Dongle.
2.Dongle and Headset Connection Status
Automatic Reconnection: If the headset and Dongle are disconnected due to distance, they will automatically reconnect once they return within the effective range (typically 10 meters / 33 feet).
Standby Mode: If no headset is paired within 5 minutes, the Dongle will enter standby mode and the blue light will turn off. In this state, if the headset transitions to normal Bluetooth range, it can reconnect by pressing the Dongle's button.

EN

### 3.Reconnect to a New Headset

Insert the Dongle into the device, hold the Dongle button for 3 seconds until the Dongle's indicator light flashes red and blue alternately. Then, power on the headset and enter pairing mode. Place the headset near the Dongle for automatic pairing.
*Note: This operation requires the OLEAP brand headsets.
4.Dongle Indicator Light Description
Blue light flashing slowly – Device disconnected or not connected to a headset
Red and blue flashing alternately – Pairing mode
Solid blue – Connected and playing music
Blue light flashing – Paired successfully or music playing
Tips:
Windows: The system typically sets the newly installed headset as the default audio input/output device. If the headset is not set as the default device, click the sound settings icon in the lower right corner of the taskbar, select and confirm "OLEAP" as the playback device for normal use.
macOS: The system does not automatically set the newly installed headset as the default audio input/output device. After successful installation, go to Settings > Sound Settings, select "OLEAP" as both the input and output device to use the headset normally.

### Basic Parameters

Product Name: Single Ear Bluetooth Headset
Product Model: OLEAP A1  Wireless Connection: Bluetooth 5.3
Charging Time: 1 hour  Charging Temperature: 0°C - 45°C
Operating Distance: 10 meters (open space without obstacles)
Note: Due to the connection characteristics of Bluetooth signals, excessive environmental disturbance (e.g., 40 Gbps wireless 4 areas with high electromagnetic interference in the 2.4GHz frequency range.

EN

### Safety Information

1.Before using and operating the device, please read and follow the precautions below to ensure optimal device performance and avoid unnecessary damage.
2.To prevent possible hearing damage, do not use the product at high volume for extended periods.
3.Please use the standard charging cable to charge the product.
4.Do not disassemble, impact, squeeze, or throw the product into fire, as it may cause an explosion.
5.The product contains a non-removable lithium battery. Do not disassemble or replace the battery yourself to avoid damage to the product or injury. If the battery shows signs of severe swelling, do not continue to use it.
6.Do not dispose of old batteries in household waste. Please dispose of old batteries and used batteries in accordance with local laws and regulations.
7.Do not expose the battery to extreme conditions such as sunlight, fire, or high temperatures, as this may cause an explosion or leakage.
8.Do not throw the battery into fire or a high-temperature oven, or crush or cut the battery mechanically, as it may cause the battery to explode.
9.Do not place the battery in environments with extremely high temperatures or low atmospheric pressure, as it may lead to explosion or the leakage of flammable liquids or gases.
10.This product is not a toy. The product and its accessories contain small parts that could cause suffocation or other injuries to children. Keep it out of the reach of children. If any skin irritation such as redness or swelling occurs upon contact, stop using it immediately and consult a doctor.

EN

### Product Warranty Information

The above warranty terms for this product is as follows:

### Warranty Period

1.Within 12 months from the date of receipt, if the product experiences any issues listed in the "Product Performance Failure Table," and after being inspected by the OLEAP after-sales service center, you are eligible for free return or exchange services.
2.Within 12 months from the date of receipt, if the product experiences any issues listed in the "Product Performance Failure Table," and after being inspected by the OLEAP after-sales service center, you are eligible for free repair services.

### Product Performance Failure Table

| Name | Reasons |
|---|---|
| Headset | Failure of functions listed in the product description |
| | No sound from the speaker |
| | Microphone cannot record |
| | Button functions are not working |
| | Damage caused by structural or material factors |
| | No call cancellation function |
| Charging Case/Charging Dongle | Cannot charge the headset properly |
| Dongle | Cannot connect to the headset |

EN

### Non-Warranty Clauses

1.Unauthorized repairs, misuse, collisions, negligence, abuse, liquid damage, accidents, incorrect use of non-original accessories, or tearing, altering labels, and anti-counterfeit marks.
2.The warranty period has expired.
3.Damage caused by force majeure.
4.Failures not listed in the "Product Performance Failure Table."
Product or accessory failures listed in the "Product Performance Failure Table" caused by human error.

### More Support

After-sales email: info@oleapai.com

EN

### Warranty Card

**Product Warranty Card**

| | | | |
|---|---|---|---|
| Product Name: | | Product Model: | |
| Purchase Date: | | Customer Name: | |
| Contact: | | | |
| Remarks: | | | |

**Product Repair Record:**

| Date | Defect | Solution |
|---|---|---|
| | | |
| | | |
| | | |

*This card is a product warranty certificate, please keep it safe.

EN

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### 产品介绍




### 耳机指示灯

工作状态指示：
红灯闪烁……配对模式
红灯常亮……充电中
充电状态指示：
红灯闪烁……正常工作
红灯常亮……已充满电

CN

### 包装清单




### 佩戴

1.选择合适大小的耳塞：耳机内附带多个不同大小的耳塞，请选择合适的耳塞进行佩戴后密封测试，以获得更好的佩戴体验。
2.请按照正确方向佩戴耳机：轻轻转动直至找到最舒适、最安全的位置。（靠近嘴部的位置）



*温馨提示：
耳机可在左耳佩戴，也可在右耳佩戴。如需在另一侧耳戴，请将麦克风杆朝上转动，将耳钩旋转180度，然后将麦克风杆放下。



CN

### 充电

请使用包装中附带的磁吸充电线或选配的充电盒为耳机充电。

### 使用充电盒

打开充电盒盖，如果充电盒指示灯显白色，则表示充电盒电量充足；如充电盒指示灯显红色，则表示充电盒电量不足，需尽快为充电盒充电。
请使用标准USB-C充电线为充电盒充电，充电过程中充电盒指示灯显红色且灯光闪烁，充满后灯光常亮。
当耳机放入充电盒中并关闭盖盖时，单击充电盒机身按钮，耳机将自动/手动进行重新配对模式。
将耳机放入充电盒中并关闭盖盖，耳机自动关机；打开盖盖，耳机自动开机。

### 配对连接

1.长按开机键直至耳机指示灯呈现红蓝交替闪烁，此时将设备连接30秒后未连接，耳机将进入配对模式。
2.打开耳机蓝牙功能并搜索设备，在设备蓝牙菜单中搜索耳机名称并连接。

### 连接OLEAP耳机APP

扫描二维码下载并安装OLEAP耳机APP。
按照APP界面提示操作连接耳机。
提示:请确保手机蓝牙处于开启状态，APP使用过程中请保持手机靠近耳机。
*OLEAP耳机APP支持安卓10.0及以上的手机和 iOS14.0 及以上手机。
*APP相关操作详细请参阅说明书

CN

### 双设备连接

耳机可同时与两台蓝牙设备保持连接，成功连接第一台蓝牙设备后，将耳机开关机键连续三次，耳机将进行第二台蓝牙配对，此时可与第二台蓝牙设备进行配对连接。

### Dongle连接

1.连接方法
将蓝牙Dongle插入设备Type-C接口，Dongle蓝灯慢闪，耳机开机后，自动与Dongle配对，配对成功后，Dongle蓝灯常亮。
*若耳机已连接了2台设备，则需要至少断开一台设备才可与Dongle进行配对连接。
2.Dongle与耳机的连接状态
自动回连 耳机与 Dongle 因远距离断连后，若与1分钟内回到正常蓝牙距离范围，将自动重新连接。
待机模式：1分钟内无耳机进行Dongle的A2DP/HFP模式，蓝灯熄灭，此状态下耳机的回正常蓝牙距离可通过短按Dongle按键回连。

3.重新连接新的耳机
把Dongle插入设备，长按Dongle按键3秒至Dongle指示灯红蓝灯交替闪烁，同时打开耳机进入配对状态，耳机将重连Dongle进行自动配对连接。
*为确保Dongle可进行OLEAP品牌耳机进行配对使用。

### 连接两台蓝牙设备

蓝灯慢闪……设备断连/未连接状态　　红蓝灯交替闪烁……配对模式
红灯常亮……耳机通话/播放　　蓝灯常亮……配对成功/播放音乐

### 基本参数

| 产品名称:单耳式蓝牙耳机 | 产品型号:OLEAP A1 |
|---|---|
| 无线连接:蓝牙5.3 | 充电接口:磁吸充电 |
| 工作温度:0°C-45°C | 蓝牙距离:10米(无障碍空旷环境) |

部分蓝牙设备可与本设备同时连接，如2.4GHz频段较为干扰区域内时，可能会影响传输效果，无声或卡顿现象。

### 安全信息

1.使用和操作设备前，请阅读并遵守以下注意事项，确保设备性能最优化，避免出现不必要的损坏。
2.为防止可能出现的听力损伤，请勿长时间或音量最大使用本产品。
3.请使用产品附带的充电线进行充电。
4.请勿拆开、碰撞、挤压或投入火中，否则可能会引起爆炸。
5.产品内含不可拆卸的锂电池，请勿自行拆解或更换电池，以免损坏电池或造成人身伤害。如电池出现严重膨胀，请勿继续使用。
6.请勿将废电池与生活垃圾混合处理，请按照当地法律法规处理废电池，可能会导致电池泄漏。
7.请勿将电池置于极高温或极低气压环境下，可能会导致爆炸或者燃烧或导致可燃液体或气体泄漏。
8.请勿将电池投入火中或放入高温烘箱内，或以机械方式破坏或切割电池，可能会导致电池爆炸。
9.请勿将电池置于极高温或极低气压环境下，可能会导致爆炸或者燃烧或导致可燃液体或气体泄漏。
10.本产品并非玩具，产品本身及配件内含小部件可能会造成窒息或者对使用者造成伤害，请将产品放置在儿童接触不到的地方。如接触后出现红肿等症状时，请立即停止使用并及时就医。

CN

### 产品保修信息

本指南是指南，内容如下：

### 一、保修期限

1.自您签收日起12个月内，本产品在因产品性能故障而对所售设备提供的保证。经由OLEAP售后服务中心的测定，可免费更换或退换货服务。
2.自您签收日起12个月内，本产品出现产品质量问题或者其他故障的情况，经由OLEAP售后服务中心的测定，可免费享受维修服务。

### 二、产品性能故障表

| 名 | 称 | 备 | 注 |
|---|---|---|---|
| 耳机 | 产品介绍中的功能失效 | | |
| | 喇叭无声 | | |
| | 麦克风无法录音 | | |
| | 按键功能失效 | | |
| | 因结构或材料问题造成的主体破损 | | |
| | 无通话降噪功能 | | |
| 充电仓/充电盒 | 无法正常给耳机充电 | | |
| Dongle | 无法连接耳机 | | |

CN

### 三、保修排除条例

1.未经授权的维修、违规、不正确的使用导致产品损坏，或意外、液体损坏、防伪标记被撕毁或更改。
2.已经过保修期限的。
3.不符合产品性能故障表内所列范围的情况。
4.因人为原因导致客户品质表现外的不良性能故障。

### 四、更多支持

售后电话：400-667-9697
售后邮箱：support@huanglai.com

CN

### 保修卡

**产品保修卡**

| | |
|---|---|
| 产品名称: | 产品型号: |
| 购买日期: | 客户名称: |
| 联系方式: | |
| 备　注: | |

**产品维修记录**

| 日　期 | 不良现象 | 解决方案 |
|---|---|---|
| | | |
| | | |
| | | |

*该卡为产品保修凭证，请妥善保管

### 产品介绍




### 耳机指示灯

工作状态指示：
红灯闪烁……配对模式
红灯常亮……充电中
充电状态指示：
红灯闪烁……正常工作
红灯常亮……充满电

TCN

### 包装清单




### 佩戴

1.选择合适大小的耳塞：耳机内附带多个不同大小的耳塞，请选择合适的耳塞进行佩戴后密封测试，以获得更好的佩戴体验。
2.请按照正确方向佩戴耳机：轻轻转动直至找到最舒适、最安全的位置。（靠近嘴部的位置）



*温馨提示：
耳机可在左耳佩戴，也可在右耳佩戴。如需在另一侧耳戴，请将麦克风杆朝上转动，将耳钩旋转180度，然后将麦克风杆放下。



TCN

### 充电

请使用包装中附带的磁吸充电线或选配的充电盒为耳机充电。

### 使用充电盒

打开充电盒盖，耳机充电盒指示灯显白色，则表示充电盒电量充足；耳机充电盒指示灯显红色，则表示充电盒电量不足，需尽快为充电盒充电。
请使用标准USB-C充电线为充电盒充电，充电过程中充电盒指示灯显红色且灯光闪烁，充满后灯光常亮。
当耳机放入充电盒中并关闭盖盖时，单击充电盒机身按钮，耳机将自动/手动进行重新配对模式。
将耳机放入充电盒中并关闭盖盖，耳机自动关机；打开盖盖，耳机自动开机。

### 配对连接

1.长按开机键，直至耳机指示灯呈现红蓝交替闪烁，又或者在智能（按键解锁）设备上打开耳机设置连接功能，耳机将进入配对模式。
2.打开耳机蓝牙功能并搜索设备，在设备蓝牙菜单中搜索耳机名称并连接。

### 连接 OLEAP 耳机 APP

扫描二维码下载并安装 OLEAP APP，按照 APP 引导的步骤进行操作以连接耳机。
*OLEAP 耳机 APP 支持安卓 10.0 及以上版本的手机和 iOS14.0 及以上版本的手机。*APP 相关操作详细请参阅说明书




TCN

### 产品保固资讯

本指南是指南，内容如下

### 一、保固期限

1.自您签收日起12个月内，若本产品在因产品性能故障而对所售设备提供保固。经由 OLEAP 售后服务中心的测定后，可免费享受退货或退换服务。
2.自您签收日起12个月内，本产品在因产品性能故障而对所售设备提供保固的情况，经由 OLEAP 售后服务中心的测定后，可免费享受维修服务。

### 二、产品性能故障表

| 名 | 稱 | 備 | 註 |
|---|---|---|---|
| 耳機 | 產品介紹中的功能失效 | | |
| | 喇叭無聲 | | |
| | 麥克風無法錄音 | | |
| | 按鍵功能失效 | | |
| | 因結構或材料問題造成的主體破損 | | |
| | 無通話降噪功能 | | |
| 充電艙/充電盒 | 無法正常給耳機充電 | | |
| Dongle | 無法連接耳機 | | |

TCN

### 三、保固排除條例

1.未經授權的維修、違規、不正確的使用導致產品損壞，或意外、液體損壞、防偽標記被撕毀或更改。
2.已經過保固期限的。
3.不符合產品性能故障表內所列範圍的情況。
4.因人為原因導致客戶品質表現外的不良性能故障。

### 四、更多支援

售後電話：400-667-9697
售後郵箱：info@oleapai.com

TCN

### 保固卡

**產品保固卡**

| | |
|---|---|
| 產品名稱: | 產品型號: |
| 購買日期: | 客戶名稱: |
| 聯絡方式: | |
| 備　註: | |

**產品維修記錄**

| 日　期 | 不良現象 | 解決方案 |
|---|---|---|
| | | |
| | | |
| | | |

*該卡為產品保固憑證，請妥善保管