



Welcome to use REDTIGER mini dash cam F3

Please read this manual carefully before use. If you have any questions please feel free to contact us.



2.5K
Resolution



WiFi-APP



Loop
Recording



G-sensor



Voice
Prompt



24H Parking
Monitor

USER MANUAL

Email: help@redtigercam.com

Website: <http://www.redtigercam.com/>

Copyright (C) 2021, All rights reserved



STOP EXPERIENCING PROBLEMS?

- ▶ How to use?
- ▶ Can not turn on?
- ▶ Missing items?
- ▶ Damaged or defective?

Please contact us before returning the item,
WE WILL HELP YOU RESOLVE ANY ISSUES ASAP.

CUSTOMER SERVICE

E-mail  help@redtigerscam.com
(7*24Hours)

Phone  +1 888 966 8028
(Mon-Fri 9am-5pm PST)

EMAIL



WhatsApp



Just Scan the QR Code with your iPhone or Android's
Camera to get in touch with us.

redtiger.cam@gmail.com

USER MANUAL

INDEX

Pre-Cautions	2
Package Contents	4
Product Overview	5
About the Micro SD Card	6
Installation	8
Key Functions	9
About WIFI & APP	10
One year Limited Warranty	16
Product Specifications	17
Contact Us	18

Pre-cautions

Please read this manual very carefully before using the camera or installation and keep it safe for future reference. It will be helpful if you have any questions or encounter any operational problems.

Warnings

Failure to comply with safety warnings and regulations can result in serious injury or death.

Please read and understand all instructions before using this product. If any damage is caused by failure to follow the instructions, the warranty will be voided.

- Keep small accessories out of the reach of children.
- Be sure to use accessories and designated parts. Using non-designated parts may damage the equipment or cause fire, electric shock, or malfunction.
- If this product is damaged or malfunctions, stop using it immediately and consult your dealer. Continued use may cause fire, electric shock or vehicle failure.
- If it interferes with driving, please do not install it. This may cause an accident.
- This product is intended to be used as a reference material in the event of an accident. We do not guarantee its effectiveness as complete evidence.
- Please note that this product may infringe on privacy and other rights depending on how it is used. We are not responsible for these cases.
- Since this product uses a wide-angle lens, part of the image may be distorted. It also differs from the actual perspective. This is a characteristic of wide-angle lenses and is not a malfunction.
- Pay careful attention when cleaning the lens surface. Use a soft, moist cloth to clean the lens to avoid scratches that may compromise video quality.

USER MANUAL

- This product is for DC 4.5V / 5.3V vehicles only.
 - The specifications and appearance of this product are subject to change without notice for improvement.
 - Do not expose this product to rain, moisture or water under any circumstances or it will result in external or internal damage.
 - Do not try to open the cover or try to repair it yourself. If the accessories for this device have any problems, please contact the seller for assistance.
 - Do not operate or install the camera while driving, or attempt to change any setting etc. Pull off the road first and only do so when it is safe.
 - Do not drop, puncture or disassemble this product.
 - Do not use the charger if the cord is broken or damaged.
 - Do not disassemble or modify this product. Otherwise, it may cause a fire, electric shock or malfunction.
- Some countries or USA states prohibit drivers from mounting anything on windshield or prohibit mounting on certain area of the windshield.
 - It is owner/operator's responsibility to mount or use of this device in compliance with local laws.
 - The company is NOT responsible for the loss of any data or your content during operation or in any circumstance.

REDTIGER

PACKAGE CONTENTS



Redtiger F3 mini dash cam x 1



Cleaning Cloth ×1



Power adapter x 1



Electrostatic sticker×1



User manual×1




3M Adhesive (sticked to the mounting bracket) ×1



1 x Crowbar

Product overview



About the Micro SD Card

Notice: Before first-time use, you MUST format the memory card in the camera to prevent any errors and for smooth operations.

Always choose a proper micro SD card

- For Dash Cam, micro SD cards are the key accessories. Always use high-quality micro SD cards to ensure that the device can record videos reliably.
- Redtiger Smart Dash Cam F3 supports standard micro SD cards. Please use cards with a capacity of 16GB~128GB and a read/write speed of Class 10 and above. Before using a new card, please format it in the APP.
- When choosing micro SD cards, please choose those purchased through official channels. Poor quality cards may have problems such as the nominal read/write speed does not match the actual read/write speed, and the nominal capacity does not match the actual capacity.

How to use the micro SD cards correctly?

Those tips help to protect both your Dash Cam and the micro SD cards.

- Do not insert or remove the micro SD cards while the Dash Cam is on. Doing so may cause damage to the device and the micro SD cards.
- Please format the micro SD cards when it is used for the first time in the Dash Cam. Formatting the micro SD cards in other devices may cause the file partition difference and the micro SD cards to malfunction.
- In order to avoid slow reading and writing, after a micro SD cards is used for a long time, it is recommended to format it in the Dash Cam every two weeks or so. Formatting deletes all files in the micro SD cards, so please save important videos in advance.

- Avoid to use the Dash Cam in extreme temperature
- Avoid to use the Dash Cam in an extremely high temperature as this may damage the battery of the device.
- If your car still supply power to the cigarette lighter after it is stopped, when it is parked in an area that exposes it to direct sun rays in summer, please plug out the power cable of the Dash Cam to turn the device off.

Installation Tips

About electrostatic Sticker

- Since the adhesive strength is strong on both sides and it is difficult to peel off once it is pasted, it will be troublesome if the pasting the position is incorrect. Therefore we design the electrostatic sticker to be attached to the windshield first then stick the bracket with 3M Adhesive on the electrostatic sticker.
You can easily adjust the location by sticking the 3M Adhesive on the electrostatic sticker and peeling it off.
- To strengthen the fixing forced not attach the main body and leave it for 24 hours at least.
- Re-sticking may weaken the adhesive strength of the tape and cause it to fall off. If you need more accessories please CONTACT US.




CAUTION

- ▶ Connect the cigar plug cord connector in the correct orientation. Connecting in the wrong direction may cause malfunction or damage. If you cannot connect successfully, check the connection part carefully before connecting.
- ▶ Only use REDTIGER's Car Charger, otherwise the camera may frequently reboot or flicker LCD due to insufficient power.


Installation**1 Install the electrostatic sticker**

Clean your windshield and put the electrostatic sticker on the recommended area as shown in the right figure.

Make sure you remove air bubbles between the sticker and the glass.

**2 Stick the camera mount to the windshield**


Peel off the 3M tape attached to the GPS built-in bracket and attach it to the electrostatic sticker on the windshield. Make sure your dash cam body is parallel to the ground.



Press the mount to attach it to the electrostatic sticker tightly.

3 Connect the USB cable to the cigarette lighter receptacle

Align the cable with the top edge of the windshield and fasten it along the passenger's side and the glovebox as shown right.



Connect the cable to the power adapter and insert the adapter into the cigarette lighter receptacle.

NOTE

- The cigarette lighter receptacle might be positioned differently in your car. The picture is provided for reference only.


Key Functions

Dash Cam only has one key, which is the power key. Different functions may be accessed by pressing the power key a different number of times for each function.

NOTE

- The dashcam will automatically turn on after it is powered on, and the shutdown is controlled by the engine or power failure.

Action	Function
Press once	Start / Stop recording
Press and hold 3 seconds	Reset factory settings




REDTIGER

Indicator

The indicator of the dashcam is at the back of the camera.

*After inserting an available microSD card, the Dash Cam automatically enters the recording mode each time it is turned on. A red dot flashes indicating that the video is being recorded.



About WIFI & APP

Install APP

Please use the product with the RedTiger app. To download and install the app, search for "RedTiger" in Google Play Store (Android) or App Store (iOS).

Or you can download the app by scanning the QR code below:

APP QR CODE IMAGE



Hotspot name: REDTIGER-F3_XXX

Default password: 1234567890


How to connect WiFi?

- ① Open the RedTiger app and make sure the dashcamera is being recorded.
- ② Tap the "Connect " on the Camera page.
- ③ Select WiFi named "REDTIGER-F3_XXX"

What kind of operations can I do on the RedTiger app?

- After connect Wifi on the RedTiger app, you can do the following operations:

Preview



Preview what the Dash Cam has recorded. Tap the icon  in the lower right corner for full-screen display.

Take Photo

When the “” button is tapped, the Dash Cam will snap as a feedback. After the photo is taken, and the photo will be stored in the app Camera file and the SD card at the same time.

Start/ Stop Recording

When the “” button is tapped, the Dash Cam will stop recording, and when the “” button is tapped, the dashcam will start there will be a voice prompt “Capture succeeded” recording.

Album

In the preview screen, you can tap the “ Camera file” button to enter the Camera file and view the videos in the Micro SD card.

The Camera file contains the following content:

- Loop(Normal videos)
- Snapshot(Photos)
- Locked(Emergency videos)

After entering the specific album list, you can view the content or download it to your mobile phone's local album. Then you can edit your download files and share them in the APP interface.

Camera Settings-Video

In the preview screen of the app, you can tap the “” icon in the upper right corner to enter the setting screen, where you can set various functions of the Dash Cam.

Here are parts of the instruction Camera Settings page:

- Speaker Volume Control
- Video resolution select (720P, 1080P, 1440P, 1600P): you can adjust the video resolution according to your needs and SD card capacity reference below:

Capacity of Micro SD card	Resolution			
	720P	1080P	1440P	1600P
32GB	≈7.8h	≈4.9h	≈4.3h	≈4.0h
64GB	≈15.6h	≈9.9h	≈8.7h	≈8.0h
128GB	≈149.3h	≈19.8h	≈17.4h	≈16.1h

**This data is given for reference only.*

- Loop Record Options : you can change the duration of each recording (1Minutes, 2Minutes, 3Minutes) by this option.
- Anti Flicker select (50Hz, 60Hz)
- Turn on & off WDR

REDTIGER

- Video time Option, you can choose “Date ” & “Date+Model ”&“ off ” .



- **How to return factory setting?**

You can do the any of the followings:

- 1 Press the key on the dashcam and hold 3 seconds, there will be a voice prompt “Reset factory settings”.
- 2 After connecting with the dash cam on the REDTIGER app, go to “Camera Settings” to return factory setting.

- **How to format a micro SD card?**

After connecting with the dash cam on the REDTIGER app, go to “Camera Settings” to format the microSD card.

- **How to set the collision sensitivity of the dash cam?**

Go to “Camera Settings” - “Collision sensitivity” to set the trigger sensitivity of the acceleration sensor which can trigger automatically emergency video saving when collision happens.

Options include:

High: high sensitivity. low-speed collision will also trigger automatically emergency video recording.

Middle: middle sensitivity (default option).

Low: Low sensitivity. Only severe collisions trigger automatically emergency video recording. Low-speed collision or light touch won't.

Off: close automatically and save the emergency video. Videos are saved in the normal video directory.

Due to the difference between vehicle collision and friction conditions is very big, so do not make sure every collision is bound to trigger automatically save emergency video, so in the case of an accident, please backup exported key video to mobile phones, computers, and other media.

● **Can the Wi-Fi password of the dash cam be modified?**

You can modify the dashcam Wi-Fi password in the app on your phone.

After entering the app, select "Camera Settings" - "Wi-Fi password" and set a new Wi-Fi password then submit.

After modifying the dash cam's Wi-Fi password, the phone needs to reconnect to the dash cam's hotspot with the new password.

LIMITATIONS / DISCLAIMER OF WARRANTY / LIABILITY

- ① Company shall not be liable/responsible directly or indirectly for any claim for compensations, damages, any losses etc. Under this "Limited Warranty" due to inconvenience, loss of time, loss of profits, loss of business opportunity, loss of data, loss of goodwill, work stoppage, any personal and / or commercial loss, compensation for mental agony, anxiety etc. Resulting from the use of the product(s) or any direct or indirect loss of any nature whatsoever (incl. any personal injury or death).

REDTIGER

- ② Except for the warranties set forth herein, company disclaims all other warranties, expressed or implied or statutory, including but not limited to the implied warranties of merchantability or fitness for a particular purpose.
- ③ The maximum liability of company under any circumstances shall be limited to an amount equal to the invoice amount paid by the purchaser to company or a company authorized reseller for the Product(s).

Safety and Legal Aspects

- ① All rights are reserved. Duplication, transfer, distribution of the contents herein in any manner without the prior written permission of is prohibited. reserves the right to add, modify or delete, any of the contents herein or withdraw this documents at any time without prior notice and without assigning any reasons thereof.
- ② Please check your local or state laws before using in car recording device. It is user's responsibility to comply with all local and state laws.
- ③ Dash Cam must be placed at proper location so it does not obstruct your view while driving.
Do not use or manipulate any functions or any accessories of Dash- Cam while driving. Distraction is a leading cause of accidents.

ONE YEAR LIMITED WARRANTY

We are committed to giving customers the best product experience and after-sale service.

We would like to provide One full year of limited warranty for your product from the date of purchase to be free from defects in materials and craftsmanship.

Please CONTACT US with your online order, and we will provide free replacement and lifetime technical support. Besides, you can also get free accessories from us.

Product Specifications

Model	F3
Power	12V/24V
Aperture	1.55
Battery	Super capacitor
Video Format	Video: TS
Loop recording	1/2/3mins
Recording method	Nomal recording / Emergency recording
Resolution	720P/1080P/1440P/1600P
Audio	Support sound recording and playback
Micro SD card	Micro SD 4GB-128GB
Record photo Production method	Computer / Smartphone
Temperature	-20°C~70°C
Warranty period	1 Year

Have questions about
REDTIGER F3?



Check us out here!
We have professional customer service!

Email: help@redtigercam.com
Website: <http://www.redtigercam.com/>

Phone: +1 888 966 8028
(Mon-Fri 9am-5pm PST)

Facebook



LINE



WhatsApp



EMAIL



Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter