



OHR554

TWS Wireless Headset

FCC ID: 2A2P5-1-OHR554

User Manuals

Product structure diagram



- 1.Function Key(Touch)
- 2.Charging compartment display
- 3.Charging Case
- 4.Charging port

Tips:

Gently place the earphones into the external ear canal and adjust the earphones after insertion
Adjust the wearing angle to a comfortable angle.

Preface

Thank you for purchasing an Acer product. For best results, please read this manual carefully before use.

Switch on/off

Switch on: Open the charging case lid, remove the earbuds from the charging case, or press and hold the left/right earbud for 3 seconds to automatically power on the earbuds.

Switch off: Place the earbuds in the charging case. The earbuds will power off. Once fully charged, the light will turn off.

Connection Operation

Wireless Connection: Open the Wireless Settings page of Settings to search and operate.

Answer/hang up

Incoming call: Click either earbud.

During a call: Press and hold any earbud function button for 2 seconds.

Play/Pause

In music mode: Double-click any function button on the headphones.

Volume control

In music mode: Volume Up: Click the right ear function button. Volume Down: Click the left ear function button.

Up/Down Curve Control

In music mode: Press and hold the left/right ear function button for 2 seconds.

Special mode

To summon the voice assistant: Press any headphone function button three times.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can receive and radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause intermittent operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 10cm between the radiator and your body.

Safety Guidelines

1. Fully charge the product before first use.
2. This product is not a toy. Children under 12 must use it under adult supervision.
3. Equipped with a long-lasting battery, charge at least once a month if left unused for extended periods.
4. Use only a 5V/1A charger from an authorized manufacturer with safety certification. Avoid fast chargers supporting high voltages to prevent damage.
5. Do not use the included charging cable to charge other devices.

After-sales Customer Service Number:

- | | |
|------------------------|-----------------------|
| 1. (978)230-8895(US) | Mon-Fri: 9am-6pm(EST) |
| 2.+0211 4187 3343(DE) | Mon-Fri:9am-5pm |
| 3.+0203868 3233(UK) | Mon-Fri:9am-6pm(GMT) |
| 4.+81090-9873-0969(日本) | 月~金:午前9時~午後6時 |
| 5.+61 451 8926 82(AU) | Mon-Fri:9am-6pm |

For any product-related issues or concerns, please reach out to our after-sales service team at the following email address:

- 1.For Temu and other purchases: shopify@newease.cc
- 2.For Amazon purchases: NE_hub.service@acergadget.com

Scan the code to view the multi-language instruction manual

