


Wireless Earphones

- 2x2pcs
- 1x1pcs
- 1x1pcs
- 1x1pcs
- 1x1pcs

Description
Smartphone is a wireless connectivity-enabled audio product compatible with Android and iOS smartphones, tablets, and other electronic devices. By eliminating the constraints of traditional wired connections, it offers users enhanced convenience and unrestricted access to a wide range of application scenarios.

Specifications
 BS
 Weight:34.7g
 Port: type-c
 Size:23*15*17mm
 Case size: 49*49*30mm



Icon	operate	Light	Tone
name	OHR501		
not	Open the lid of the charging case and take out the two earphones to automatically enter the pairing state, with the white and blue lights flashing rapidly. Long press the touch button of the earphone for 3 seconds to manually power on.	White and blue lights flashing alternately	power on/开机
down	Put the earphones into the charging compartment to enter the charging state and automatically power off to disconnect the connection, with the white and blue lights flashing quickly three times and then extinguishing. Long press the touch button of the earphone for 5 seconds to manually power off.	white lights flash three times	power off/关机
left the names	After powering on, the left and right earphones automatically enter the pairing mode.	Pairing status: White and blue lights flashing alternately	
ed prompt	After the left and right earphones are successfully paired and in the unconnected device state, double-click any earphone to switch the prompt language.	White light flashing	English/中文
device activity	After the earphones are successfully paired, they automatically enter the waiting connection state. Open the Bluetooth list of the smart device, search for "OHR501" and click to connect. After the successful connection between the earphones and the smart device, there will be a prompt tone.	Left and right earphone lights extinguished	Connected/ 连接成功
ause	In the connected state and when playing music, click the touch button of any earphone	/	/
song	In the connected state and when playing music, double-click the touch button of the left.	/	/
song	In the connected state and when playing music, double-click the touch button of the right.	/	/
the time	In the connected state, triple-click the touch button of the right earphone.	/	/
the ne	In the connected state, triple-click the touch button of the left earphone.	/	/
assistant	In the connected state, long press the touch button of the earphone for 2 seconds.	/	Ding
ing Call	In the incoming call state, click the touch button of any earphone.	/	Phone ringtone

set parameters

Model: CHRS01	10. Horn rated power :5mW
Version : Bluetooth 5.4	11. Headphone battery capacity :3V/50mAh (polymer)
Codec :AAC/SBC	12. Charging bin battery capacity :3V/300mAh (polymer)
Transmission distance :10m	13. Charging interface :USB Type-C
Frequency :2.402GHz~2.480GHz	14. Headset use time :~5-6 hours
Response range :20Hz~20KHz	15. Earphone single charging time :~1hours
Impedance :16Ω	16. Charging time :~1hours
Frequency :30dB ±3dB	17. Charge the headset: About 2 times
Charging : 320mAh±5%	18. Shutdown standby time :~3000 hours

	Cause	Resolution
Phone on	The headphones are low on battery	Charge the headphones
Phone on	The headphones are low on battery	Charge the headphones
Phone is	The headphones were not put away	Adjust the position where the headphones are placed
Power off	Automatic low battery	Charge the headphones
	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment
Surround headphones	Serious external interference or too far away from the phone	Change the location or be closer to your phone
Party's get	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear or volume
Phone is not	Serious external interference or too far away from the phone	Choose a distraction-free environment or be closer to your phone

5. This product has a built-in non-removable rechargeable battery, discharging of the earbuds will lead to a decrease in battery performance.

- 6. This product comes with a healthy battery, if it has not been used, it will charge it at least once a month.
- 7. If you feel skin discomfort when wearing it due to individual differences, please wear it and consult a doctor.
- 8. When using this product with Bluetooth connection, please adjust to an appropriate volume to avoid hearing damage caused by long-term use. If you use this product while engaging in activities that require your attention to your own safety and the safety of others, such as driving, road construction, walking, or walking, you should reduce the volume to ensure that you can hear the sounds around you, in signals.

1. Before using this product for the first time, please fully charge it before using it.
2. The product is not a toy, and children under the age of 12 must be used under the supervision of adults.
3. Please use a 5V/1A charger that has passed the safety certification of a regular manufacturer to avoid damage to the product caused by a fast charging charger that supports high voltage.
4. Please charge in a safe environment, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid damage to the charging battery caused by long-term charging. The charging method of the charging case is the Type-C interface.
5. This product has a built-in non-removable rechargeable battery, and repeated charging a discharging of the earbuds will lead to a decrease in battery performance over time, which is normal for all rechargeable batteries.
6. This product comes with a healthy battery, if it has not been used for a long time, please charge it at least once a month.
7. If you feel discomfort when wearing it due to individual differences, please stop wearing it and consult a doctor.
8. When using this product with Bluetooth connection, please adjust the sound of the earphone to an appropriate volume to avoid hearing damage caused by long-term loud volume.
9. Please do not use this product in dangerous areas, such as construction site, please also pay attention to your own safety and the safety of others, such as when driving or cycling, roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warning signals.
10. Please follow the relevant regulations of your region or country and use this product as required when driving.
11. This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using the product.
12. It is recommended to use this product in an environment with a temperature of -0°C~45°C. When the ambient temperature is below -5°C, battery performance is limited.
13. Do not use this product in places where it is expressly prohibited to use wireless equipment. It will interfere with other electronic equipment or cause other dangers.
14. Before approaching medical or industrial equipment or boarding a plane, please ask the local staff if they can use it.
15. Before cleaning and maintaining this product, stop using this product, turn off the power, and disconnect all connections or cables to other equipment.
16. Please dispose of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electronic and electronic equipment, parts, batteries and other household waste.

- ## Warning
-
- Do not use abrasive cleaners to clean this product.
 - Do not allow this product to be heated or close to a fire source, such as a cooking stove.
 - Do not expose the product to direct sunlight for a long time.
 - Do not discard this product in fire to avoid explosion.
 - Do not attempt to disassemble this product to make any modifications, as it does not contain any maintenance components.
 - Do not use this product in rain.
 - If you do not plan to use this product for a long time, please store it in a dry environment and charge the headset less often to prolong its life and avoid extreme temperature and dust.
 - Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.
 - Batteries may explode if not handled properly.
 - Do not disassemble or dispose of batteries in fire.
 - Do not short external contacts, crush, puncture or otherwise tamper with batteries.
 - Follow local regulations when disposing of used batteries.

- Do not use abrasive cleaners to clean this product.
- Do not allow this product to be heated or close to a fire source, such as a cooking stove.
- Do not expose the product to direct sunlight for a long time.
- Do not discard this product in fire to avoid explosion.
- Do not attempt to disassemble this product to make any modifications, as it does not contain any maintenance components.
- Do not use this product in rain.
- If you do not plan to use this product for a long time, please store it in a dry environment and charge the headset less once to prolong its life and avoid extreme temperature and dust.
- Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.
- Batteries may explode if not handled properly.
- Do not disassemble or dispose of batteries in fire.
- Do not short external contacts, crush, puncture or otherwise tamper with batteries.
- Follow local regulations when disposing of used batteries.

Equipment has been tested and found to comply with the limits for a B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Warning: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

equipment complies with FCC radiation exposure limits set forth in an uncontrolled environment, This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

