



OHR620
OWS Wireless headset
2A2P5-OHR620

User Manual

Please read this user manual carefully when using this product.

Preface

Thank you for purchasing Acer products. For optimum operation, please read this manual carefully before using.

Model

OHR620

Item Name

OWS Wireless headset

Product List

Earphones Headphones x2

Charging case x1

Type-C charging cable x1

Instruction manual x1

Product Description

This OWS earphone is a wireless connectivity-enabled audio product, which is compatible with Android and iOS smartphones, tablets, and other portable electronic devices. By eliminating the constraints of wired connections, it offers users enhanced convenience and unrestricted mobility, catering to a wide range of application scenarios.

Product Specifications

Material:ABS


Product Weight:54g

Charging port:Type-C

Earphones Size:41*44*11mm

Charging case size:52*52*31mm

Product structure diagram



- 1. Headphone Indicator Light
- 2. Function Touch Control
- 3. Charging Port
- 4. Charging Case

Tips:

Gently place the earphones into the external ear canal and adjust the earphones after insertion. Adjust the wearing angle to a comfortable angle.

Wireless headphone parameters:

1. Wireless version: V5.4
2. Connection method: Wireless audio receiver.
3. Communication distance: Approximately 10 meters (in an open and unobstructed surroundings).
4. Talk time: About 3 hours.
5. Music playback time: About 4 hours (at medium volume).
6. Frequency response range: 20Hz - 10KHz.
7. Product material: Plastic.
8. Wearing style: Hanging-ear style.

Operation Instructions:

1. Wireless connection: On Android/iOS platforms, search and perform operations in the Wireless settings page of your mobile phone.
2. Charging: Put the earphones into the charging case and turn off the earphones. The indicator light on the charging case will light up, and the indicator light will go out when fully charged.

Multifunction key:

1. Power On: Take the earphones out of the charging case / long-press the touch position for 5 seconds, and the earphones will turn on automatically.
2. Power Off: Put the earphones into the charging case, or long-press the touch position for 5 seconds, and the earphones will turn off automatically.
3. Play/Pause: Single-click the function key of either the left or right earphone.
4. Answer Incoming Call / End Call: Single-click the function key of either the left or right earphone.
5. Volume Up / Volume Down: Triple-tap the function key on the left earphone / right earphone.
6. Switch to the Next Track / Previous Track: Double-click the function key of the right/left earphone.
7. Voice Assistant: Long-press the function key on the left/right earphone for 3 seconds.

Note: This product can be connected and used with any device equipped with Wireless functionality.

Safety guidelines

1. Before using this product for the first time, please fully charge it before using it.
2. The product is not a toy, and children under the age of 12 must be used under the supervision of an adult.
3. Please use a 5V/1A charger that has passed the safety certification of a regular manufacturer to avoid damage to the product caused by a fast charging charger that supports high voltage
4. Please charge in a safe surroundings, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid damage to the battery caused by long-term charging. The charging method of the charging case is the Type-C interface.
5. This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the earbuds will lead to a decrease in battery performance over time, which malformation nonchargeable batteries.
6. This product comes with a healthy battery, if it has not been used for a long time, please charge it at least once a month.
7. If you feel skin discomfort when wearing it due to individual differences, please stop wearing it and consult a doctor.
8. When using this product with Wireless connection, please adjust the sound of the earphones to an appropriate volume to avoid hearing damage caused by long-term loud volume.
9. If you use this product while engaging in activities that require concentration, you should pay attention to your own safety and the safety of others, such as when driving or cycling, on roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warning signals.
10. please follow the relevant regulations of your region or country and use this product as required when driving.
11. This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using or placing the product.
12. It is recommended to use this product in an surroundings with a temperature of -0°C~45°C When the ambient temperature is below +5°C, battery performance is limited.
13. Do not use this product in places where it is expressly prohibited to use wireless equipment otherwise it will interfere with other electronic equipment or cause other dangers.
14. Before approaching medical or industrial equipment or boarding a plane, please ask the local staff if they can use it.
15. Before cleaning and maintaining this product, stop using this product, turn off application, and disconnect all connections or cables to other equipment.
16. Please dispose of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electrical and electronic equipment, parts, batteries and other household waste.
17. The power delivered by the charger must be between min 5 Watts required by the radio equipment, and max 10 Watts in order to achieve the maximum charging speed.
18. Regarding the rechargeable headphones, please use our company's standard USB cable or the designated charging cable to charge the headphones.
19. To ensure the normal operation of the headphones, please make sure the headphones have sufficient power.
20. Please use a charger with the specification of 5V 1A.

Warning

- Do not use abrasive cleaners to clean this product.
- Do not allow this product to be heated or close to a fire source, such as a cooking stove.
- Do not expose the product to direct sunlight for a long time.
- Do not discard this product in fire to avoid explosion.
- Do not attempt to disassemble this product to make any modifications, as it does not contain any maintenance components.
- Do not use this product in rain.
- If you do not plan to use this product for a long time, please store it in a dry surroundings and Charge the headset less once to prolong its life and avoid extreme temperature and dust.
- Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.
- Batteries may explode if not handled properly.
- Do not disassemble or dispose of batteries in fire.
- Do not short external contacts, crush, puncture or otherwise tamper with batteries.
- Follow local regulations when disposing of used batteries.
- The power delivered by the charger must be between min [5] Watts required by the radio equipment, and max[10] Watts in order to achieve the maximum charging speed.



FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.5m between the radiator and your body.

CE Declaration of Conformity

Hereby, Acer Gadget Inc. declares in compliance with the essential requirements and the other relevant provisions of the Radio Equipment Directive 2014/53/EU and RoHS Directive 2011/65/EU.

Disposal of Waste Equipment by Users in Private Households in the European Union

This symbol on the product or its packaging indicates that this product must not be disposed of with other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the store or the shop where you purchased the product.

