
S5 说明书

尺寸：65*105mm

材质：双面印刷，风琴折，128g铜版纸

acer
Gadget



Wireless Charging Station

S5

1


Product Specifications

Product Name	Wireless Charging Station
Product Model	S5
Wireless Output 1(for Phone)	25W Max
Wireless Output 2(for Phone)	7.5W Max
Wireless Output 2(for Earbuds)	3W Max
Wireless Output 3(for Watch)	3W Max
Product Size	166 × 98.9 × 169mm
Product Weight	421g
USB-C Input	15V ⎓ 3A
USB-C Output	5V ⎓ 1A
USB-C Cable Output	5V ⎓ 2A, 9V ⎓ 2.22A
Total Output	Max. 30W (For Input DC 15V)

Contents

1. Wireless Charging Station x 1
2. Charging Cable x 1
3. Charging Adapter x 1
4. User Manual x 1
5. Warranty Card x 1

Product Overview



2


Instructions For Use

1. Wirelessly charge up to three devices simultaneously: a phone, a watch, and earbuds case.
2. Power On: Use the included adapter and Type-C cable.
3. Place and charge:
- Top area: For Phone
- Bottom circular area: For Phone/Earbuds
- Left circular area: Works with Apple Watch and Samsung Watch.

4. Night Light Controlled via the bottom night light touchpad:
- Single-Touch Control:
 Power On (Cool White Light) -WarmYellow Light - Warm White Light - Power Off
- Long Press Touch: Increase/Decrease Brightness

Built-in retractable cord control

- The retractable cable can charge phones, tablets, and other devices, with up to 20W wired output.
- After stretching to the desired length, release the tension and lock at the fixed length (maximum 70cm).
- To retract, simply pull **gently** to automatically retract the cord.




3

Indicator Status

Mode	LED Status
Power ON	All three indicators turn on for 3 seconds, then turn off.
Phone Charging	Indicator 1 turns on for 30 seconds, then turns off.
Phone / Earbuds Charging	Indicator 2 turns on for 30 seconds, then turns off.
Watch Charging	Indicator 3 turns on for 30 seconds, then turns off.
Charging Error	The corresponding indicator light will flash until the error is cleared.

Charging Indicator Light



4

⚠ IMPORTANT SAFETY INSTRUCTIONS

Warning: Failure to follow these safety instructions could result in fire, electric shock, personal injury, or damage to the product or other property.

1. Use Certified Power Accessories Only
Always use the included cable and adapter, or those certified by local safety authorities (e.g., FCC, CE, BSMI). Strictly prohibit the use of uncertified, substandard, or mismatched high-power chargers and cables, which may cause product damage or hazards.

2. Strictly Prohibit Foreign Metal Objects (FOD)
Never place any foreign metal objects (such as coins, keys, RFID/induction cards, or phone cases containing metal components) between your phone and the wireless charging area. Doing so will cause the metal object to heat up rapidly, potentially leading to severe burns or fire.

3. Ensure Precise Alignment with the Charging Coil
Please make sure your phone supports wireless charging. This product transmits power wirelessly over a short distance through inductive coupling between charging coils. Align the center of your phone with the charging coil in the wireless charging pad. Misalignment may significantly reduce charging efficiency, interrupt charging, or cause abnormal device heating.

4. Avoid Charging in High-Temperature or Confined Spaces
Always charge the device in a well-ventilated area. Do not use the wireless charger in enclosed or poorly ventilated environments, such as inside a car under direct sunlight, on a bed, under blankets, or inside a bag. Excessive heat buildup may cause thermal runaway.

5

5. Keep Away From Moisture and Wet Environments
Do not use the product in damp locations such as bathrooms or near sinks. Never plug or unplug the power adapter with wet hands to prevent moisture from penetrating internal circuits, which could cause leakage, short circuits, or electric shock.

6. No Self-Disassembly or Use of Damaged Units
Do not attempt to disassemble, modify, or repair this product yourself. Stop using the device immediately and disconnect the power if you notice any physical damage (e.g., cracked housing, deformed pins, frayed cables) or operational anomalies (e.g., strange noises, burning odor, or smoke).

7. Medical Device Interference
This product contains magnets and radios that emit electromagnetic fields, which may interfere with medical devices such as implanted pacemakers and defibrillators. Maintain a safe distance of at least 12 inches / 30 cm between this wireless charger and your medical device. Consult your physician and medical device manufacturer for specific guidelines before use. If you suspect interference, stop using the device immediately.

8. Child & Pet Safety
This product is not a toy and contains internal electronic circuitry. Keep out of reach of children and pets. Ensure children do not play with the device or insert foreign objects into the USB ports and charging areas.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

6

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this product.

7

Warranty & Customer Service

Thank you for purchasing our product. We provide comprehensive after-sales service to ensure you have an excellent user experience. To safeguard your rights, please read the following warranty instructions carefully:

1. This product offers a one-year warranty service under non-human factors:
 (1) Returns and Exchanges: Supported within one month of purchase.
 (2) Free Repairs: Supported within one year of purchase.

2. The warranty does not cover:
 (1) Damage caused by improper use or unauthorized disassembly of the product.
 (2) Product malfunctions caused by repairs not authorized by our company.
 (3) Damage or malfunctions caused by external forces or other human factors.
The warranty period starts from the date of purchase. Please provide proof of purchase when seeking repairs. If proof of purchase is unavailable, the warranty period will be calculated from the manufacturing date.
This product is covered by LOCAL WARRANTY ONLY, valid only in the country/region where you purchased this product. For any warranty service, please contact your local dealer directly.

3. For repairs and related inquiries, please contact our service email:**support@szjltech.com**

Made in China

8