





Introduction

The P5D2 is a wireless conference speakerphone that delivers high quality and crystal clear audio for efficient meeting. The high USB speakerphone lets you take audio conferencing freely.




DE 1

Hardware Overview




DE 2

Button Function




DE 3

Status LED




DE 4

Option 2: Connect to your computer through USB Dongle




DE 5

Option 3: Connect to your computer or mobile device via Bluetooth




DE 6

Charging the Speakerphone




DE 7

Status




DE 8

Checking Battery Level




DE 9

Troubleshooting



DE 10

Support and Other Resources




DE 11

Einführung




DE 12

Hardware-Übersicht




DE 13

Tastenfunktionen




DE 14

Status LED



DE 15

Option 2: Verbinden Sie mit Ihrem Computer über einen USB Dongle




DE 16

Option 3: Verbindung zu Ihrem Computer oder Mobilgerät über Bluetooth




DE 17

Aufladen der Freisprechanlage




DE 18

Prüfen des Batteriestands



DE 19

Fehlerbehebung




DE 20

Support und andere Ressourcen




DE 21

Introduction




DE 22

Aperçu du Matériel




DE 23

Fonction des Touches




FR 1

Statut des Indicateurs LED




FR 2

Option 1: Connexion avec un ordinateur à l'aide d'un câble USB




FR 3

Option 2: Connexion avec un ordinateur ou un appareil portable via Bluetooth




FR 4

Chargement du Haut-Parleur




FR 5

Vérification du Niveau de la Batterie




FR 6

Dépannage




FR 7

Support et Autres Informations



FR 8

Compliance Information



FR 9

CE



FR 10