

Instruction

Website: <http://www.szrdcj.com>

CONTENTS

Warnings and safety precautions.....1

Turn on

Android Touch.....2

Accessories and attachments.....3


Customer Service.....4

Warnings and safety precautions


- 1、 Before operating and using the product, please read the instruction manual carefully and keep it well for future use.
- 2、 Turn off immediately and pull out the fixing plug when the machine makes abnormal noise or smell. When a fault appears in the machine, stop using the machine and contact the maintainer to check.
3. If the machine is not used for a long time, turn off the power and pull out the fixing plug. Disconnect the machine from the antenna during stormy seasons.
- 4, For safety reasons, please keep the machine away from flammable and explosive materials, candles, electric stoves, light bulbs, etc.
- 5, please take care to prevent the liquid and metal from entering the machine, once this happens, do not turn on the power and need professional inspection as soon as possible. Be sure to keep the machine away from water and wet areas, such as bathtub, kitchen, sink, wet basement or near a swimming pool.
6. Do not place this product on an unstable cart, shelf, tripod, stand, or table in case the machine tips over. Move carefully when the machine is placed on a cart. Quick stops, excessive force, or uneven surfaces can cause the cart and machine to tip over.
- 7, do not put debris into this product through a crack or hole. Otherwise, the machine will probably come into contact with dangerous voltage points or protruding parts, which may cause fire or electric shock.
- 8、 Users are not allowed to disassemble or repair the product without permission.
- 9、 When users install this product, please follow the manufacturer's instructions

Android touch

- 1) Screen rotation: Setting -- Display -- Screen rotation
- 2) Wi-Fi and network: setting -- Wi-Fi/LAN
- 3) System: Setting -- About
- 4) Sync on/off: Desktop applications -- Sync application on/off
- 5) Navigation bar: drag from the bottom of the screen to call up the navigation bar.
- 6) Interfaces: different sizes of machines, the quantity and type of interfaces interfaces can be different.



- 7) Applications office:



Accessories and attachments

Wall Machine:

Wall mounting bracket, wall mounting screw kits, instructions, warranty card.

Option:

If users need to purchase a suspension bracket, please contact customer service.

And if the suspension bracket used by users is not from us, but from other suppliers, the damage to the machine is not covered by the warranty.

Make sure to install the machine by qualified technicians. Incorrect installation may cause the product to fall down or be damaged, etc.

After-sales service and warranty period

1.Details of the host machine and accessories

1.1 Touch screen part: display screen, backlight components, path components, cross flow board components, motherboard components, etc.

1.2 The built-in operating system and some software defects are not covered by the warranty.

2.Installation Policy

2.1 For consumers of all-in-one touch machines, our company does not provide free on-site installation and debugging services. If these services are requested, a corresponding service fee is required.

2.2 For special installation services, such as special wall surfaces made of glass, marble, porcelain, cavity wall, ceiling lifting, lifting and other special installations, additional fees must be negotiated separately.

3.warranty period

3.1 The period of validity starts from the date of delivery signed by the consumers. For consumers who do not require delivery, installation and debugging, the validity period begins on the day the products leave the factory.

3.2 If quality problems such as design, manufacturing, operation or procedure occur during the warranty period, we will assume full responsibility and bear all economic losses incurred.

The company reserves the right of final interpretation of this instruction

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.