


Discover your new IT-801 tablet

Thank you for purchasing **IT-801** . To turn on your tablet, press and hold the power button for few seconds. To turn it off, press and hold the same button until the Power Off and Reboot options appear on the screen.



Introducing IT-801

- 1.VOL-
- 2.VOL+
- 3.Reset
- 4.Power
- 5.Front Camera
- 6.Micro SD
- 7.Type-c
- 8.Earphones
- 9.MIC
- 10.Speaker

IT-801 Features

· 8 " HD
· 800x1280

· RAM 2GB
· ROM 32GB

· WIFI Supported

· Front: 2MP Rear: 5MP

· Accelerometer G-SENSOR

· JPG, GIF, BMP, PNG

· Charger
· Type-c Cable
· Quick Start Guide
· Warranty Card

· 121.3x201.8x8.9mm
· 328g

· Quad Core 1.6GHz

· 4000mAh
· 3 hrs Video

· Type-c OTG
· Audio Jack 3.5mm
· Micro SD (up to 64GB)

· Multi-user

· Android 9.0

· MPEG-1, MPEG-2, MPEG-4 SP/ ASP-
GMC/ DIVX3, H.263, H.264 BP/ MP/ HP,
XVID, H.263, WMV7/8, WMV9/ VCJ BP/
MP/ AP, VP6/8, AVS, JPEG/ MJPEG,
3GP, AFS, FLV, MPG, TS, VOB
· MP2, MP3, WMA, OGG, APE, FLAC,
AAC, M4A, MA4, 3GP, WAV

Safety Measures

- Do not expose your **IT-801** to high temperatures, humidity or dust. Avoid direct sunlight.
- Do not drop the tablet as it may cause damage or malfunction.
- Use at an appropriate volume levels and do not use headphone with high volumes levels.
- Do not disconnect your device when it is in file transfer mode. Sudden disconnects could cause system errors.
- Do not disassemble the device by yourself. Please seek help or assistance from our qualified personnel.
- Do not use liquid such as alcohol, thinner or benzene to clean your device.
- Do not use the device in places where electronic devices are restricted.
- Refrain from using the device while driving or walking.

Charging & Using the Battery

It is recommended to fully charge the battery of your device before using it for the first time. To charge the device, simply plug in the adapter or the USB cable to your table and plug it into the power source.

[NOTE]: To ensure a longer battery life, it is advisable to consume it completely before recharging. In the event that you will not use the tablet for a long period of time, charge and use tablet once a month to avoid damage to your battery. 2. When the battery is fully depleted, connect the device to the adapter and wait for a few minutes before it has enough charge to access its main menu. 3. While charging, the device will go into standby mode until it has sufficient charge. It is advisable to not use the device during charging as its charging time will be greater if the device stays on during charging.

Status and notification icons

Your tablet will tell you what's going on by showing you simple icons. Here's what they mean:

- USB connected
- Battery charge
- Mute mode
- Wi-Fi network
- New Wi-Fi network detected

Setting up IT-801 for the first time usage.

- Unlock your screen

The display of your tablet will lock every time the device went into sleep mode. To unlock it, simply swipe the padlock icon.

- Modify Settings

To modify your desktop, press the Menu Key and you will have access to all the settings or application installed on your device. To configure the main settings such as keyboard, language, sound, brightness & contrast, data usage, Internet, storage options, rotating screen, look for the icon .

- Connecting **IT-801** to a PC

IT-801 offers multiple connectivity options with USB connectivity where you can connect your device to a computer. USB connection notification will automatically display on the screen of your device.

正面

Thank you for using

Getting Connected to the Internet

One of the connectivity option that the **IT-801** gives you is the ability to connect to the Internet via Wi-Fi. In order to do so, you will have to click on the Settings icon, and slide the tab to the right, to enable connection through Wi-Fi. When the wireless connection is on, the tablet will look for and display a list of available wireless networks.

Choose which one of the available connections you would want to connect to. If the network is available for public, or you have the necessary credentials to connect, the tablet will display a message to confirm if you really want to connect to that particular network. Click Connect to confirm your action.

Once the connection to the wireless network has been established, the wireless network signal icon will be displayed at the notification bar.

[NOTE] : If the access point has security settings, you will be required to provide a password.

Surf on the Internet

Once you have connected to the internet, you can use the browser to surf on the websites as you wish.

App Installation

Your tablet has a number of preloaded applications to improve your user experience. Nevertheless, you can download all the applications you want and need. You will have to use the marketplace you will find on your device. Another option is for you to download them directly from the internet, on the official website of each application.

To manage the applications, you have installed (in the event that you, for instance, wish to delete the application) you have to click on the Settings icon, select the Application option, and once there, scroll through for the application you wish to manage.

More info and Support

For more information about our products, practical advices, frequently asked questions, updates, etc.

Tablet instructions

IT-801

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference,
and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.