

Gemini1 SE User Manual



Copyright 2025

All Rights Reserved

User Manual Version 1.0

The information in this document is subject to change without notice and therefore should not be interpreted in any way as a guarantee or warranty by Nebullar. Nebullar assumes no responsibility or liability for any errors that may appear in this document.

Safety Warning

Please insert the AC plug into the AC socket corresponding to the input voltage of the power adapter;

It is strictly forbidden to use it at a site with the existence of any potential explosive gas;

Operating temperature: 0°C~45°C, Storage temperature: -20°C~70°C.
To avoid injury, unauthorized persons shall not open the power adapter;

Revision History

Changes to the draft user manual are listed below:

Revision	Description	Date
1.0	Initial Draft	2025/8/13

Operation of the Gemini1 SE

To power on the unit, Long press the power button located at the side of the machine. When powering the unit on, machine screen will light up.

If the device malfunctions and cannot be shut down by pressing the power button, you can keep holding the power button until the device forces a restart.

This unit is powered by an AC adaptor. Please make sure to insert the AC plug into the AC socket that corresponds to the input voltage of the power adapter.

Packing List

Intelligent Desktop All-in-one Computer
Adapter(Input: AC100-240V Output: 24V/1.5A)

System View

Front View




Rear View





Specifications

Brand	Nebullar
Model	Gemini1 SE
Operation System	Android 15
CPU	A75*2, A55*6
Storage	3GB LPDDR4 + 32G EMMC 4GB LPDDR4 + 64G EMMC
Screen Size	15.6"
Resolution	1080*1920 IPS
Networking	WIFI 802.11 a/b/g/n/ac Ethernet 100Mbps
Bluetooth	Version 5.1
I/O	USBA*3, USBC, RJ12, RJ45, Ear-Jack, MicroUSB
PowerAdapter	Input: AC 100-240V Output: 24V/1.5A

I/O





FCC Regulations

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/ TV technician for help.
- Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To comply with FCC RF Exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for the transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.