

FRONT

HOW TO CHARGE



STEP 1:
Place the product in the charging stand with the power button facing down. Rotate the product until it fully and securely sits in the stand.



STEP 2:
Plug the charging cable into the port on the back of the charging stand.



STEP 3:
Plug the other end into a 5V power source (standard mobile phone charger). The LED light will pulse slowly to indicate charging and turn solid when fully charged.

HOW TO CONNECT



STEP 1:
To detach the g-spot sleeve, hold it firmly over the bullet, and twist the metal handle until you hear a click, then slide the top layer off, revealing the bullet.



STEP 2:
To re-attach the g-spot sleeve, slide it over the bullet. Line up the small tabs on the inside of the g-spot sleeve. You can do this by twisting the handle until the g-spot sleeve falls into place.



STEP 3:
Holding the g-spot sleeve firmly, push the g-spot sleeve and bullet handle together and twist. You will hear a click when the layers attach.

KNOW A HIGHER LOVE

CLEANING:
Be sure to clean thoroughly before and after each use. Clean using mild soap and warm water.

STORAGE:
Store in a cool dry place separately from other sexual wellness devices; devices of different material can damage each other if left in contact.

QUALITY:
This product is manufactured using body-safe silicone that is harmless to the human body; free from phthalates, BPA and latex. Use water-based lubricant only.

CHARGING:
Do not turn on while charging and/or cleaning. While charging, the LED light on the charging stand will pulse slowly and turn solid when fully charged. Use only with 5-volt USB wall adapter (standard mobile phone charger). Low battery alert: Light on device flashes rapidly when battery is running low. Allow 120 minutes for a full charge. Total usage time from full battery on highest setting is 85 minutes.

WARNINGS:
Discontinue use if there is any discomfort for you or your partner. Do not expose device to water while charging.

WATERPROOF:
The bullet and g-spot sleeve are waterproof to IPX7 standards and can be submerged in the bath or shower. Do not expose the charging stand to water.



THE COUPLE
TWO-IN-ONE G-SPOT
AND BULLET MASSAGER

INSTRUCTION MANUAL



Deia

For more information:
Visit deialove.com

FCC Statement
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
1) this device may not cause harmful interference, and
2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement
This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

POWER BUTTON
Press and hold the power button for 3 seconds to turn on. Press firmly to cycle through the 10 settings. Press and hold for 3 seconds to power off.



CHARGING INDICATOR



CHARGING PORT
Plug the charging cable into the port on the back of the charging case and plug the other end into a 5V power source (standard mobile phone charger).



BULLET MASSAGER
for external or anal stimulation



G-SPOT SLEEVE
for internal stimulation



LOCKING TABS
to lock g-spot sleeve



WAYS TO USE

TEASE
Using the bullet, tease your partner by caressing their erogenous zones - behind the ears, sides of the neck, or the back to slowly increase their arousal.



EXPERIMENT
In the mood for anal play? Use the bullet for anal and prostate stimulation by cycling through the various vibration settings to explore a variety of sensations.



GET THERE
Slide the device into your or your partner's vagina and tilt the g-spot massager's handle down to apply direct pressure on the g-spot. Gently rock the g-spot massager back and forth to stimulate the area.



KNOW A HIGHER LOVE

BACK