


90 mm

User Manual

Wireless headphones

Model# EDB0004AYZ, EDB0006AYZ

CONTROLS



- O Button:**
Press: Pause/play music while playing
During a call: short press answer / hand up a call, long press to reject a call
- M Button:**
Long Press: Power ON / OFF
- V+ Button:** Press: Increase volume
Long press: Skip to next track
- V- Button:** Press: Decrease volume
Long Press: Skip to previous track
- 3.5mm AUX Port:**
Power off when audio cable is plugged in
- USB Type-C Charging Port**
- LED Indicator**
- Built-in Microphone**

SPECIFICATION

Battery capacity:200mAh
50% Volume Play Time: 12Hours
Charging Time: 2-3 Hours
Working Distance: ≤ 10m

Wireless version: 5.4
Frequency: 20Hz - 20kHz
Charging port: USB Type-C
Impedance: 32 Ohms

INCLUDES

1 Wireless Headphone
USB Type-C 15cm Charging Cable

GETTING STARTED

Charging the Headphones
Plug the small connector of the included charging cable into the charging port on the headphones. Plug the large connector into the USB port on a computer or a compatible USB adapter (not included) and plug into a wall socket.
The LED indicator on the headphones will turn RED while charging and turn BLUE when finished charging.

Powering ON/OFF

Press and hold the ON/OFF button for 3 seconds to power the headphones ON and OFF. When powered on, the headphones may automatically reconnect to a nearby previously-paired device with Wireless enabled.

Bluetooth Pairing

- Power the headphones ON. A tone will be heard, the LED indicator will flash Blue and Red, and the headphones will enter pairing mode.
- Set your mobile device to search for Wireless devices. When it appears, select "EDB0004A or EDB0006A" from the list of found devices.
- After a successful pairing, a tone will be heard and the LED indicator will turn slowly flash Blue, and you will be able to play music on the headphones.
- When disconnected, a tone will be heard, the LED indicator will flash Blue and Red, and the headphones will enter searching mode.

In Wired mode, the volume cannot be controlled via the buttons on the headphones

Phone Calls

When connected to a phone via Wireless, phone functions can be used on the headphones.
*Press the Power ON/OFF Button to answer an incoming call. Press again to end the call. *Long Press the Power ON/OFF Button to reject an incoming call.

77.7 mm

Connecting with a 3.5 mm AUX Cable

Plug one connector of a 3.5 mm aux cable into the 3.5 mm aux input port on the headphones. Plug the other connector into the audio output port on your media-playing device. In AUX mode, all playback and volume will be adjusted with the controls on your connected device. The headphones will automatically power OFF when a 3.5 mm AUX cable is inserted.



THIS IS A BATTERY-OPERATED PRODUCT. THIS IS NOT A TOY.INTENDED USE OF THE PRODUCT SHOULD NOT RESULT IN EXPOSURE TO THE INTERIOR BATTERY.
In case of abuse, there is risk of rupture, fire, heat, leakage of internal components.

Do not open, disassemble, crush, or burn battery. Do not handle battery in a manner that allows terminal to short circuit. Avoid mechanical damage of the battery. Battery may explode or cause burns, if disassembled, crushed, or exposed to fire or high temperature. Do not short or install with incorrect polarity. Avoid all personal contact, including inhalation. Wear protective clothing when risk of exposure occurs. Use in a well-ventilated area. Prevent concentration in hollows and sumps. Proper Storage: Store in a cool, dry, and well-ventilated area. Keep away from heat, fire, and direct sunlight. Keep out of the reach of children. Disposal considerations: Recycle in accordance with government, state and local regulations, to ensure proper disposal.

If exposed to the battery
First aid measure:

After eye contact:
Flush eyes cautiously with plenty of water for at least 15 minutes, occasionally lifting the upper and lower eyelids to assure adequate flushing. Get medical aid.

After skin contact:
Remove contaminated clothing and rinse skin with plenty of water or shower for 15 minutes. Get medical aid.

After inhalation:
If inhaled, quickly leave the site to fresh air immediately. Administer artificial respiration if breathing is difficult. Get medical attention.

After swallowing:
If swallowed, wash out mouth with water provided person is conscious. Get medical attention.



Battery may burst and release hazardous decomposition products when exposed to a fire situation. Lithium-ion batteries contain flammable electrolyte that may vent, ignite, and product sparks when subjected to high temperature, when damaged or abused (e.g. mechanical damage or electrical overcharging), may burn rapidly with flare-burning effect may ignite other batteries in close proximity.

Specific protective actions for fire-fighters:
Wear positive pressure self-contained breathing apparatus (SCBA). Structural firefighters' protective clothing will only provide limited protection.
Eliminate all ignition sources (no smoking, flares, sparks, or flames in immediate area). Do not touch or walk through spilled material. Absorb with earth, sand, or other non-combustible materials. Leaking batteries and contaminated absorbent material should be placed in metal containers.
Suitable fire-extinguishing media:
Small fire: dry chemical, CO₂, water spray, or regular foam.
Large fire: water spray, fog, or regular foam.

Questions? Comments? Contact contact@culturefly.com

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction.

FCC ID: 2A2WN-SCEJ03
FRN:0031270333