

FRONT

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

We are grateful.

We believe that there's noise within each and every one of us. A burning flame that's constantly pushing us to do everything possible to follow our passions.

Our goal has always been to give you wonderful products equipped with the latest technology that bring out the best in you. We hope we can be an able companion in your journey towards making all your dreams come to life.

Thank you for choosing our product, and a very warm welcome to the Noise family.

Register your warranty.



Your Noise product is covered under a warranty against manufacturing defects for one year after purchase.

Scan the QR code with your smartphone camera or pay us a quick visit at **bit.ly/noisewarranty** to register your product.

noise

BACK

noise

POWER ON

Press and hold the Crown button for a few seconds to turn on the watch.

POWER OFF

Press and hold the Crown button for a few seconds, select 'Power Off' and confirm to power off.

WAKING UP THE WATCH


To preserve battery, the watch screen turns off when not in use. To turn the screen back on, you can wake up the watch by:

- Pressing the Crown button
- Turning on the wrist sense


CHARGING THE WATCH

- Plug the USB cable into a power adaptor.
- Plug the power adaptor into an electrical socket. (Power adaptor not included)
- Place the magnetic charger on the magnetic charging points of the watch.
- Once the battery is fully charged, remove the charger.


Contents



NOISEFIT HALO 3 SMARTWATCH



CHARGING CABLE



PAIR THE WATCH

- Open the NoiseFit app and allow the Bluetooth and GPS positioning to be turned on.
 - Feed in your personal information and health goals in the app.
 - Go to 'Pair Device' page in the app, select the watch name and MAC address and link the watch
- Or you can follow these steps:
- Turn on the watch.
 - Scan the QR code from the NoiseFit app on your phone.
 - Select Pair with device and wait for it to pair.



SCAN TO DOWNLOAD THE APP


Noise User manual

For the detailed user manual, scan the QR code and search "NoiseFit Halo 3" user manual.

USER MANUAL



noise



NoiseFit
Halo 3

Please refer to this User Manual before using the product.