





I . Product Introduction

1. Packing List




2. Product Buttons Overview




II. Direction For Use

1.Buttons Instruction




NOTE: When the Product is turned on, the bluetooth is also automatically turned on. You can search for the bluetooth name "K1", and connect to it to play the music in your cell phone via bluetooth.

(b)Play/Pause Music
In the state of playing music, short press the button to play/pause the song.




(b)Next Music: When playing music, Press and hold for 2-3 seconds to play next song.



(b)Lights ON/OFF: Press and hold for 2-3 seconds to turn on/off the LED dancing light.


3. Microphone Instruction



ON/OFF Button
Long press: Long press for 2-3 seconds to turn on/off the microphone.

Short press: Short press to enter the Reverb volume, music volume, mic volume.

Double-click: When playing music, Quickly double-click to play/pause the song.



(b)Long press: When playing music, Press and hold for 2-3 seconds to play next song.

Volume- & Previous Music Button
(a)Short press: Short press this button to lower the volume of the microphone.
(b)Long press: When playing music, Press and hold for 2-3 seconds to play previous song.

Sound Effect Mode & Play/Pause Music Button
(a)Short press: Microphone sound mode switching (magical voice 1/2/3/4/Original singing mode)
(b)Long press: Long press for 2-3 seconds to turn on/off the microphone.

(b)Double-click: Original sound on/off.

Microphone Indicator
(a)Blue indicator light: Blue light flashing in unconnected stade,blue light is always on when connected successfully.
(b)Red indicator light: Red light is on when charging, and red light is off after full charge.

III. Use The Microphone Correctly



IV.Frequently Asked Questions

- Bluetooth can't be paired
(a)Distant Bluetooth connection, Try to adjust the distance between the Bluetooth Speaker and the mobile phone.
(b)The Bluetooth Speaker has been paired with other mobile phones: first turn off the Bluetooth of other mobile phones, then restart the Bluetooth Speaker and try to pair with the mobile phone again.
- The microphone produces no sound
(a)Try to fully charge the microphone before using it.
(b)Try to turn up the volume of the microphone and try again.
(c)Try to restart the Bluetooth Speaker and microphone and try again.
- The speaker produces no sound during playback
(a)Check whether the Bluetooth connection is successful.

(b)Check whether the volume of the mobile phone has been turned up.
(c)Short press(+) of the Bluetooth Speaker to trun up speaker's volume.

4.Presence of noise
(a)Environmental noise and mobile phone signal interference, adjust the distance between the Bluetooth Speaker and the mobile phone.
(b)Adjust the distance between the Bluetooth Speaker and the microphone.

5. Plug in Instruction
①Please fully charge the Product before first use;
②Please DO NOT dismantle,crash,squeeze the Product, or throw the Product into fire. if there is severe swelling and heat, please do not continue to use it;do not place it in a high temperature environment;
③Please connect the Product to a suitable adaptor(5V/1A), power bank, or laptop for power supply;
④The charging time depends on the power supply device;
⑤The charging indicator lights up in red when charging and lights up in green when fully charged.

V.Parameter Information


Product Model	K1
Speaker battery capacity	1200 mAh
Microphone battery capacity	300 mAh
Input	5V --- 1A
Rated Power	5W MAX

Warning

- The light source of the Product cannot be replaced. When the light source expires, please replace the whole Product;
- When the product is in normal use, do not place it on an inclined surface greater than 6°;
- When the product is not used for a long time, please cut off the power supply;
- The power supply used with the toy is to be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toys must not be used with this power supply until the damage has been repaired.
- Not connected more than recommended number of power supplied.
- Warning! The toy is not intended for children under 3 years old.
- WARNING: For the purposes of recharging the battery,

only use the detachable supply unit provided with this toy (5V,1A).

- The toy shall only be used with a transformer for toys or a power supply for toys.
- The toy only using output DC 5V, 1A transformer or power supply. The power supply is not a toy.
- Toys liable to be cleaned with liquid are to be disconnected from the power supply before cleaning.
- Do not dismantle, crush, incinerate or short-circuit battery.
- Keep away from flammable materials and direct sunlight.
- Rechargeable battery is only to be charged by an adult.
- Children use products under adult supervision.
- Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong odor.
- Do not stare directly into the projecting light. Inspect this product before each use. If it is cracked or broken in any way, discontinue use and discard immediately.
- Batteries and accumulators must not be disposed of with household waste! Every consumer is legally obliged to hand in all batteries and accumulators, regardless of whether they contain harmful substances * or not, at a collection point in the city or at a retail outlet so that they can be disposed of in an environmentally friendly manner.
- This product contains 3.7V rechargeable lithium battery that is non-replaceable.
- This toy is only to be connected to equipment bearing either of the following symbols:



FCC warning:

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in the portable exposure condition without restriction.

Read operator's manual The instruction must be retained since it contains important information. **WARNING!** Not suitable for children under 3 years. Small Parts. Choking hazard.

US REP:
Corporation: SUN BEYOND CONSULTING LTD
Address:OFFICE NO.448,4TH FLOOR,90 CANAL STREET, BOSTON,MA 02114
Telephone Number:+1(508)4700660
E-mail:mrsunbeyond@gmail.com

