





Cable*1+AUX Cable*1 +User Guide*1 *1: 1 unit	
--	--

Cable*1+AUX Cable*1 +User Guide*1 *1: 1 unit	
--	--



1.Buttons

- ① Short press to turn off the lamp
- ② After the work, short press to adjust the brightness of the lamp from dark to



tion

- the warm-white light, short press again
the light is on, long press to adjust the
The brightness is steplessly adjusted
m bright to dark. You can choose the
. In addition, this product supports the
that is, the product will return to the
turned on.
- the coloured light, and the light color
ing order: red light - green light - blue
purple light - colorful gradient, short
e light.

the Bluetooth function (

- Note: After the Bluetooth function is turned on, there will be no connection with the device for about 5 minutes. After the Bluetooth function will be automatically turned on.**
- The following devices can be connected to the Bluetooth:
- Bluetooth is turned on:
- Mobile phone bluetooth connection
- Turn on Bluetooth on your phone, click to scan for devices, select the device ZL-H10, and click again to enter the pairing mode. Pairing is successful and there is a prompt to connect. You can connect to play music at this time. If the device is disconnected during use, there will be a prompt to reconnect.
- Note: After the Apple phone is disconnected, there will be a prompt to reconnect.**

an

- ☒ The operation is as follows:
 - Click on the "Start Me Up" button.
 - Open "Computer Bluetooth devices", then click Bluetooth devices.
 - The computer will automatically find the Bluetooth device and make a pairing connection.
- ☐ (If the music still cannot be played, please check whether the audio device of the computer is in the "Bluetooth" mode, and confirm whether the connection is successful.)
- ☐ The AUX mode can only be used when the AUX mode is turned on. The specific operation is as follows:

can be connected to play

- [illegible]

and other devices

- When the AUX audio cable is unplugged from the product, the product will automatically switch to the Bluetooth connection mode (with a prompt tone "Bluetooth connection").
- Bluetooth connection precautions**
- When the speaker has been connected to other Bluetooth devices, it will actively connect to the last connected device when powered on.
- If the speaker has not been connected to a mobile phone before, the speaker enters the pairing mode when powered on.

④When the

- cannot connect with this product.
- the connection of other devices.
- speaker, enter the pairing mode.
- ### 3.Charging Instruction
- ①Please fully charge the Product.
 - ②Please DO NOT dismantle, crash or throw the Product into fire. If the Product is damaged, please do not continue to use it; do not use it in a wet environment;
 - ③Please connect the Product to a power bank, or laptop for power.

other devices, it

- Restart the Bluetooth connection.
- First use;
- Size the Product, or
- Swelling and heat,
- High temperature
- Adapter (5V/1A),
1. The product
- this product

.....

- | | |
|--|-------------------------|
| | Flying Bird Music Light |
| | WH-J04 |
| | 75*140*160mm |
| | White |
| | Bluetooth model |
| | 1800mAh |
| | 5V $\equiv$ 1A |
| | 5W MAX |

The light source of the

- Charge expires, please replace the whole Product.
 Please cut off the power when you have no
 charging time. We recommended charging the Product
 prevent shortening of the life of the lithium battery.
 When the Product is in regular use, do not p
 surface more significant than 6°;
 Please use an adapter with compliance cert
 Children under 14 need to use it properly in
 Use separate collection facilities for electric
 dispose of unsorted municipal waste. Con
 Government for information about the collect
 Don't discard this electrical appliance in land

hen the light

- Product for a
y 30 days to
an inclined
dy of adults;
ces that do
ocal
a. Please
aps at will,

...then being,

- essly approved by the party
void the user's authority to operate
of the FCC Rules. Operation is
tions:
ful interference, and
ference received, including
sired operation.
sted and found to comply with the
oursuant to Part 15 of the FCC Rules.
de reasonable protection against

and used in accordance

- reference to radio communications. However, it does not guarantee that interference will not occur in a particular installation. If such interference does cause harmful interference to radio reception which can be determined by turning the equipment off, the user is encouraged to try to correct the interference by taking one or more of the following measures:
- reorient or relocate the receiving antenna.
 - increase the separation between the equipment and the receiver.
 - plug the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - consult the dealer or an experienced radio/TV technician for help.

- s no
ion.
sion
and
ie or
-
- n
- elp.