

FRONT

Welcome Aboard

Sign up get 15% OFF your next Boompod

(Terms & conditions apply)



Share your adventure!

#BOOMPIDS

BACK

Activate your warranty

Please register your product within 30 days of purchase at www.boompods.com or scan the QR code




You can also sign-up to receive our latest news, discounts, product support and troubleshooting.

NEW card same as old but new shape:

FRONT

BOOMTAG

Quick guide:
Open or download the free Apple Find My app from the App Store.




switch on:
press for 5 seconds.
open Apple Find My App.
tap: Items +
tap: Add Other Item .
BOOMTAG will now show Tap: Connect.

to disconnect:
press 5 times quickly.
to factory reset:
first remove from Find My App, press 2 times, then immediately press and hold for 8 seconds.

BOOMTAG

This product has a replaceable CR2032 battery. Please make sure you use high-quality batteries that will last for an additional year. **Simply replace it like so:**



use a fingernail.

replace battery positive side up.

gently press back together.

Online manuals



www.boompods.com

BACK

Please read instructions before use, and keep for future reference.

WARNING:
Do not ingest battery. Chemical burn hazard. Coin battery inside. Swallowing can cause severe internal burns in 2 hours, even death. Keep batteries away from children. If battery compartment doesn't close securely, stop using product. Keep away from children. If swallowed or inserted, seek immediate medical attention. Product not a toy or edible. Mobile device casings can weaken signal and reduce visibility. Avoid large metal objects near device and Boomtag. Interference with Bluetooth signal.
Caution: Lithium battery inside. Risk of explosion with incorrect use. Avoid direct heat and mechanical stress. Do not disassemble Boomtag. Risk of electric shock and voiding warranty.

Warranty- UK & Europe
Your BOOMPIDS product is guaranteed against any defects in material or workmanship for 2 years from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage.

Warranty- US & Canada
Your BOOMPIDS product is guaranteed against any defects in material or workmanship for 1 years from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage.

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.

Please check www.boompods.com for your local service centre

The Declaration of Conformity can be found at:
<https://www.boompods.com/product/BOOMTAG>
Hereby, Boompods declares that the radio equipment type [Tracker with Bluetooth] is in compliance with Directive 2014/53/EU.
FCC-ID: 2A36Q-SPTS



www.boompods.com

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPods, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.



BOOMPIDS is a trademark of BOOMPIDS LTD. BOOMPIDS ©2023 All Rights Reserved.
BOOMPIDS Ltd (UK), Norwich NR11 7AQ, UK
BOOMPIDS (EU), Głogów 05-806, PL
info@boompods.com Registered No: 08147066. Made in China.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.


www.boompods.com

Manual:

FRONT

BOOMTAG

Kurzanleitung:
Öffne die iOS App „Wo ist?“ oder downloade diese aus dem App Store




Einschalten:
Für 5 Sekunden gedrückt halten
Öffne die Apple „Wo ist?“ App
Tippe: Geräte +
Tippe: Anderes Objekt hinzufügen
BOOMTAG wird nun angezeigt
Tippe: Verbinden

Ausschalten:
5 x kurz drücken
Reset: BOOMTAG in den Auslieferungszustand zu versetzen:
2 x kurz drücken, dann sofort für 8 Sekunden gedrückt halten

BOOMTAG

Dieses Produkt hat eine austauschbare CR2032 Batterie. Bitte stelle sicher, dass du qualitativ hochwertige Batterien einsetzt, die mindestens für ein Jahr halten. **Der Austausch geht ganz einfach:**



Benutze einen Fingernagel

Setze die neue Batterie mit dem + Pol nach oben ein

Drücke die beiden Schalen sanft zusammen

BACK

Bitte lesen Sie die Anleitung vor der Verwendung und bewahren Sie sie zur späteren Referenz auf.

WARNUNG:
Batterie nicht verschlucken. Gefahr von chemischen Verbrennungen. Münzbatterie im Inneren. Verschlucken kann schwere innere Verbrennungen innerhalb von 2 Stunden verursachen, sogar tödlich. Batterien von Kindern fernhalten. Wenn das Batteriefach nicht sicher verschlossen werden kann, verwenden Sie das Produkt nicht weiter. Von Kindern fernhalten. Bei Verschlucken oder Einführen sofort medizinische Hilfe suchen. Produkt ist kein Spielzeug und nicht zum Verzehr geeignet. Handygehäuse kann das Signal schwächen und die Sichtbarkeit verringern. Vermeiden Sie große Metallgegenstände in der Nähe des Geräts und des Boomtags. Störungen mit Bluetooth-Signalen möglich.

Vorsicht: Lithiumbatterie im Inneren. Explosionsgefahr bei unsachgemäßer Verwendung. Direkte Hitze und mechanische Belastung vermeiden. Den Boomtag nicht zerlegen. Gefahr eines elektrischen Schlags und Verlust der Garantie.

Garantie - Vereinigtes Königreich & Europa
Ihr BOOMPIDS-Produkt ist für 2 Jahre ab dem Datum des ursprünglichen Kaufs gegen Material- oder Verarbeitungsfehler garantiert, sofern es nicht auseinandergenommen wurde und keine versehentlichen Schäden aufweist.

Das Gerät muss gemäß der Bedienungsanleitung verwendet werden. Die Garantie gilt nur bei Vorlage der Originalrechnung oder des Kassenbelegs vom Händler und gilt nicht für normalen Verschleiß oder Geräte, die falsch verwendet oder manipuliert wurden. Es sollte an das örtliche Servicezentrum zurückgeschickt werden. Das Servicezentrum übernimmt keine Versandkosten für zurückgeschickte Artikel.

Bitte prüfen Sie www.boompods.com für Ihr örtliches Servicezentrum.

Die Konformitätserklärung finden Sie unter:
<https://www.boompods.com/product/BOOMTAG>
Hiermit erklärt Boompods, dass das Funkgerät (Tracker mit Bluetooth) der Richtlinie 2014/53/EU entspricht.
FCC-ID: 2A36Q-SPTS



www.boompods.com

Die Verwendung des "Works with Apple"-Abzeichens bedeutet, dass ein Produktspezial für die Zusammenarbeit mit der in dem Abzeichen identifizierten Technologie entwickelt wurde und vom Produkt-Hersteller zertifiziert wurde, um den Produktspezifikationen und -anforderungen des Apple Find My-Netzwerks zu entsprechen. Apple ist nicht verantwortlich für den Betrieb dieses Geräts, die Verwendung dieses Produkts oder dessen Einhaltung von Sicherheits- und Regulierungsstandards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPods, Mac, macOS und watchOS sind Marken von Apple Inc., die in den USA und anderen Ländern registriert sind. iOS ist eine Marke oder eingetragene Marke von Cisco in den USA und anderen Ländern und wird unter Lizenz verwendet.



BOOMPIDS is a trademark of BOOMPIDS LTD. BOOMPIDS ©2023 All Rights Reserved.
BOOMPIDS Ltd (UK), Norwich NR11 7AQ, UK
BOOMPIDS (EU), Głogów 05-806, PL
info@boompods.com Registered No: 08147066. Made in China.