

BOOMPODS

BOOMTAG

universal
Wallet

Quick guide



1. Press and hold for 3 seconds to switch on.
2. Open the Apple Find My App.
3. Tap Add Item.
4. Tap Other Supported Item.
5. BOOMTAG Wallet will appear. Tap Connect.
6. You are now connected.


Disconnect:

1. Open the app and select the item.
2. Scroll to the bottom of the screen.
3. Tap Remove Item and then tap Remove to confirm.

Factory Reset :

1. Press the button 4 times.
2. Wait for the beeps, then immediately Press & hold the button for 8 seconds.

Power off/Disable: Press 5 times quickly.



1. Press and hold for 3 seconds to switch on.
2. Open the Android Find Hub App.
3. You will receive a pairing notification to set up BOOMTAG Wallet.
4. Follow the on-screen instructions to complete the pairing process.

Disconnect:

1. Open the app and tap on the item.
2. Tap the settings icon on the right of the item.
3. Tap "Remove from Find Hub" to disconnect.

Factory Reset :


1. Press the button 4 times.
2. Wait for the beeps, then immediately press & hold the button for 8 seconds.

Power Off/Disable: Press 5 times. beeps will sound.



charging:

Place on wireless charging point with the logo facing down, as shown below.



Red LED will appear.
Once charged LED will switch off.



Battery: 120mah 3.7V
life span: 5-6 month for 1 charge
charging hours: 1.5h full charged.



Wireless Charge not included

Please read instructions before use, and keep for future reference.

WARNING:

Do not expose the battery to fire or dispose of it in fire
Do not use chargers or devices with incorrect terminals. Avoid shorting the battery.
Avoid excessive physical shock or vibration.
Do not disassemble or deform the battery.
Do not immerse the battery in water.

This product is not a toy and is not edible. Mobile device casings may weaken the signal and reduce visibility. Avoid placing large metal objects near the device and Boomtag, as they may interfere with the Bluetooth signal.

Caution: Contains a Lithium battery. Risk of explosion if used incorrectly. Avoid direct heat and mechanical stress. Do not disassemble Boomtag, as this may cause electric shock and void the warranty.

Warranty- UK & Europe

Your BOOMPODS product is guaranteed against any defects in material or workmanship for 2 years from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage.

Warranty- US & Canada

Your BOOMPODS product is guaranteed against any defects in material or workmanship for 1 years from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage.

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.

Please check www.boompods.com for your local service centre

The Declaration of Conformity can be found at:
<https://www.boompods.com/product/BOOMTAG>
Hereby, Boompods declares that the radio equipment type [Tracker with Bluetooth] is in compliance with Directive 2014/53/EU.



Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

www.boompods.com

BOOMPODS is a trademark of BOOMPODS LTD. BOOMPODS ©2025 All Rights Reserved.
BOOMPODS (EU), Granica, 05-806, P.L.
info@boompods.com Registered No: 08147066. Made in China.



Statment

FCC ID: 2A36Q-TWALBK

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.