



Switch Music BKS-E01  
Switch 音乐背夹  
产品说明书 / Product Manual



一、产品接口说明 /Product interface description





- ④⑤
- (1) 电源键：单击打开 Switch 音乐背夹，**双击**关闭 Switch 音乐背夹。**长按则是重启 Switch 音乐背夹。**  
Power button: Single click to open the Switch music back clip, double click to close the Switch music back clip. Long press is to restart the Switch music back folder.
  - (2) 功能键：**单击为功能切换**。开机时**默认为**声音喇叭外放**功能**；单击可切换为蓝牙发射**功能**，可连接蓝牙耳机、蓝牙音箱等。  
Function key: Click to switch the function. When the machine is turned on, it defaults to the speaker output function; click to switch to the Bluetooth transmitting function, which can be connected to Bluetooth headsets, Bluetooth speakers, etc.
  - (3) TypeC 接口：Switch 插入时即可边充电边玩游戏。  
TypeC interface: When the Switch is plugged in, you can play games while charging.
  - (4) USB A 充电接口：可外接手机，Switch 手柄等设备充电。  
USB A charging port: It can be charged with external mobile phones, Switch handles and other devices.
  - (5) TypeC 充电接口：插上充电线连接至适配器即可给音乐背夹充电。  
TypeC charging port: plug in the charging cable and connect to the adapter to charge the music back

clip.

- (6) 拉升夹板：把夹板拉升起来将 Switch 固定，即可充电。

Pull up the splint: Pull up the splint to fix the Switch, and then it can be charged.

- (7) 两路喇叭：插入 Switch 后，音乐背夹将自动实现声音外放。

Two-way speaker: After plugging in the Switch, the music back clip will automatically realize the sound output.

- (8) 散热口：switch 散热口。

Cooling port: switch cooling port.


- (9) 支架：两个调整音乐背夹的角度。

Bracket: Two angles to adjust the music back clip.

## 二. 产品使用方法操作说明 / Product usage instructions

1. 单击电源键打开 Switch 音乐背夹

Click the power button to open the Switch music back folder.



2. 先把夹板拉升到最高自动卡住，将 Switch 对准 Typec 口仔细装好，轻压一下夹板自动固定。

开机音乐响起，背夹将会自动连接 switch，即可边充电边把声音通过两路外置喇叭播放出来。


First pull up the splint to the highest position and automatically jam, align the Switch with the Typec port and install it carefully, and press the splint to automatically fix it.

When the power-on music sounds, the back clip will automatically connect to the switch, and the sound can be played through two external speakers while charging.



3. 单击功能键可以切换为蓝牙发射，可连接蓝牙耳机、蓝牙音箱等。

Click the function button to switch to Bluetooth transmission, and connect to Bluetooth headsets, Bluetooth speakers, etc.



4. USB 接口可外接手机，Switch 等设备充电。

The USB interface can be used for external charging of mobile phones, Switches and other devices.

5. 接 Type-c 接口可以对音乐背夹进行充电

Connect the Type-c interface to charge the music back clip



6. 用手轻轻一拍便即可轻松收合音乐背夹。

You can easily close the music back clip with a light tap with your hand.

7. 双击电源键可关闭 Switch 音乐背夹。

Double-click the power button to turn off the Switch music back clip.

### 三. 重要安全说明 / Important safety instructions

8. 请注意防水

Please pay attention to waterproof.

9. 请使用符合安全标准的充电器充电。

Please use a charger that meets safety standards for charging.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.