

PANTONE 1505C

INSTRUCTION

AP06




DO NOT use this device before watching the video guide at

● evulme.com
● support@evulme.com
● +1213-878-2412

Packing List


1



Remote Control
Receiver Collar
USB Cable

Product Overview


2



Front View
Back View

Product Overview

3



Front View
Back View

Important Safety Information

4

WARNING

Not suitable for aggressive dogs. If your dog is prone to aggressive behavior, do not use this product. Aggressive dogs can cause severe injury or even death to their owner and others. Consult with your veterinarian or certified trainer. If you are unsure if this product is safe for your dog.

CAUTION

To prevent injury from improper use, please carefully read the user manual before using this product. Proper collar fit is crucial as leaving the collar on for an extended period or making it too tight can lead to skin damage. This can range from mild redness to pressure ulcers, also known as bedsores.

- Do not leave the receiver on your dog for more than 12 hours a day to prevent discomfort or injury.
- If possible, reposition the receiver every 4-6 hours to avoid excessive pressure on one area.
- Always check the fit of the collar and refer to the instructions in the manual to ensure proper use.

Important Safety Information

5


- Do not attach a leash to the electronic collar as it may cause excessive pressure on the contacts.
- When using a separate collar for a leash, avoid putting pressure on the electronic collar.
- To maintain hygiene, clean the dog's neck area and collar contacts weekly using a damp cloth.
- Check the contact area daily for any signs of rash or sores.
- Discontinue use of the collar if any such issues arise.
- Only use an adapter with an output of 5V or less to charge the collar.

How to Charge

6

Charging Instructions (2h charging time):


When charging is completed, the battery icon will stop flashing and show a full status. Charging takes about 2 hours.



Please wear the silicone cover after charging.

How to Wear a Collar

7



1. Thread the strap through the buckle.
2. Adjust the length to fit your dog's neck.
3. Put the collar on your dog's neck and fasten the buckle.
4. Press adjust collar to fit one finger between it and the dog's neck.

How to Power On/Off

8

Turn on/off the remote

- Long press the power button for 2s to turn on/off the remote.
- The LED display will turn off automatically after 30 seconds of inactivity. Press any button on the remote control to turn it back on.

Turn on/off the collar

- Long press the power button for 2s to turn on/off the collar.
- The screen will show all the icons for 2s and go off when power is off.

Operating Guide

9

Operation of Beep Mode

Beep command: Press the beep key, the collar beeps once. And the volume is adjustable.

Operation of Vibration Mode

Vibration command: Press the vibration key, the collar vibrates once.

How to adjust the level

Press the M key to switch to the vibration mode, and press the "+" button to increase or decrease the intensity.

Operating Guide

10

Operation of Shock Mode

Shock command: Press the shock key, the collar generates an e-shock once.

How to adjust the level

Simply press the "+" button to increase or decrease the intensity level.

How to test the e-shock function:

- Attach the test board to the 7 contact points of the collar.
- Press the shock button on the remote, the test board will light up if the shock functions.

Channel Selection & Pair

11

How to Select the Channel

The device supports training 2 dogs with only 1 remote. Simply press the channel select button to switch between the 2 dogs.

How to pair the collar and the remote


The remote and the collar in the package are already paired at the factory. When you need to add a new collar to the remote, please follow the steps to match the collar to the remote.

- Turn on the collar and the remote.
- Press the e-shock button on the collar twice quickly, and all the icons on the collar will start flashing.
- Press the e-shock button on the remote to pair it with the collar.
- When you hear a beep, the pair is complete.

Safety Lock

12

Keyed: Lock or unlock.



When in lock mode, all keys on the remote will be disabled and will not react when you press. To activate the keys, please slide downward to unlock.

Troubleshooting

13

Q1: When I press the beep, vibration, or e-shock button, my pet is not reacting/responding.

- Check whether the receiver collar is On.
- Check if the remote or the collar is in low battery level.
- Use the test board to test whether the e-shock functions normally.
- Adjust the intensity level.
- Make sure that the contact points of the receiver collar are touching your dog's skin closely.

Troubleshooting

14

Q2: Remote/receiver does not response.

- Check if the Receiver Collar is on.
- Check if the collar or the remote is in low battery.
- Check whether the remote and the collar are paired.

Warranty

15

2-Year Warranty

This device is a product of the company, which is committed to 2-year warranty from the date of purchase, which covers parts and labor for most services. However, the buyer is responsible for paying for the postage to return the unit. Accessories such as chargers, straps, and batteries are covered for the first year only. After the warranty expires, the buyer will be responsible for any necessary parts and services.

Non-eligible Warranty Situations

- Products that have been bought secondhand or as a result of theft.
- Manual damage or loss.
- Any water damage on the remote or receiver collar.
- The unit has been modified or damaged by an unauthorized third party.
- Replacing batteries during warranty if damage occurs (replacement of batteries is not recommended during the warranty period).

How to Activate the Warranty

If there is a problem with your product, please send the below info to support@evulme.com for after-sales service.

- Your original package.
- Your current shipping address.
- After confirm the info, we will send you the replacement within 5 business days.

Certification Statements

16

CE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty to the extent of the change.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Certification Statements

17

CE

The company declares under its own responsibility that this product complies with the Union requirements of (2014/53/EU) and (2014/53/EU). Where the approval of use involves the declaration, the company declares or modification to the equipment may require the CE approval. The user is responsible for ensuring the equipment is used in accordance with the CE requirements.

Recycling Information/Battery Disposal

Please observe the regulations for electronic and electrical devices to be disposed of in the respective country. In some countries or regions, the device must be recycled. If the device is recycled, it must not be disposed of with normal household waste. Separate collection of special batteries is required in some regions. Check the regulations in your area, please recycling your batteries. For more recycling information, please refer to local regulations.

Manufacturer:
Shenzhen Evulme Technology Co., Ltd.
Manufacturer Address:
212, Building 3, No. 55, Xingxing Road, Xixiang Community, Shiqing Street, Shenzhen District, Shenzhen

● support@evulme.com
● +1213-878-2412
● evulme.com