

Please read this manual before first usage. If you have any issues while using our product, feel free to contact us for after sale service. We will take care of your issue as seen as possible.

©2022 MiLife Health, LLC. 715 W. Park Ave., Unit 107 Oakhurst, NJ 07755
Phone: 732.720.0210 Option 3 for Customer Service
ALL RIGHTS RESERVED. All designs, logos and images are the exclusive property of MiLife Health. This image contains material protected under International and Federal Copyright Laws and Treaties. Any unauthorized reprint or use of this material is prohibited. No part of the image may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system without express written permission from MiLife Health.
Products distributed by MiLife Health, LLC. As part of our commitment to excellence in our products, MiLife Health routinely improve the designs, materials or production methods of its existing products. Because it is impractical to publicize all changes in every product, we reserve the right to make such changes without notice.
U.S. AND FOREIGN PATENTS PENDING.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth® SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are those of their respective owners.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Specification

General

Power Requirement ----- DC 5V USB
Power Consumption ----- 15W
Weight ----- 2.1Kgs
Dimension ----- 39 x18 x15.8 cm
Operation temperature ----- +5degree C - +35 degree C

Audio Section

Speaker size: ----- Dual 4" woofer
Power ----- 20 Watts

Rechargeable Battery

Capacity ----- 3.7V, 4000mAh
Input ----- DC 5V
Playing time ----- 3-5 hours

Accessories

USB charging cable x 1
Wireless Microphone x 1
Instruction manual x 1
Straps x 1
Remote control x 1

Note: Specifications are subject to change for continuous improvement without prior notice.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



MLB-2000PS

Bluetooth® PORTABLE LED COLOR CHANGING PARTY SPEAKER



User Manual

Please read this manual carefully before operating the speaker.
Please keep this manual with you for further reference.

BACK

FRONT


Introduction

Congratulations on your purchase!
We encourage you to take few minutes to read this manual, which describes the product and includes step-by-step instructions to help you to enjoy the product features. Read and understand all the safety instructions before using your product.

If you have any questions about these products, their installation or their operation, please contact your retailer or customer service.

Important Safety Instructions


1. Read all warnings.
2. Follow all instructions.
3. This apparatus should not be exposed to dripping or splashing. No objects filled with liquids such as vases should be placed on the apparatus.
4. Do not block any ventilation openings. Minimum distance of 30cm around the apparatus must be maintained.
5. Do not install this apparatus near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
6. No naked flame sources, such as lighted candles should be place on the apparatus.
7. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
8. Use only attachments/accessories specified by the manufacturer.
9. Unplug this apparatus during lightning storms or when unused for long duration.



1

Product overview

Top panel operation



1. LED Display.
2. VOLUME: In USB/TF card/AUX/Bluetooth mode, rotate to adjust volume to your desired level.
3. TF CARD: Insert memory card to playback your stored music. File support MP3 format with capacity up to 32G (FAT32).
4. USB: Connect to a USB storage device to playback your stored music. File support MP3 format with capacity up to 32G (FAT32).
5. ◀◀: In USB/TF card/Bluetooth mode, short press to select previous song. In FM mode, short press to move to previous stored FM channel.
6. ▶▶/SCAN: In USB/TF card/Bluetooth mode, short press to play/pause the music. Long press to REPEAT ONE /REPEAT ALL tracks. In FM mode, short press to play/pause music, long press to AUTO SCAN the radio frequencies and save to memory. In AUX mode, short press to play/pause music.
7. ▶▶: In USB/TF card/Bluetooth mode, short press to move to next song. In FM mode, short press to move to next stored FM channel.
8. MODE: Short press to select between USB/TF/AUX/Bluetooth and FM modes.
9. ECHO-: Press to reduce ECHO effects.
10. ECHO+: Press to increase ECHO effects.

2

11. Recording/DEL: Short press to enable records. During recording ECHO should be turned to minimum. Long press to delete recorded file. Recording in Microphone model is available.
12. LIGHT: Short press to select different lighting modes.
13. Mic Vol: Rotate knob to adjust the volume to your desired level
14. POWER: Press to power ON/OFF speaker.
15. DC 5V input (charging slot): Connect USB cable to the unit and plug into any USB charger.
16. Charging indicator: While charging the red indicator light will turn on, when fully charged blue light will turn on.
17. AUX IN: Connect to External device with AUX IN cable.
18. MIC IN: Insert a microphone to sing along while listing to music.
19. TWS pairing mode: Power on two PRPS-1777 speakers and select Bluetooth mode, speakers will automatically pair up. Pair the speaker with your Bluetooth device to share the music on both speakers. To exit TWS mode, long press MODE button.
20. EQ: In USB/TF/AUX/Bluetooth mode short press to select between NOR(Normal), POP(Pop), ROC(Rock), JAZ(Jazz), CLA(Classic), CVB(Concert) modes.

Basic operation

TURNING THE UNIT ON/OFF

Press the power ON/OFF button to switch the unit on/off. When the unit is powered on LED will be display.

SELECTING MODE

To change function modes, press the MODE to switch between Bluetooth/FM/LINE IN/USB/TF function.

ADJUSTING THE VOLUME

Rotate the VOLUME knob on the unit to increase or decrease the music volume to desired level.

MICROPHONE JACK

Microphone input is available in all modes.
Connect your microphone to the 6.3mm MIC JACK found on the top panel of the unit. Rotate MIC VOL button on the unit to adjust MIC Volume.
To record, connect a storage device (USB/TF card) and short press "REC/DEL" button to start recording. During recording, tune the "ECHO" to minimum. Please maintain proper distance between speaker and microphone to avoid.

LINE-IN

Connect your audio device to unit with AUX IN cable. Unit will start playing music automatically from the device connected. Adjust the volume to your

3

desired level.

TF CARD

Press the MODE button to select "TF" mode. Music stored on your TF card will start playing.

USB PLAYBACK

Press MODE button on the unit to select "USB" and insert the USB stick, the unit will automatically read and play the music on the USB device.
Press "▶▶" key to Pause the music, press again to resume play.
Short press "◀◀" to play previous song.
Short press "▶▶" to move to next song.

BLUETOOTH OPERATION

Press MODE button on the unit "bLUE" will be displayed on screen. Put the Bluetooth device within 10 meters, turn on the Bluetooth function on your device and search for "MLB-2000PS" and connect. If required input "0000" as password. Once the pairing is completed unit will start playing the music from your device.
Short Press PLAY/PAUSE ▶▶ button to play or pause the music.
Short press ◀◀ or ▶▶ key to select previous or next track.

FM MODE

Press MODE button repeatedly to select FM function, frequency is displayed on the screen.
Press the PLAY/PAUSE ▶▶ button to activate auto search, tuner will search for stations available and memorize automatically. The number of memorized stations depends on the reception in your area.
Use the ◀◀ or ▶▶ buttons to listen to the memorized station.
To select a memorized station directly, press the corresponding numeric key on the remote control.

TWS Mode

You can pair two MLB-2000PS speakers to share the music. Turn on both speakers simultaneously; long press "TWS" button and speakers will pair up with each other automatically. Open Bluetooth on your device and search for "MLB-2000PS", connect to enjoy stereo sound effect.

4