


REMOTE CONTROL



REMOTE CONTROL

1. **POWER:** Turn the TV on/off.
2. **MUTE:** Turn the sound on or off.
3. **MEMBER:** Choose or add an account.
4.  : Start a voice search or speak to Google Assistant.
5. **SETTING:** Press to open the setting option.
6. **ARROWS:** Navigate on-screen menu.
7. **OK:** OK to confirm selection.
8. **BACK:** Return to previous menu.
9. **HOME:** Open Android TV home page.
10. **GUIDE:** Select electronic program guide, in DTV mode, it will display all the information of program in a week when pressing this button.
11. **VOLUME:** Increase or decrease TV volume.
12. **Keyboard:** Press to open the virtual keyboard
13. **CHANNEL:** Next or previous TV channel.
- INFO:** Display channel information.
14. **MENU:** Display Menu
15. **APPS:** Open Netflix, YouTube, PrimeVideo, **FAV APP**

Bluetooth pairing operation:

Long press the "home" and "back" buttons on the remote control, wait for the indicator light to start flashing, the remote control will display the Bluetooth name, and at the same time broadcast the Bluetooth pairing signal, and the remote control will enter pairing mode.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.