



WALLMUM

Hibuds F1

TWS Wireless Earbuds

USER MANUAL/取扱説明書/说明书

Contents

English ————— **1~5**

日本語 ————— **6~10**

中文 ————— **11~15**

Package Content



Power On

Open the charging case, the earbuds will automatically power on.

Power Off

Place the earbuds back into the charging case and close the case, the earbuds will automatically power off.

Pairing&Re-pairing

- 1.Open the charging case and take both Earbuds out of the charging case and the twin Earbuds will power on and pair with each other automatically.
- 2.Active Bluetooth setting on your device ,search and choose "Hibuds F1" to connect.You will hear a voice prompt "di" when the earbuds F1" to connect.You will hear a voice prompt "di" when the earbuds F1" to connect.You will hear a voice prompt "di" when the earbuds F1" to connect.
- 3.The earbuds can remember previously paired devices.When you make the second connection, simply active the Bluetooth in your device,take out the both earbuds from the charging case.They will reconnect to your device automatically.If the earbuds doesn't automatically connect to your device,please active the Bluetooth in your device and click "Hibuds F1" on the Bluetooth list.
- 4.Mono mode: When Bluetooth connected, you can use either one of the earbuds only by putting the other one back into the charging case and closing the cover.

LED Indicator Behavior

TWS connecting	both earbuds rapidly flashing blue
TWS connected	one earbud rapidly flashing blue , one earbud light off
Bluetooth pairing	one earbud rapidly flashing blue , one earbud light off
Bluetooth connected	both earbud blue light off

Specifications

Bluetooth version	Bluetooth 5.0
Driver diameter	Φ13mm
Bluetooth range	10m/33ft
Battery capacity	45mAh*2 (Earbuds) ;400mAh (Charging Case)
Charging time	60mins
Playtime	4Hours (Earbuds)

Control

Stereo Mode

Play/Pause: tap once

Previous track: tap two times

Next track: tap two times

Answer phone call/Hang up: tap two times

Reject phone call: long press for 4s

Active voice assistant: tap three times

Mono Mode

Play/Pause: tap once

Answer phone call/Hang up: tap two times

Reject phone call: long press for 4s

Active voice assistant: tap three times

Charging

Charging the earbuds

You will hear a voice prompt "dididi" When the earbuds battery is low.

1.When the charging case is powered,put the earbuds into the charging case and close the charging case,the earbuds will charge automatically.

Charging the charging case

When charging case battery is low,the LED indicator of the charging case is rapidly flashing in red.

1. Please use the provided USB-C cable to charge the charging case directly.

2. During charging,the LED indicator of the charging case is rapidly flashing in red.When the case are fully charged,the LED indicators will be turning red.

NOTE : Fully charge both the earbuds and the charging case before the first use.

Warranty

We warrant this device **12 MONTHS** from the date of the original purchase for manufacturer defects.

Email: VIP@MSPT-Wallmum@outlook.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Model: Hibuds F1
FCC ID: 2A3AH-HIBUDSF1
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.