

L1-中性-折页英文说明书尺寸78X120MM

PROJECTOR

User manual



◆Please read this user manual carefully before using the projector.
◆Please save it for future reference.

Safety instructions

Notice

1. Please read the user manual carefully before using the projector.
2. Please use standard power cable with good earth to ensure power safety.
3. Please use the same power voltage as marked on the projector.
4. Please do not disassemble the projector by yourself otherwise the warranty will void.
5. Please do not look into the lens when the projector is working, otherwise it may hurt your eyes.
6. Please do not cover the projector ventilation holes with any material.
7. Please keep the projector away from water or any other liquid as it is not waterproof.
8. Please don't put the projector in wet or other conditions to prevent electric shock.
9. Please turn off and unplug from the power supply if not using the projector for a long time.
10. Please use the original padding cover or other antistatic material when replacing the projector.
11. Please contact our customer support if you encounter any problem with the projector.
12. Not recommended for PowerPoint, Word, Excel or business presentations. To connect the video projector to PCHardware, please download the PCHardware display modules to 1920*1080 for best display.
14. Recommended for use in the dark rooms. Please dim the curtains if you want to see the display.
15. Display is not supported.
16. If it is installed in environment, turning this device may cause wireless interference.

Accessory List

Projector	Manual	Power cable	Remote Control
Projector	Manual	Power cable	Remote Control

Basic parameters

Display Technology	LED
Native Resolution	1280*720 dpi
Light	LED
Life Span	20000hrs
Color Reproduction	16.7M
System	Android
Focus	AutoFocus/Electronic focusing
Keystone	Auto-Keystone/Electronic keystone
Power-Memory	10000mAh / 5000mAh/500mAh
Input	USB/HDMI
Output	Earphone USB (3W-600mA)
Environment of use	0~40℃
Storage of use	Temperature: 0~42 °C Storage Temperature: 0~40°C Humidity: 15% ~ 85%
Power Distance	0.52-1.0M
Screen Size	40"~100"
Projector Ratio	1.26:1
Relay output	5W
Use case	200,000,000shots
Net Weight	1.5KG

Projector Overview



Connection



Remote Control

Button instruction:
Power On/Off: Switch-on/switch-off power on/off power
Source: Switch system input signal sources
Arrow keys: Up/down/left/right: Press the left and right arrow keys in the black interface to realize the text forward/back back function
Focus +/- Focus: Adjust focal length to adjust picture size



Power on

After 5-10 seconds, the system screen will be displayed



Power On
When the projector is powered on through the power cord, it enters the standby state. Press the "P" button on the projector or press the "P" button on the remote control to power on.



Power off & Focus

Power Off
Overheat protection: "P" button to shut down immediately.
Click the "P" button to display the function prompt and select shutdown.



Focus
Auto Focus: Automatically enter the focus mode after the boot, the picture is instantly clear.



Tip: The focus state will be updated from time to time. The actual sight preview.

System setting

Keystone: Press the "K" button after starting up, press the "K" and "S" keys on the remote control directly to fix the keystone on the remote control with the arrow keys. The keystone will be fixed at the position of the screen. The decision focusing angle will be updated from time to time.



Notice: The picture is still blurry, please adjust the projection distance appropriately.

Press the "Q" arrow key all the way to the top to display "Source/Screen/Settings" menu.






Press the "Down arrow key" all the way to the top to display "Application/Source/Screen/Settings" menu.



Source:
Switch HDMI/USB signal source



System setting	System setting	System setting	System setting	System setting	System setting	System setting	Installation
Connecting a USB device Plug the USB flash drive to enter the fast reading state. Click Open then click USB disk to enter, select the file you need to open.  You can also select the USB signal source after inserting the USB flash drive. Connecting an HDMI device Plug the HDMI cable into the HDMI jack on the back of your projector and into the HDMI jack on your device. Then press the "Source" button to switch to HDMI. *Auto interface → Settings → Network Eshare server for iOS 1) Connect your device and projector to same WiFi. 2) Open the Eshare APP on your projector. 3) On your iOS device, tap the screen image. Search for the same device name as the projector and click Connect. 	Eshare server for Android 1) Connect your device and projector to same WiFi. 2) Open the Eshare APP on your projector. 3) In Android device, you need to scan the QR code on the projector screen to download "Eshare" and install it. After installation, select the file you need to open if the link is displayed during installation. Click to understand the rule, then click to use.  Settings Press the up arrow key to go to the top of the main interface and click Settings. You can also press "Settings" on the remote control to enter. Network Click the settings on the main interface to enter, select the corresponding WiFi, and enter the password to connect. 	Source *Switch HDMI/USB signal source. Google Account *Sign into Google Account. Projection *Choosing Front Projection/Desktop Rear Projection/ Ceiling Front Projection/Ceiling Rear Projection  Trapezoid Setting *Automatic Focus On or off this function. *Auto Keystone Correction On or off this function (correction mode). *Auto Curtain Alignment On or off this function. Auto focus at power on On or Off Auto horizontal at power on On or Off 	Manual Keystone *Press the OK button to select the correction point. *Press the direction buttons to adjust the image. *Press the menu button to restore.  Screen Zoom *Press the up and down arrow keys to zoom in and out. 	Image mode *Change Standard/Mode/Scene/Mode/Sports/Mode/Full Definition Screen saver *Enable Screen Saver: On & Off, 45 Minutes/15 Minutes/30 Minutes/20 Minutes/30 Minutes.  Language *Press the "V" and "O" button to select the language, and press the "OK" button to confirm. 	Time & Time zone *Click the 24-hour clock: On & Off When the 24-hour time system is enabled, the time zone can be changed.  Upgrade *Online Upgrade: WiFi online upgrade *Local Upgrade: Upgrade through the USB flash drive upgrade program.  Sound *System Volume: Press "+" and "-" arrow keys to adjust the system volume. *Key sound effects: On or off the key tones.	Reset Restore factory original data, free up storage/empty space. On the displayed dialog box, select "Yes".  System Settings *Audio system light: On & Off About Projector *Device name/Android version/Version No./IP Address etc. 	Install Method *This projector can be hanged on the ceiling with a special hanger frame, and keep the projector at a height where its lens is solid symmetry to the screen. If this is not possible, use the four-point keystone function to adjust the projected image.  Projector distance and size 

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.