

Quick Start Guide

AGM M11




Quick Start Guide English

NOTICE:

Product features and accessories depend on software, phone memory, and local networks, and may be restricted by operators or service providers. Descriptions may not match the purchased items. The manufacturer may change information in this manual without prior notice.

Overview & Functional Description



1> Tpye-C charging cable

By default, reverse charging is turned off. Users can choose to enable this feature by clicking on the main menu > Reverse Charging.
***After shutdown or restart, the reverse charging switch will return to its default state.**

2> RECEIVER

Waterproof receiver for receiving calls. Do not touch with hard materials.

3> Display (2.8" inches Display)

4> Confirm / SOS KEY

Short press to confirm the operation function. On the standby screen, press and hold for 5 seconds to activate the emergency SOS function.

5> KEYPAD

6> 3.5mm Headphone Jack and Waterproof Rubber Cover

7> Microphone

8> USB Type-C port and Waterproof Rubber Cover

9> INNER BATTERY DOOR

Inner battery door is designed to prevent water ingress. Install. Open the inner battery door from top left corner.

10> PPOWERING YOUR DEVICE ON/OFF

Long press the power button to turn on or off the device. The default language is English. To change the language, please go to the "Settings" menu.

11> LOUDSPEAKER

12> CAMERA(2MP)

13> LED

14> OUTER BATTERY DOOR

Outer battery door does not prevent water ingress. Open the outer battery door from left lower corner.

15> SIM TRAY 1 (Nano SIM)

16> SIM TRAY 2 (Nano SIM)

17> Micro SD TRAY

GETTING STARTEN

WATERPROOF WARNING:
This device is IP68/IP69K/MIL-STD-810H certified. Battery doors and USB port cover must be completely closed to prevent water damage.

INSTALLING A NANO SIM CARD OR MICRO SD CARD

1. Open the outer battery door from left lower corner.
2. Open the inner battery door from top left corner.
3. Take out the battery from top and remove the insulation tape (if have) from the battery contacts.
4. Align Nano SIM according to the graphic note and use your fingertip to place the Nano SIM card in the SIM 1/ SIM 2 tray with gold pins facing downwards.
5. Install the micro sd card (with the contacts facing down), slide in the direction of the "Lock" arrow, and gently push it into the groove.
6. Reinsert the battery, inner battery door and outer battery door.

NOTE:

The device supports dual SIM dual standby but single pass. This means that you cannot use both SIM cards for calls or data services simultaneously.

1. A cut SIM card or anyothernon-standard cards are not allowed. Those non-standard cards may not be recognized by the phone and can damage the tray.
2. After you insert the card,communication and network services require support from the operator.
3. Any expenses incurred for calls, data, and other services will be charged by the operator corresponding to the card you have chosen.

***Your network usage status and the services you can enjoy depend on the deployment status of the operator you have chosen in the local area.**

CHARGING THE BATTERY

Before using your device for the first time you will need to charge the battery.

1. Remove the insulation tape (if have) from the battery contacts.
2. Connect the USB power cable to the charging power adapter. This device is an Eco-friendly mobile device, which does not come along with a power adapter in the box in editions of some areas. This device supports CE/FCC or equivalent certified chargers.

The recommended charger output is 5V==2A. Uncertified equipment may cause damage to the device or cause batteries to explode.
3. Open the USB Type-C port cover and connect the USB power cable to the port.Be careful not to use excessive force when plugging the cable.Any damage caused by attempting to insert the connector incorrectly is not covered by the warranty.

4. Plug the charger into an AC mains socket.

5. When charging is complete, remove the cable from the device. then unplug the power adapter from the mains socket. Close the USB port cover on the device.

COMMON FUNCTIONS

VOLUME TUNING

On the standby interface, adjust the volume using the up and down arrow keys.

Set SOS Key

* The SOS button is enabled by default. Users can click on the main menu>Settings>SOS to choose to turn it on/off.
* When the user wants to edit the phone number saved by the SOS button, click on the main menu>Settings>SOS, and then select the SOS number to re edit.

Lock/Unlock the screen

When the screen is awakened, pressing the "Menu" key and the "" key will unlock the device.
* When the device is turned on for the first time, there is no "lock screen shortcut" by default.
Users can switch the shortcut according to their personal needs through the following method: Settings < Security.

TORCH SWITCH

When the screen is unlock,long press the "0" key to turn on/off the torch.

RING/MUTE/VIBRATE MODE/#

Press and hold # key to change modes of RING, MUTE and VIBRAT.

Sending an SMS/MMS*

Select and enter Messaging menu to write SMS or MMS. MMS is dependent on the APN settings and it may not work with some SIM cards. This device does not support automatic settings updates sent by your network provider.


Volte call*

Volte calling is supported in some areas and only with some SIM cards. The signal bar place will show"4G" or "HD" or "VOLTE"during calling if Volte is working.

RESET TO FACTORY DEFAULT

Reset codeis 1234.

WARNING



DISPOSAL AND RECYCLING INFORMATION

his symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage.

Do not dispose of the device or batteries as unsortedmunicipal waste.

The device (and any batteries) should be handed over to a certified collection point for recycling orproper disposal at the end of their life.

Basic information of manufacturer

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

CE

The maximum results of SAR as follows:

SAR 10 g limit: 2.0 W/Kg,

SAR Value: Head (with 0mm separation): 0.716W/Kg,

Body-worn (with 0mm separation): 1.979W/Kg

Hands (with 0mm separation): 1.979W/Kg

Refer to the following specifications to use the adapter:

Manufacturer: Shenzhen HuajinElectron Co., Ltd.

Model Name: HJ-0502000-EU

Rated Input & Output: 100-240V~, 50/60Hz, 0.3A,

5.0V==2.0A, 10.0W

Manufacturer:

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

EU REP:

Company: E-CrossStu GmbH

Address: Mainzer Landstr.69 ,60329 Frankfurt am Main

E-mail: E-crossstu@web.de

RESET TO FACTORY DEFAULT

Reset codeis 1234.



RED Declaration of Conformity



DISPOSAL AND RECYCLING INFORMATION

his symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage.

Do not dispose of the device or batteries as unsortedmunicipal waste.

The device (and any batteries) should be handed over to a certified collection point for recycling orproper disposal at the end of their life.

Basic information of manufacturer

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

CE

The maximum results of SAR as follows:

SAR 10 g limit: 2.0 W/Kg,

SAR Value: Head (with 0mm separation): 0.716W/Kg,

Body-worn (with 0mm separation): 1.979W/Kg

Hands (with 0mm separation): 1.979W/Kg

Refer to the following specifications to use the adapter:

Manufacturer: Shenzhen HuajinElectron Co., Ltd.

Model Name: HJ-0502000-EU

Rated Input & Output: 100-240V~, 50/60Hz, 0.3A,

5.0V==2.0A, 10.0W

Manufacturer:

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

EU REP:

Company: E-CrossStu GmbH

Address: Mainzer Landstr.69 ,60329 Frankfurt am Main

E-mail: E-crossstu@web.de

RESET TO FACTORY DEFAULT

Reset codeis 1234.



RED Declaration of Conformity



DISPOSAL AND RECYCLING INFORMATION

his symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage.

Do not dispose of the device or batteries as unsortedmunicipal waste.

The device (and any batteries) should be handed over to a certified collection point for recycling orproper disposal at the end of their life.

Basic information of manufacturer

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

CE

The maximum results of SAR as follows:

SAR 10 g limit: 2.0 W/Kg,

SAR Value: Head (with 0mm separation): 0.716W/Kg,

Body-worn (with 0mm separation): 1.979W/Kg

Hands (with 0mm separation): 1.979W/Kg

Refer to the following specifications to use the adapter:

Manufacturer: Shenzhen HuajinElectron Co., Ltd.

Model Name: HJ-0502000-EU

Rated Input & Output: 100-240V~, 50/60Hz, 0.3A,

5.0V==2.0A, 10.0W

Manufacturer:

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

EU REP:

Company: E-CrossStu GmbH

Address: Mainzer Landstr.69 ,60329 Frankfurt am Main


E-mail: E-crossstu@web.de

RESET TO FACTORY DEFAULT

Reset codeis 1234.



RED Declaration of Conformity



DISPOSAL AND RECYCLING INFORMATION

his symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage.

Do not dispose of the device or batteries as unsortedmunicipal waste.

The device (and any batteries) should be handed over to a certified collection point for recycling orproper disposal at the end of their life.

Basic information of manufacturer

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

CE

The maximum results of SAR as follows:

SAR 10 g limit: 2.0 W/Kg,

SAR Value: Head (with 0mm separation): 0.716W/Kg,

Body-worn (with 0mm separation): 1.979W/Kg

Hands (with 0mm separation): 1.979W/Kg

Refer to the following specifications to use the adapter:

Manufacturer: Shenzhen HuajinElectron Co., Ltd.

Model Name: HJ-0502000-EU

Rated Input & Output: 100-240V~, 50/60Hz, 0.3A,

5.0V==2.0A, 10.0W

Manufacturer:

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

EU REP:

Company: E-CrossStu GmbH

Address: Mainzer Landstr.69 ,60329 Frankfurt am Main


E-mail: E-crossstu@web.de

RESET TO FACTORY DEFAULT

Reset codeis 1234.



RED Declaration of Conformity



DISPOSAL AND RECYCLING INFORMATION

his symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage.

Do not dispose of the device or batteries as unsortedmunicipal waste.

The device (and any batteries) should be handed over to a certified collection point for recycling orproper disposal at the end of their life.

Basic information of manufacturer

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

CE

The maximum results of SAR as follows:

SAR 10 g limit: 2.0 W/Kg,

SAR Value: Head (with 0mm separation): 0.716W/Kg,

Body-worn (with 0mm separation): 1.979W/Kg

Hands (with 0mm separation): 1.979W/Kg

Refer to the following specifications to use the adapter:

Manufacturer: Shenzhen HuajinElectron Co., Ltd.

Model Name: HJ-0502000-EU

Rated Input & Output: 100-240V~, 50/60Hz, 0.3A,

5.0V==2.0A, 10.0W

Manufacturer:

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

EU REP:

Company: E-CrossStu GmbH

Address: Mainzer Landstr.69 ,60329 Frankfurt am Main


E-mail: E-crossstu@web.de

RESET TO FACTORY DEFAULT

Reset codeis 1234.



RED Declaration of Conformity



DISPOSAL AND RECYCLING INFORMATION

his symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage.

Do not dispose of the device or batteries as unsortedmunicipal waste.

The device (and any batteries) should be handed over to a certified collection point for recycling orproper disposal at the end of their life.

Basic information of manufacturer

Company: AGM MOBILE LIMITED

Address: FLAT/RM 2253 22/F HOI TAI FACTORY ESTATE

TSING YEUNG CIRCUIT TUEN MUN NT, HONG KONG, CHINA

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

CE

The maximum results of SAR as follows:

SAR 10 g limit: 2.0 W/Kg,

SAR Value: Head (with 0mm separation): 0.716W/Kg,

Body-worn (with 0mm separation): 1.979W/Kg

Hands (with 0mm separation): 1.979W/Kg

Refer to the following specifications to use the adapter:

Manufacturer: Shenzhen HuajinElectron Co., Ltd.

Model Name: HJ-0502000-EU

Rated Input & Output: 100-240V~, 50/60Hz, 0.3A,

5.0V==2.0A, 10.0W

Manufacturer:

Company: AGM MOBILE LIMITED