

User Manual

ARBTK11

(Fold Inward) — — — — ➔

(Back Cover)

(Front Cover)

Using the 3.5 mm AUX Cable

1. Plug one end of the included 3.5 mm auxiliary cable into the 3.5 mm auxiliary input port on the headphones.
2. Plug the other end into the headphone jack or 3.5 mm aux output port on your media-playing device. Switch input modes until you reach AUX mode.
3. In AUX mode, all playback and volume adjustment will be controlled by your connected device.

Note: The headphones do not need to be charged or powered on to listen using the AUX cable.



Compliance Information

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING: Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label Definitions

— Direct current symbol.



This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.



This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.



This symbol signifies that this is a wireless device powered by Bluetooth® technology.



Warranty Information

90-Day Limited Warranty

Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product is supplied and supported only by an authorized retailer. It is warranted by Southern Telecom, Inc. to the original consumer purchase against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:

- Visit our customer support portal: www.customersupport123.com
- Select the brand and model of your device.
- Select "Service Request" and fill out the form to begin your inquiry.
- Exchanges require dated proof of purchase from an authorized retailer.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided

This warranty does not cover damage resulting from accidents, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY SET FORTH ABOVE, SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR WARRANTY GIVEN ANY PURCHASE. FROM ONWARD WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, NEITHER REPLACEMENT OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT SHALL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, REVENUE, DATA OR RECORDS CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THE WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Designed in US
Printed in China
v1.01-0022



Before You Begin...

READ CAREFULLY AND KEEP THIS MANUAL

Caution


To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY.** do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust or water, or to come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- Wireless Headphones (x1)
- Micro-USB Charging Cable (x1)
- 3, 5 mm AUX Cable (x1)
- User Manual (x1)

Location of Controls




Getting Started

Charging the Headphones

Plug the small connector of the supplied USB charging cable into the charging port on the headphones. Plug the large connector into a USB power source, such as the USB port on a computer, or a **5V USB wall adapter** (not included).

The LED indicator will light up RED when charging, and turn OFF when fully charged.

When the headphones are low on power, a tone will be heard indicating that they need to be recharged.



Powering ON/OFF

- Press + hold the Power button for **3 seconds** to power ON. A tone will be heard, and the headphones will enter Bluetooth pairing mode. They will automatically re-pair to any nearby, previously-paired device with Bluetooth enabled.
- Press + hold the Power button for **4 seconds** to power OFF.

Bluetooth Pairing

1. Power the headphones ON. A tone will be heard, the LED indicator will **flash RED and BLUE**, and the headphones will enter Bluetooth pairing mode.
2. Set your mobile device to search for Bluetooth devices. When it appears, select BT Name from the list of found devices.
3. After a successful pairing, a tone will be heard, the LED indicator will **slowly blink BLUE**, and you will be able to play music on the headphones.

In Bluetooth mode, volume and playback can be controlled with the following:

- Press the Power button to pause and resume playback.

- All volume & playback can be controlled by the paired device.

Phone Calls

When connected to a phone via Bluetooth, you can control phone functions with the controls on the headphones.

- Press the Power button to **answer** an incoming call. Press again to **end** the call.
- **Press + hold** the Power button for **2 seconds** to **reject** an incoming call.
- 2x Press the Power button to redial the last outgoing number.

Instructions continued on the next page.