

Mobile phone manual

Mobile telephone
User Manual
V1.0
2017.09.22

Because the product version to upgrade or other reasons, the document content will not regular updates. Our company reserves in do not make any prior notice in this manual revision content of rights

1 Insert the SIM card and battery
Pay attention to the SIM card chip contacts must be correct. SIM card slot to be identical with the outline.

- 2 Battery Charging**
- ⌘ The phones and charger connection.
 - ⌘ Will the power plug into the charger power socket
 - ⌘ Cellular phone to start charging, the screen will show power icon scrolling effect.
 - ⌘ Power ICONS no longer scroll that charge is full already. please disconnect with the connection of the cell phone charger.

3 Keypad Description

access the address book of a request, click on 'consent'.

- ⌘ Support for reading the phone book on the remote device can also be synchronized to the phone book on the machine in the phone memory
- ⌘ Support read call log on the remote device
- ⌘ Dialer can remotely play the song saved in the remote device, realize music sharing
- ⌘ Support BT anti-lost function. Bluetooth anti-lost alarm set feature is disabled by default.

Note: The real function in accordance with the configuration of the phone.

9 File management

The machine can be a variety of media resources for rapid review and use. From standby, select Menu / file management, it supports the following major functions.

- ⌘ Establish the default folder structure tree, these folder is related to the default storage location other applications (such as Audio, Photos, video, etc.);
- ⌘ Support build new file folder.
- ⌘ Support essential file operation, ex copy, delete, rename;

- Up / Down Navigation : Keys : scroll through the names, telephone numbers, SMS and the sub-menu options. editing to move the cursor up and down; in the menu mode, scroll up and down options to choose.
 - Light / Soft key : Standby press this key to enter the main menu, non-standby interface is generally confirmed function.
 - Right / Soft key : Standby press this button to open the phone book, non-standby interface is generally a return function.
 - Dial-up key: Call the phone number and answer a call: standby mode, SIM card out of a list of call records.
 - Hand-up Key: press the red key to reject a call, end active call; also, it's the power key.
 - Numeric Keys : 0-9 number keys to enter numbers and characters: Long press the number key 1, you can into the voice mail of SIM. When the function of speed dial is open.
 - * Key : Different status or menus with different functions.
 - # Key: Different status or menus with different functions.
- Note: In this manual, "press the key" refers to press the button then release, "long press the key" refers to pressing the key and keeping 2 seconds or more than two**

- ⌘ Support operation to T-flash , format, edit etc. .

10 Settings

With this menu, you can set the system date and time, language, security password, and phone-related parameters will restore factory settings.

Notes: Mobile factory default password is 0000 or 1122

11. Input method

Editing screen, press the * key to input punctuation, the # key switch input method mode.

- ⌘ **En**
In the 'En' input mode, according to the need of the English words. Press the corresponding key once, mobile phone will be combined from the corresponding words. At the same time, also with the other letter combinations, choose the words you need.

- ⌘ **Abc**
In the 'Abc' input mode, press the number keys to input single English letters.

Click once, can input the first letter on this key; Click twice, can input the second letter on this key, which in

seconds. 1.2 collectively referred to as navigation keys.

4. Phonebook

- ⌘ You can save names and phone numbers stored in the SIM card or phone.
- ⌘ In the contact list, press up and down navigation keys to browse phone book entry.

5 Information

- ⌘ In idle screen, choose Menu/Message/Write message.
- ⌘ Input information, choose send.
- ⌘ Edit the recipients
- ⌘ Press "send" to send the message.

6 Call function

- ⌘ Making a call
- ⌘ in idle mode, press the number key to input number. If you want to dial international number, quickly press key * twice to input "+", then input the nation or area code, zone description, phone number. If you want to call a extension number, quickly press key * 3.4 times to input "p" or "w"
- ⌘ Press the Dial-up key, outgoing call.

turn on. If the input of letters and a letter before in the same key, please wait for the cursor appear again, before the confirmation letter already input, then enter a letter after.

⌘ 123

- ⌘ In the '123' input method, press the number keys to directly enter Numbers.
- ⌘ In the 'Abc' input mode, Press the corresponding digital key continuously, until all required number appearing on the screen can.
- ⌘ In the 'En' input method, press the corresponding key, when the number appearing in the candidate area, chooses the words you need.

⌘ Input punctuation

- ⌘ In any input method, press the * key to into the character list interface, chooses the character you need.

12 Warning

Before use this mobile phone, please read and compliance the following matters, in order to avoid dangerous or illegal conditions, and guarantee this equipment be best.

Armamentarium

Make use of any wireless equipment, including honeycomb phone, may disturb armamentarium. Any case, please query the doctor or manufacture.

- **Hearing protection**
When listening music or making a dialing, please use the minimum volume to avoid hurting hearing
- **Flammable and combustible area**
Be sure to remember, you should abide by the special rules and regulations, in the place prohibition of use the phone, you should power off the phone.
In any place (ex gas station, chemical plant), if using the phone may arouse blast, please power off.
- **Traffic safety**
Please do not hold the phone while driving cars, and abide by the area or nation rules.
Please do not put the phone above the air bags or the area that the air bags can reached if is expansion, because the phone may do harm to your body if is get a strong push.
Phone may disturb the airplane flight system, please

abide by the rules of the airlines, please power off if you are in the area that the wireless equipment be forbidden to use.

- **Operating environment**
Keep the phone dry, liquid may corrode the metallic circuit.
Keep the phone far away high temperature, high temperature can shorten the life of electronic instrument, melt the plastic and damage the battery.
Please don't unpack the machine, nonprofessional dismantle may damage the phone.
Don't use strong acid or strong alkaline cleanser to clean the phone.
Please use the original accessories, go against the rules may result in warranty lose efficacy.
- **Children's health**
This phone and accessories may contains some little parts, please lay up the phone to the place that the children can't reach. Children may not be inclined to damage the phone or accessories, or to ingurgitation them, it is too dangerous.

• Environmental protection

Please abide by the local laws and degrees about the equipment, battery and accessories. Please don't take them as common house refuse.

• Original accessories

Only once use the original accessories. If the use of any original spare, may influence the use of equipment performance. It was a violation of this equipment warranty terms about the communications and the state of end products and relevant regulations, and even cause bodily harm..

• Battery power and battery charger

When the phone charging completes or not in charging, please disconnects the equipment from the connection of the charger and pulled out the charger from the socket.
Please don't butt joint the two poles of battery or contact the end point of the battery by metal object, in order to avoid the short circuit of battery, and avoid the damage by overheating of the battery.
Please don't put the battery or equipment around the

heating equipment, such as the microwave oven, oven, heat sink etc. The overheating battery may cause explode.

Do not disassemble or modified battery, lest cause the battery leak, overheating, fire or blowout.
If the battery have seepage, please don't be exposed the skin or eye to battery seepage; if it is on, please wash quickly and go to the hospital to do Medical Treatment.
If the battery has the abnormal occurrence such as change color, transformation, abnormal heating and etc, please disuse it and renewal the battery.
If the power line is damaged, please don't use it, in order to avoid electric shock or fire hazard.
Don't take the battery into the fire, and it could lead to the battery fire and blowout.

Service and maintenance

Please keep the equipment and accessories dry. Please don't use the microwave and other heating equipments to dry them.

Please don't let the equipment and accessories suffer strong push or shake, in order to avoid the damage of the equipment and accessories, or avoid the combustion or explosion of battery.

Please don't put the equipment and accessories at the area with over temperature or too low temperature, otherwise, the equipment, battery and charger may get breakdown, get fired, or get explosion. When the temperature is under zero centigrade, the performance of the battery is under restrictions.

Please don't put the metal items such as pin and other poignant items around the phone receiver, the phone may be able to grip them and do damage to you body.

Please don't use the violent chemical products, cleaning agent or strong detergent to clean equipment or accessories. Please power off before clean them, and disconnect the connection of the charger and equipment. Please don't take down the equipment and accessories, otherwise the warranty will lose efficacy.

Emergency

In an emergency situation, when the mobile phone power on and be in service, you can use equipment for emergency calls. Because can't guarantee all cases network can link, therefore, in an emergency situation, do not use this device as the only way to contact.

For users don't comply with the above Suggestions or incorrect use of mobile phone of the consequences of, manufacturer disclaim all responsibility.

Electronic information products poisonous and harmful material statements

Parts	Poisonous and harmful substances or elements					
	Pb	Hg	Cd	Cr^6+	PBB	PBDE
Phone	X	0	0	0	0	0
Battery	X	0	0	0	0	0
Accessories	X	0	0	0	0	0

Federal Communication Commission Interference Statement

FCC ID: 2A3GK-230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Radiation Exposure Statement:

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions (10mm) accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

To maintain compliance with radio frequency exposure guidelines and limits, keep the smartphone at least 10 mm away from your body. When you carry the smartphone on your body, use only accessories equipped with an integrated belt clip that are supplied or approved by the manufacturer. If you use a body-worn accessory not supplied by the manufacturer, verify that the accessory does not contain metal and keep the smartphone at least 10 mm from your body.