


Bluetooth headset user manual

BOTH EARS ARE PAIRED AND CONNECTED

1. Open the charging box, turn on both ears and automatically match each other (blue light flashes). When the match is successful, the blue light of the main earphone flashes, and the blue light of the second earphone goes off.
 2. Open the device wireless list and search for "MD19R".
 3. Click to complete the connection (the blue light goes off). If the connection fails, place the headset back in the charging case and close the cover. Repeat the procedure.
- When both ears leave the device at the same time and exceed the distance, the earphones will enter the wireless state of reconnecting. If there is no reconnecting to the device within 3 minutes, the earphones will automatically shut down. After the first connection, the headset will automatically connect back to the previous pairing device after restarting the headset (wireless devices need to be turned on)

PAIRING NAME DM-6



1

MODE OF OPERATION

1. THE BOOT

- (1) Open the cover of the charging case, and the headset will start automatically immediately. The voice prompts "Start up", and the blue light of the headset will flash.
 - (2) When the headset is off, touch the touch button for 1-2 seconds, and the voice prompts "Power on".
- ### 2. TO TURN IT OFF
- (1) Put the headset back to the charging case and close the cover, and the voice prompt power off.
 - (2) When the earphone is turned on, the 3-second long-touch earphone will be turned off, and the voice prompts to turn it off.
- ### 3. CLEAR THE TWS PAIRING RECORD
- The headset has four modes: music mode, call mode, game mode and touch the headset for 3 seconds to release and switch.

INSTRUCTIONS FOR

The volume
Click the left ear 3 times
under music status

The volume
Click the right ear 3 times
under music status

Play the previous song
Click the right ear twice
in the music state

Play the next song
Click the left ear twice
under music status

Answer and hang up
Touch once

GAME MODE

- When the ear is connected to the phone, long touch the right earphone for about 2 seconds, and there will be a prompt sound. Long press again to exit.
1. **Game mode:** The headset indicator shows the breathing state.
 2. **Music mode:** the light flashes slowly.
 3. **Call mode:** the headset indicator shows the breathing state.

PRODUCT INTRODUCTION

1. Charging box *1
2. Left and right earphones *1
3. Size of ear cap *1 pair
4. Data line *1
5. Product Specifications *1

CONFIGURATION PARAMETER

- Standby time: 240 hours
Talk time: about 48 hours
- Chip version: 5.2
Charging time: about 1-2h


3

蓝牙耳机使用说明书

双耳配对连接

1. 打开充电盒，双耳开机自动互配(蓝灯闪烁)，互配成功，主耳机蓝灯闪烁，副耳机熄灭。
 2. 打开设备无线列表搜索；
 3. 点击完成配对(蓝灯熄灭)。
- 如果连接失败，将耳机放回充电盒后关盖，重复上述操作。
- 双耳同时离开设备则自动脱离，耳机进入回连无线状态，3分钟内如果没有回连则到设备，双耳机则自动关机。
- 首次连接后，耳机重新开机后自动回连上一次配对设备(需开启无线设备)

配对名称 DM-6



1

操作方式

1. 开机

- (1) 打开充电盒盖，耳机立即自动开机，语音提示“开机”，耳机蓝灯闪烁。
- (2) 耳机关机状态时，触摸触控键1-2秒，语音提示“关机”。

2. 关机

- (1) 将耳机放回充电盒上盖，语音提示“关机”。
- (2) 在耳机开机情况下，长按的触控3秒耳机关机，语音提示关机。
- (3) 耳机有音乐模式、通话模式、游戏模式，长按触控3秒切换一种模式。

操作说明

- 音乐+音乐模式下
长按触控键一下
- 音乐+音乐模式下
长按触控键一下
- 音乐+音乐模式下
长按触控键一下
- 音乐+音乐模式下
长按触控键一下

2

游戏模式 音乐模式 通话模式

1. 游戏模式：耳机指示灯为呼吸灯效果。
2. 通话模式和音乐模式：耳机指示灯为慢闪。
3. 连续触控4次启动手机语音智能。

产品介绍

1. 充电盒 *1
2. 左右耳机 *1
3. 大小耳帽 *1对
4. 数据线 *1
5. 产品说明书 *1

配置参数

- 芯片版本: 5.2
充电时间: 约1-2H
- 通话时间: 约48H
待机时间: 240小时

耳机电池300毫安，充电仓300毫。

3

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.