

TOZO®

EN

1.0 Product description

MFB Touch Panel

Medial (Ear Canal) Noise Cancelling Microphone

Outside Noise Cancelling Microphone

Indications Lights

Indications lights of charging case

Step 1

Step 2

2.0 Wearing Steps

Step 1: Ensure sounds hole downward, then place earbuds into ear.

Step 2: Rotate earbud back to auricle side to fit snugly.

Step 1

Step 2

TOZO®

EN

3.0 Operation of earbuds

3.1 How to pair

1. Take out the 2 earbuds from charging case, they will power on automatically and will connect each other automatically within 10 seconds.

2. The two earbuds flash red and blue alternately.(Pairing Mode)

3. Search for pairing name (TOZO - NC9) and select it .

Step 1

Step 2

3.2 Another method of Turning on & Turning off

Turn on :

Tap and hold the Touch Control on both earbuds for over 3 seconds .

Turn off :

1. Touch the Control button 5 seconds will turn off when earbuds in playless status .

2. The earbuds will turn off automatically after it is disconnected for more than 5 minutes .

3.3 Reset

If you accidentally get only one earbud work, or fails to pair each other, please reset it:

1.Delete all TOZO-NC9 records on the phone, then turn off the Bluetooth.

2.Holding both earbuds button for 5 seconds till red lights on to turn off earbuds.

3.Holding the MFB Touch Panel on each of earbuds for another 5 seconds till bluelight turn on and off, and then clicking the MFB Touch Panel on each of earbuds twice quickly, the reset process will be done when the Purple light on for 1 second, then two earbuds flash red and blue alternately.

NOTE:

In case there is [Connection Unsuccessful] in your devices, please consider to delete all historical records of [TOZO-NC9] and try the paring process again.

3.4 Switch between noise-control modes

Click the left earbud to switch the ANC Noise Cancellation/ Transparency mode.

The ANC function are not available when using single earphone.

NOTE:

If the electromagnetic interference signal is strong in your area, it may affect the Bluetooth connection, and the earbuds will be silent or disconnected, please reconnect it or change the place of use.

TOZO®

EN

4.1 Active Noise Cancellation Mode (ANC Mode)

With Active Noise Cancellation, an outward-facing microphone detects external sounds, which your TOZO NC9 earbuds then counter with anti-noise, canceling the external sounds before you hear them. An inward-facing microphone listens inside your ear for unwanted internal sounds, which your TOZO NC9 earbuds also counter with anti-noise.

ANC

Active noise cancellation

4.2 Transparency Mode

Transparency mode can enhance the voice frequency band and improve the perception of the surrounding sound, so you can hear what's going on around you with out taking off the earbuds.

Active Noise Cancellation and Transparency mode work best when your TOZO NC9 fit well and wearing correctly.

4.3 ANC Off Mode

ANC Off Mode is the default mode.

5.0 BOX Wireless Charging

Designed for the modern life, never be strangled by headphone cables.

Enjoy the convenience of wireless charging and free charging devices provided by airports, hotels, and cafe shops around the world. (Wireless Charging Pad Not Included)

Thank you for purchasing the TOZO authentic product.

For more latest products, parts and accessories, please visit: www.tozostore.com

For any assistance please contact Email: info@tozostore.com

CE

FC

UK

UKCA

RoHS

REACH

TOZO®

EN

6.0 Detailed Function List

Turn on

1. Manually Turn On: After the headset is in close status, tap and hold the touch control for 3 seconds and release it, the blue light will turn on. Then looking for the phone with the last connect connection memory within 10s after the headset is turned on. If it is not found, enter the pairing state (the red and blue lights flash alternately).

2. Auto Turn On: When the earbuds are in the charging case, you can pick it up and it will automatically turn on. Then finding the phone with the last connect connection memory within 10s after the headset is turned on. If it is not found, enter the pairing state (the red and blue lights flash alternately).

Turn off

1. Manually Turn Off: Tap the Touch Control 5 seconds for turn off in not playing status, and then release it, the red light will turn off after one second.

2. Auto Turn Off: Take the earbuds into the charging case and charge it for 3 seconds, then the red light will be on to turn off automatically.

TWS pairing Timeout

After the two earbuds are paired for more than 15 seconds on TWS, if they are not successfully paired, they will enter the mobile phone pairing state.

Phone Pairing

When the earbuds are turned off, tap and hold the touch control simultaneously for 5 seconds and release them to pairing mode (the red/blue light flashes alternately), then searching for pairing name "TOZO-NC9" and select it in your mobile phone.

1. Take out the 2 headset from charging base, they will power on automatically and will connect each other automatically within 10 seconds.

2. The two earbuds flash red and blue alternately (Pairing mode)

3. Search for pairing name "TOZO-NC9" and select it in your mobile phone.

Auto Turn Off

Automatically Turn Off after no connection for more than 5 minutes.

After the headset is disconnected from the phone at a long distance, it will automatically turn off after more than 5 minutes.(Normal mode)

TOZO®

EN

Restore Factory Settings

In case reset step not resolve your issue, please restore to factory setting:

1. Pick up two earbuds from charging case, then holding both earbuds button for 5 seconds till red lights on to turn off earbuds.

2. Holding the MFB Touch Panel on each of earbuds for 5 seconds till blue light turn on and off, and then clicking the MFB Touch Panel on each of earbuds 3 times quickly, the Restore Factory Settings process will be done when the red light.

3. Put earbuds into charging case, and then take them out to connect records of "TOZO-NC9" on your phone.

NOTE:

After Restore Factory Settings successfully, please delete all connection records of "TOZO-NC9" on your phone, then research again.

Turn on for re-connection

1. Tap the touch control for 3 seconds and release to turn on the earbuds -- wait for a few seconds for the earbuds to automatically interconnect with each other -- wait for a few seconds for the earbuds to connect with the paired phone -- the connection is successful.

2. Take out the earbuds from charging case -- wait for a few seconds for the earbuds to automatically interconnect with each other -- wait for a few seconds for the earbuds to connect with the paired phone -- the connection is successful.

Over distance for re-connection

After the headset is disconnected from the phone at a long distance, it can automatically reconnect when it returns to the close distance with the phone within 5 minutes. More than 5 minutes, the headset will automatically turn off.

Answer Phone Call

Tap the touch control once to answer the incoming call.

Hang up Phone Call

Tap and hold the Touch Control for 2 seconds to hand up the phone.

Reject Incoming Call

Tap and hold the Touch Control for 2 seconds to reject the Incoming call.

Cancel dialing

Tap and hold the Touch Control for 2 seconds to cancel dialing before dialing out and the other party fails to answer.

TOZO®

EN

7.0 Function List

7.1 Left earbud

Turn On

Pick up the earbuds from the case it will turn on automatically.

Tap the Touch Control 3 seconds for Turn On.

Put back the charging case will turn off & charge automatically.

Turn Off

Tap the Touch Control 5 seconds for turn off in not playing status.

Automatically Turn Off after no connection for more than 5 minutes.

Previous Track

Tap the Left Touch Control twice for backward.

Volume down

Tap and hold the Touch Control on Left earbud.

ANC Mode

Tap the Left Touch control Once.

Transparent mode

Tap the Left Touch Control Once.

ANC Off

Tap the Left Touch control Once.

Hang up Phone Call

Tap and hold the Touch Control for 2 seconds on Left earbud.

Reject Incoming Call

Tap and hold the Touch Control for 2 seconds on Left earbud.

Cancel Phone Call

Tap and hold the Touch Control for 2 seconds on Left earbud.

7.2 Right earbud

Turn On

Pick up the earbuds from the case it will turn on automatically.

Tap the Touch Control 3 seconds for Turn On.

Put back the charging case will turn off & charge automatically.

Turn Off

Tap the Touch Control 5 seconds for turn off in not playing status.

Automatically Turn Off after no connection for more than 5 minutes.

Next Track

Tap the Right Touch Control twice for backward.

Volume up

Tap and hold the Touch Control on Right earbud.

Play/Pause

Tap the Touch Control Button once on Right earbud.

Answer Phone Call

Tap the Touch Control Button once on Right earbud.

Hang up Phone Call

Tap and hold the Touch Control for 2 seconds on Right earbud.

Reject Incoming Call

Tap and hold the Touch Control for 2 seconds on Right earbud.

Cancel Phone Call

Tap and hold the Touch Control for 2 seconds on Right earbud.

SPECIAL REMINDER:

Wipe the hardware contacts of the headset and charging box when the headset is not charging.

Note:

If your problem is not answered above, please contact us via email, we will respond within 24 hours.

Email: info@tozostore.com

Battery Warning!

This product has built in lithium battery. Do not expose the product to strong sunlight, fire or throw it into the fire to avoid explosion.

TOZO®

www.tozostore.com

NC9

ACTIVE NOISE CANCELLING

User Manual

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.